Engduino IDE – System Manual

Compilation of the Engduino IDE

With either the repository pulled, or the zip file downloaded and extracted, the command "ant build.xml" can be used to compile the source code, and the command "ant run" can be used to compile, create a jar and run the software.

Running the Engduino IDE

The Engduino IDE can be run by running the engduino_IDE.jar file inside the dist directory.