

	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
3	2.0122.931	HI T-Fuel	Fuel temperature too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
4	2.0122.932	SS T-Fuel	Fuel temperature too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
5	2.0121.931	HI T-Charge Air	Charge air temperature too high (limit 1) ==> Check InterCooler (Alarm Configuration Parameter, for details see PR 2.8008.100)
6	2.0121.932	SS T-Charge Air	Charge air temperature too high (limit 2) ==> Check InterCooler (Alarm Configuration Parameter, for details see PR 2.8008.100)
9	2.0124.931	HI T-Coolant Intercooler	Coolant temperature of InterCooler too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
10	2.0124.932	SS T-Coolant Intercooler	Coolant temperature of InterCooler too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
15	2.0100.921	LO P-Lube Oil	Pressure of lube oil too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
16	2.0100.922	SS P-Lube Oil	Pressure of lube oil too low (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
19	2.0126.931	HI T-Exhaust A	Exhaust gas temperature (A-side) too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
20	2.0126.932	SS T-Exhaust A	Exhaust gas temperature (A-side) too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
21	2.0127.931	HI T-Exhaust B	Exhaust gas temperature (B-side) too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
22	2.0127.932	SS T-Exhaust B	Exhaust gas temperature (B-side) too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
23	2.0152.921	LO Coolant Level	Coolant level too low (limit 1) ==> Check coolant level in compensation container (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
25	2.0154.931	HI P-Diff-Lube Oil	Differential pressure of oilfilter too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
26	2.0154.932	SS P-Diff-Lube Oil	Differential pressure of oilfilter too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
27	2.0151.931	HI Level Leakage Fuel	Level of leakage fuel too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
29	1.8004.206	HI ETC Idle Speed too High	Idle Speed of one of the switcheable chargers too high. (Alarm Configuration Parameter, for details see PR 2.8008.100)
30	2.2510.932	SS Engine Overspeed	Engine Overspeed (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
31	2.3011.931	HI ETC1 Overspeed	Speed of basic charger too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
32	2.3012.932	SS ETC1 Overspeed	Speed of basic charger too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
33	2.0114.931	HI P-Diff-Fuel	Differential pressure of fuelfilter too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
34	2.0114.932	SS P-Diff-Fuel	Differential pressure of fuelfilter too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
36	2.3013.931	HI ETC2 Overspeed	Speed of 1st switcheable charger too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
37	2.3013.912	SS ETC2 Overspeed	Speed of 1st switcheable charger too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
38	1.8004.205	AL ETC Speed Deviation	Speed deviation between basic turbo charger and one of the switcheable chargers. (Alarm Configuration Parameter, for details see PR 2.8008.100)
39	1.8004.204	AL ETC2 CutIn Failure	Switching of charger ETC2 failed. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
44	2.0153.921	LO Coolant Level Intercooler	Coolant level of intercooler too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
51	2.0125.931	HI T-Lube Oil	Lube oil temperature too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
52	2.0125.932	SS T-Lube Oil	Lube oil temperature too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
57	2.0101.921	LO P-Coolant	Coolant pressure too low (limit 1) ==> check cooling cycle. (Alarm Configuration Parameter, for details see PR 2.8008.100)
58	2.0101.922	SS P-Coolant	Coolant pressure too low (limit 2) ==> Engine stop or limitation of the injection quantity ==> check cooling cycle (Alarm Configuration Parameter, for details see PR 2.8008.100)
59	2.0120.933	SS T-Coolant L3	Coolant temperature too high/ too low (limit 3). (Alarm Configuration Parameter, for details see PR 2.8008.100)
60	2.0120.934	SS T-Coolant L4	Coolant temperature too high/ too low (limit 4). (Alarm Configuration Parameter, for details see PR 2.8008.100)
63	2.0106.931	HI P-Crank Case	Crankcase pressure too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
64	2.0106.932	SS P-Crank Case	Crankcase pressure too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
65	2.0102.921	LO P-Fuel	Fuel supply pressure too low (limit 1) ==> Check filter, fuel on low-pressure side (Alarm Configuration Parameter, for details see PR 2.8008.100)
66	2.0102.922	SS P-Fuel	Fuel supply pressure too low (limit 2) ==> Check filter (low-pressure side) (Alarm Configuration Parameter, for details see PR 2.8008.100)
67	2.0120.931	HI T-Coolant	Coolant temperature too high (limit 1) ==> Check circulation of coolant (Alarm Configuration Parameter, for details see PR 2.8008.100)
68	2.0120.932	SS T-Coolant	Coolant temperature too high (limit 2) ==> Check circulation of coolant (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
81	1.8004.046	AL Rail Leakage	Rail pressure gradient too low for Start or too high for Stop (==> High-pressure system leaks, air in the system) (Alarm Configuration Parameter, for details see PR 2.8008.100)
82	2.0104.931	HI P-Fuel (Common Rail)	Rail pressure > setpoint value => DBR reduction, shift of start of injection delayed (==> interphase transformer sticks or connections of the interphase transformer) (Alarm Configuration Parameter, for details see PR 2.8008.100)
83	2.0104.921	LO P-Fuel (Common Rail)	Rail pressure < setpoint value => DBR reduction (==> interphase transformer defective or leakage in high-pressure system) (Alarm Configuration Parameter, for details see PR 2.8008.100)
85	2.0128.931	HI T-Umbblasen	'Umbblasen' temperature too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
86	2.0128.932	SS T-Umbblasen	'Umbblasen' temperature too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
89	2.2500.030	SS Engine Speed too Low	Engine is being stalled. The engine speed of the normally operating engine dropped below the limit from parameter 2.2500.027 Limit Engine Speed Low without any stop request. For safety reason the engine is stopped when this event occurs. (Alarm Configuration Parameter, for details see PR 2.8008.100)
90	2.1090.925	SS Idle Speed Not Reached	Idle speed not reached ==> Start abort ==> pay attention to other messages (Alarm Configuration Parameter, for details see PR 2.8008.100)
91	2.1090.924	SS Release Speed Not Reached	Acceleration speed not reached ==> Start abort ==> observe other messages (Alarm Configuration Parameter, for details see PR 2.8008.100)
92	2.1090.923	SS Starter Speed Not Reached	Starter speed not reached ==> Start abort ==> Starter does not turn or turns too slowly (Alarm Configuration Parameter, for details see PR 2.8008.100)
93	2.1090.922	SS T-Preheat	Preheat temperature too low (limit 2) ==> Coolant temperature for engine start too low ==> Bolting engine start (Alarm Configuration Parameter, for details see PR 2.8008.100)
94	2.1090.921	LO T-Preheat	Preheat temperature too low (limit 1) ==> Coolant temperature for engine start too low (Alarm Configuration Parameter, for details see PR 2.8008.100)
95	2.1090.920	AL Prelubrication Fault	Prelubrication fault. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
102	1.8004.624	AL Fuel Cons. Counter Defect	Fuel consumption counter defect. (Alarm Configuration Parameter, for details see PR 2.8008.100)
104	1.8004.623	AL Eng Hours Counter Defect	Engine Hours Counter defect. (Alarm Configuration Parameter, for details see PR 2.8008.100)
118	2.0140.921	LO ECU Power Supply Voltage	Power supply voltage too low (limit 1) ==> Check battery / generator (Alarm Configuration Parameter, for details see PR 2.8008.100)
119	2.0140.922	LOLO ECU Power Supply Voltage	Power supply voltage too low (limit 2) ==> Check battery / generator (Alarm Configuration Parameter, for details see PR 2.8008.100)
120	2.0140.931	HI ECU Power Supply Voltage	Power supply voltage too high (limit 1) ==> Check battery / generator (Alarm Configuration Parameter, for details see PR 2.8008.100)
121	2.0140.932	HIHI ECU Power Supply Voltage	Power supply voltage too high (limit 2) ==> Check battery / generator (Alarm Configuration Parameter, for details see PR 2.8008.100)
122	2.0132.921	HI T-ECU	Temperature of electronic too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
141	1.1088.007	AL Power too high	This alarm is set if the average of the engine power of the last 24 hours exceeded the value specified by PR1.1088.001. (Alarm Configuration Parameter, for details see PR 2.8008.100)
142	1.1088.006	AL MCR exceeded 1 hour	This alarm is set if in the last 12 hours the MCR was exceeded longer than 1 hour. (Alarm Configuration Parameter, for details see PR 2.8008.100)
176	2.4000.004	AL LifeData not available	No (fitting) LifeData-Backup-System is available within a delaytime after ECU-Reset . ==> Backup-system has no LifeData-function or CAN bus interrupted to Backup-system. (Alarm Configuration Parameter, for details see PR 2.8008.100)
177	2.4000.006	AL LifeData restore incomplete	If the ADEC has to restore the LifeData from the backup-system and at least one checksum is wrong after the upload or the upload is incomplete, then this failure is set. (Alarm Configuration Parameter, for details see PR 2.8008.100)
180	2.0500.680	AL CAN1 Node Lost	Connection to a node on CAN bus 1 lost. ==> Check devices connected on CAN (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
181	2.0500.681	AL CAN2 Node Lost	Connection to a node on CAN bus 2 lost. ==> Check devices connected on CAN (Alarm Configuration Parameter, for details see PR 2.8008.100)
182	2.0500.682	AL CAN Wrong Parameters	Incorrect CAN parameter values have been entered. (Alarm Configuration Parameter, for details see PR 2.8008.100)
183	2.0500.683	AL CAN No PU-Data	A CAN mode is selected which the communication is initialized aided of the PU data module. However, required PU data module is not present or is not valid. ==> Check the devices connected by CAN (Alarm Configuration Parameter, for details see PR 2.8008.100)
184	2.0500.684	AL CAN PU-Data Flash Error	During attempt to copy a received PU data module to Flash module, a program error occurred. ==> Electronic service (Alarm Configuration Parameter, for details see PR 2.8008.100)
186	2.0500.686	AL CAN1 Bus Off	CAN Controller 1 is in "Bus Off" state => Automatic switchover to CAN2 ==>causes e.g. short circuit, massive interference or baud rate incompatibility (Alarm Configuration Parameter, for details see PR 2.8008.100)
187	2.0500.687	AL CAN1 Error Passive	CAN Controller 1 has signaled a warning. ==> causes e.g. lack of associated nodes, slight interference or short-term bus overload. (Alarm Configuration Parameter, for details see PR 2.8008.100)
188	2.0500.688	AL CAN2 Bus Off	CAN-Controller 2 is in "Bus Off" state => Automatic switchover to CAN 1 ==>causes e.g. short circuit, massive interference or baud rate incompatibility. (Alarm Configuration Parameter, for details see PR 2.8008.100)
189	2.0500.689	AL CAN2 Error Passive	CAN Controller 2 has signaled a warning. ==> causes e.g. lack of associated nodes, slight interference or short-term bus overload. (Alarm Configuration Parameter, for details see PR 2.8008.100)
190	2.0500.690	AL EMU Parameter Not Supported	EMU parameters are not supported. ==> Incompatibility (Alarm Configuration Parameter, for details see PR 2.8008.100)
201	1.8004.570	SD T-Coolant	Coolant temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B6), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
202	1.8004.572	SD T-Fuel	Fuel temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B33), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
203	1.8004.571	SD T-Charge Air	Charge air temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B9), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
204	1.8004.602	SD Level Lube Oil	Level sensor for lube oil defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
205	1.8004.574	SD T-Coolant Intercooler	Intercooler coolant temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B26), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
206	1.8004.576	SD T-Exhaust A	Exhaust gas temperature-sensor on A-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.21), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
207	1.8004.577	SD T-Exhaust B	Exhaust gas temperature-sensor on B-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.22), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
208	1.8004.566	SD P-Charge Air	Charge air pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B10), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
211	1.8004.563	SD P-Lube Oil	Lube oil pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
212	1.8004.564	SD P-Coolant	Collant pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B16), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
213	1.8004.569	SD P-Coolant Intercooler	Intercooler coolant pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B43), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
214	1.8004.568	SD P-CrankCase	Crankcase pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B50), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
215	1.8004.567	SD P-HD	Rail pressure-sensor defect. ==> High-pressure controller emergency operation ==> short circuit or cable breakage ==> Check sensor and cable (B48), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
216	1.8004.575	SD T-Lube Oil	Lube oil temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B7), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
219	1.8004.573	SD T-Intake Air	Intake air temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B3), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
220	1.8004.584	SD Level Coolant Water	Sensor for coolant level defect. ==> short circuit or cable breakage ==> Check sensor and cable (F33), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
221	1.8004.585	SD P-Diff Lube Oil	Sensor for differential pressure of lube oil defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
222	1.8004.582	SD Level Leakage Fuel	Sensor for leakage level of fuel defect. ==> short circuit or cable breakage ==> Check sensor and cable (F46), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
223	1.8004.583	SD Level Coolant Intercooler	Sensor for coolant level of intercooler defect. ==> short circuit or cable breakage ==> Check sensor and cable (F57), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
227	1.8004.620	SD P-Lube Oil before Filter	Pressure sensor for lube oil before filter defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5.3), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
228	1.8004.595	SD P-Fuel before Filter	Fuel pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B5.3), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
229	1.8004.562	AL Stop Camshaft Sensor Defect	Sensor of Camshaft defect and sensor of crankshaft defect before. ==> Engine stop ==> Check sensor and cable of B1, if necessary replace it. ==> After Engine restart curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
230	1.8004.498	SD Crankshaft Speed	Sensor defect on crankshaft. ==> short circuit or cable breakage ==> Check sensor and cable (B13), if necessary replace it. After Engine restart follows curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
231	1.8004.499	SD Camshaft Speed	Sensor defect on camshaft. ==> short circuit or cable breakage ==> Check sensor and cable (B1), if necessary replace it. After Engine restart follows curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
232	1.3011.128	SD Charger 1 Speed	Speed-sensor of basic charger defect. ==> short circuit or cable breakage ==> Check sensor and cable (B44.1), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
233	1.3011.129	SD Charger 2 Speed	Speed-sensor of switching charger defect. ==> short circuit or cable breakage ==> Check sensor and cable (B44.2), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
239	1.8004.598	SD P-Diff Fuel	Sensor for differential pressure of lfuel defect. ==> only if SD-Alarme Fuel b. Filter or Fuel after Filter (Alarm Configuration Parameter, for details see PR 2.8008.100)
240	1.8004.565	SD P-Fuel	Fuel pressure-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B34), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
241	1.8004.581	SD T-Umblasen	Temperature-sensor of recirculated charge air defect. ==> short circuit or cable breakage ==> Check sensor and cable (B49), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
242	1.8004.622	SD T-Coolant (R)	Redundant coolant temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
244	1.8004.621	SD P-Lube Oil (R)	Redundant pressure sensor for lube oil defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
245	2.8006.589	SD ECU Power Supply Voltage	Internal ECU error. ==> electronic defect (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
266	2.8006.586	SD Speed Demand	Analog speed demand defect. ==> short circuit or cable breakage ==> Check setpoint tachogenerator and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
268	2.8006.591	SD Spinning Value	Analog spinning value defect. ==> short circuit or cable breakage (Alarm Configuration Parameter, for details see PR 2.8008.100)
269	2.8006.588	SD Loadp. Analog filt	Filtered analog load pulse signal not available. ==> short circuit or cable breakage ==> Check cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
270	2.8006.590	SD Frequency Input	Frequency input defect ==> short circuit or cable breakage (Alarm Configuration Parameter, for details see PR 2.8008.100)
301	1.8004.500	AL Timing Cylinder A1	Error in timing of injector cylinder A1: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
302	1.8004.501	AL Timing Cylinder A2	Error in timing of injector cylinder A2: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
303	1.8004.502	AL Timing Cylinder A3	Error in timing of injector cylinder A3: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
304	1.8004.503	AL Timing Cylinder A4	Error in timing of injector cylinder A4: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
305	1.8004.504	AL Timing Cylinder A5	Error in timing of injector cylinder A5: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
306	1.8004.505	AL Timing Cylinder A6	Error in timing of injector cylinder A6: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
307	1.8004.506	AL Timing Cylinder A7	Error in timing of injector cylinder A7: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
308	1.8004.507	AL Timing Cylinder A8	Error in timing of injector cylinder A8: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
309	1.8004.508	AL Timing Cylinder A9	Error in timing of injector cylinder A9: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
310	1.8004.509	AL Timing Cylinder A10	Error in timing of injector cylinder A10: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
311	1.8004.510	AL Timing Cylinder B1	Error in timing of injector cylinder B1: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
312	1.8004.511	AL Timing Cylinder B2	Error in timing of injector cylinder B2: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
313	1.8004.512	AL Timing Cylinder B3	Error in timing of injector cylinder B3: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
314	1.8004.513	AL Timing Cylinder B4	Error in timing of injector cylinder B4: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
315	1.8004.514	AL Timing Cylinder B5	Error in timing of injector cylinder B5: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
316	1.8004.515	AL Timing Cylinder B6	Error in timing of injector cylinder B6: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
317	1.8004.516	AL Timing Cylinder B7	Error in timing of injector cylinder B7: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
318	1.8004.517	AL Timing Cylinder B8	Error in timing of injector cylinder B8: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
319	1.8004.518	AL Timing Cylinder B9	Error in timing of injector cylinder B9: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
320	1.8004.519	AL Timing Cylinder B10	Error in timing of injector cylinder B10: timing value too low / high. ==> if very often replace solenoid (Alarm Configuration Parameter, for details see PR 2.8008.100)
321	1.8004.520	AL Wiring Cylinder A1	Short circuit in injector cable of cylinder A1. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
322	1.8004.521	AL Wiring Cylinder A2	Short circuit in injector cable of cylinder A2. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
323	1.8004.522	AL Wiring Cylinder A3	Short circuit in injector cable of cylinder A3. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
324	1.8004.523	AL Wiring Cylinder A4	Short circuit in injector cable of cylinder A4. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
325	1.8004.524	AL Wiring Cylinder A5	Short circuit in injector cable of cylinder A5. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
326	1.8004.525	AL Wiring Cylinder A6	Short circuit in injector cable of cylinder A6. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
327	1.8004.526	AL Wiring Cylinder A7	Short circuit in injector cable of cylinder A7. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
328	1.8004.527	AL Wiring Cylinder A8	Short circuit in injector cable of cylinder A8. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
329	1.8004.528	AL Wiring Cylinder A9	Short circuit in injector cable of cylinder A9. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
330	1.8004.529	AL Wiring Cylinder A10	Short circuit in injector cable of cylinder A10. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
331	1.8004.530	AL Wiring Cylinder B1	Short circuit in injector cable of cylinder B1. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
332	1.8004.531	AL Wiring Cylinder B2	Short circuit in injector cable of cylinder B2. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
333	1.8004.532	AL Wiring Cylinder B3	Short circuit in injector cable of cylinder B3. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
334	1.8004.533	AL Wiring Cylinder B4	Short circuit in injector cable of cylinder B4. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
335	1.8004.534	AL Wiring Cylinder B5	Short circuit in injector cable of cylinder B5. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
336	1.8004.535	AL Wiring Cylinder B6	Short circuit in injector cable of cylinder B6. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
337	1.8004.536	AL Wiring Cylinder B7	Short circuit in injector cable of cylinder B7. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
338	1.8004.537	AL Wiring Cylinder B8	Short circuit in injector cable of cylinder B8. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
339	1.8004.538	AL Wiring Cylinder B9	Short circuit in injector cable of cylinder B9. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
340	1.8004.539	AL Wiring Cylinder B10	Short circuit in injector cable of cylinder B10. ==> interrupted ignition ==> Remove short circuit of solenoid (plus to ground) (e.g. replace injector) ==> after engine restart curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
341	1.8004.540	AL Open Load Cylinder A1	Open load in injector cable of cylinder A1 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
342	1.8004.541	AL Open Load Cylinder A2	Open load in injector cable of cylinder A2 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
343	1.8004.542	AL Open Load Cylinder A3	Open load in injector cable of cylinder A3 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
344	1.8004.543	AL Open Load Cylinder A4	Open load in injector cable of cylinder A4 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
345	1.8004.544	AL Open Load Cylinder A5	Open load in injector cable of cylinder A5 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
346	1.8004.545	AL Open Load Cylinder A6	Open load in injector cable of cylinder A6 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
347	1.8004.546	AL Open Load Cylinder A7	Open load in injector cable of cylinder A7 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
348	1.8004.547	AL Open Load Cylinder A8	Open load in injector cable of cylinder A8 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
349	1.8004.548	AL Open Load Cylinder A9	Open load in injector cable of cylinder A9 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
350	1.8004.549	AL Open Load Cylinder A10	Open load in injector cable of cylinder A10 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
351	1.8004.550	AL Open Load Cylinder B1	Open load in injector cable of cylinder B1 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
352	1.8004.551	AL Open Load Cylinder B2	Open load in injector cable of cylinder B2 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
353	1.8004.552	AL Open Load Cylinder B3	Open load in injector cable of cylinder B3 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
354	1.8004.553	AL Open Load Cylinder B4	Open load in injector cable of cylinder B4 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
355	1.8004.554	AL Open Load Cylinder B5	Open load in injector cable of cylinder B5 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
356	1.8004.555	AL Open Load Cylinder B6	Open load in injector cable of cylinder B6 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
357	1.8004.556	AL Open Load Cylinder B7	Open load in injector cable of cylinder B7 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
358	1.8004.557	AL Open Load Cylinder B8	Open load in injector cable of cylinder B8 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
359	1.8004.558	AL Open Load Cylinder B9	Open load in injector cable of cylinder B9 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
360	1.8004.559	AL Open Load Cylinder B10	Open load in injector cable of cylinder B10 ==> Interrupted ignition ==> Check cable and solenoid if open load (e.g. replace injector) ==> after cycle curing of failure (Alarm Configuration Parameter, for details see PR 2.8008.100)
361	1.8004.496	AL Power Stage Low	Internal error of electronic (electronic defect possible) ==> Start ITS ==> if electronic o.k. continue to pay attention to messages. If bit "1.1020.021" (Power Stage Failure: Stop Engine) set ==> Engine stop. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
362	1.8004.497	AL Power Stage High	Internal error of electronic (electronic defect possible) ==> Start ITS ==> if electronic o.k. continue to pay attention to messages. If bit "1.1020.021" (Power Stage Failure: Stop Engine) set ==> Engine stop. (Alarm Configuration Parameter, for details see PR 2.8008.100)
363	1.8004.560	AL Stop Power Stage	Internal error of electronic (electronic defect possible) ==> Start ITS ==> if electronic o.k. continue to pay attention to messages. If bit "1.1020.021" (Power Stage Failure: Stop Engine) set ==> Engine stop. (Alarm Configuration Parameter, for details see PR 2.8008.100)
365	1.8004.561	AL Stop MV-Wiring Ground	Cable line error. Engine Stop possible via Protection Module Possible causes: 1. short circuit of injector line-plus to ground. 2. short circuit of injector line-minus to ground. -> Check cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
371	1.8004.634	AL Wiring TO 1	Short circuit or open load on transistor output 1 (TO 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
372	1.8004.635	AL Wiring TO 2	Short circuit or open load on transistor output 2 (TO 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
373	1.8004.636	AL Wiring TO 3	Short circuit or open load on transistor output 3 (TO 3). (Alarm Configuration Parameter, for details see PR 2.8008.100)
374	1.8004.637	AL Wiring TO 4	Short circuit or open load on transistor output 4 (TO 4). (Alarm Configuration Parameter, for details see PR 2.8008.100)
381	2.8006.638	AL Wiring TOP 1	Short circuit or open load on transistor output plant 1 (TOP 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
382	2.8006.639	AL Wiring TOP 2	Short circuit or open load on transistor output plant 2 (TOP 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
383	2.8006.640	AL Wiring TOP 3	Short circuit or open load on transistor output plant 3 (TOP 3). (Alarm Configuration Parameter, for details see PR 2.8008.100)
384	2.8006.641	AL Wiring TOP 4	Short circuit or open load on transistor output plant 4 (TOP 4). (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
390	1.1085.009	AL MCR exceeded	DBR/MCR Function: MCR (Maximum Continuous Rating) is exceeded. (Alarm Configuration Parameter, for details see PR 2.8008.100)
392	2.0480.197	HI T-Coolant Red	Redundant coolant temperature too high (limit 1) ==> Check circulation of coolant (Alarm Configuration Parameter, for details see PR 2.8008.100)
393	2.0480.199	SS T-Coolant Red	Redundant coolant temperature too high (limit 2) ==> Check circulation of coolant (Alarm Configuration Parameter, for details see PR 2.8008.100)
394	2.0480.297	LO P-Lube Oil Red	Redundant pressure of lube oil too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
395	2.0480.299	SS P-Lube Oil Red	Redundant pressure of lube oil too low (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
396	1.0480.193	TD T-Coolant Sensor Deviation	Maximum deviation of T-Coolant sensors
397	1.0480.293	TD P-Oil Sensor Deviation	Maximum deviation of P-Oil sensors
400	2.8006.625	AL Open Load Digital Input 1	Open Load on digitil input 1. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
401	2.8006.626	AL Open Load Digital Input 2	Open Load on digitil input 2. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
402	2.8006.627	AL Open Load Digital Input 3	Open Load on digitil input 3. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
403	2.8006.628	AL Open Load Digital Input 4	Open Load on digitil input 4. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
404	2.8006.629	AL Open Load Digital Input 5	Open Load on digitil input 5. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
405	2.8006.630	AL Open Load Digital Input 6	Open Load on digitil input 6. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
406	2.8006.631	AL Open Load Digital Input 7	Open Load on digitil input 7. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
407	2.8006.632	AL Open Load Digital Input 8	Open Load on digitil input 8. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
408	2.8006.633	AL Open Load Emerg. Stop Input ESI	Open Load on input for emergency stop. ==> cable breakage or no resistance above switch (Alarm Configuration Parameter, for details see PR 2.8008.100)
410	2.0141.921	LO U-PDU	Power driver voltage (injectors) too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
411	2.0141.922	LOLO U-PDU	Power driver voltage (injectors) too low (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
412	2.0141.931	HI U-PDU	Power driver voltage (injectors) too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
413	2.0141.932	HIHI U-PDU	Power driver voltage (injectors) too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
414	2.0156.931	HI Level Water Fuel Prefilter	Water level of fuel prefilter too high (limit 1) ==> empty fuel prefilter (Alarm Configuration Parameter, for details see PR 2.8008.100)
415	2.0107.921	LO P-Coolant InterCooler	Coolant pressure of InterCooler too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
416	2.0107.922	SS P-Coolant InterCooler	Coolant pressure of InterCooler too low (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
417	1.8004.594	SD Level Water Fuel Prefilter	Water level-sensor of fuel prefilter defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
419	1.8004.604	SD T-Coolant b.Engine	Coolant In temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable (B3), if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
420	2.0160.921	AL L1 Aux 1	Input of Aux 1 injured limit 1. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
421	2.0160.922	AL L2 Aux1	Input of Aux 1 injured limit 2. (Alarm Configuration Parameter, for details see PR 2.8008.100)
428	2.0130.921	AL L1 T-Aux 1	Temperature input of Aux 1 injured limit 1. (Alarm Configuration Parameter, for details see PR 2.8008.100)
434	2.0173.931	HI T-Coolant before Engine	Coolant temperature too high (limit 1) ==> Check circulation of coolant (Alarm Configuration Parameter, for details see PR 2.8008.100)
440	2.0110.921	AL L1 P-Aux 1	Pressure input of Aux 1 injured limit 1. (Alarm Configuration Parameter, for details see PR 2.8008.100)
442	2.0110.931	AL L2 P-Aux1	Pressure input of Aux 1 injured limit 2. (Alarm Configuration Parameter, for details see PR 2.8008.100)
444	1.8004.578	SD U-PDU	Sensor defect of Injector Power driver unit. ==> Internal error of ECU7. Change ECU7. (Alarm Configuration Parameter, for details see PR 2.8008.100)
445	1.8004.580	SD P-Ambient Air	Ambient air pressure-sensor defect. (Alarm Configuration Parameter, for details see PR 2.8008.100)
448	2.0103.931	HI P-Charge Air	Pressure of charge air too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
449	2.0103.932	SS P-Charge Air	Pressure of charge air too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
450	2.8006.592	SD Idle/End-Torque Input [%]	Input of Idle/End-Torque defect. ==> short circuit or cable breakage ==> Check transmitter and cable, if necessary replace it. After Engine restart follows curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
454	2.7000.011	SS Power Reduction Active	Power Reduction is activated. (Alarm Configuration Parameter, for details see PR 2.8008.100)
455	2.8006.650	AL L1 Aux1 Plant	Input of Aux 1 (plant) injured limit 1. (Alarm Configuration Parameter, for details see PR 2.8008.100)
456	2.8006.651	AL L2 Aux1 Plant	Input of Aux 1 (plant) injured limit 2. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
460	2.8006.652	HI T-Exhaust EMU	Exhaust gas temperature of EMU too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
461	2.8006.653	LO T-Exhaust EMU	Exhaust gas temperature of EMU too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
462	2.8006.654	HI T-Coolant EMU	Coolant temperature of EMU injured limit 1. (Alarm Configuration Parameter, for details see PR 2.8008.100)
464	1.8004.589	SD P-AUX 1	Analog input for pressure Aux 1 defect. ==> short circuit or cable breakage ==> Check transmitter of pressure and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
467	2.0130.922	AL L2 T-Aux1	Temperature input of Aux 1 injured limit 2. (Alarm Configuration Parameter, for details see PR 2.8008.100)
468	1.8004.579	SD T-AUX 1	Analog input for Temperature Aux 1 defect. (Alarm Configuration Parameter, for details see PR 2.8008.100)
469	1.8004.590	SD AUX 1	Analog input for Aux 1 defect. ==> short circuit or cable breakage ==> Check transmitter and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
470	1.8004.587	SD T-ECU	ECU temperature-sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
471	1.8004.592	SD Coil Current	Coil Current sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
472	2.8006.593	AL Stop SD	Engine stop, because critical channel has sensor defect. (Alarm Configuration Parameter, for details see PR 2.8008.100)
473	1.8004.593	AL Wiring PWM_CM2	Open load or short circuit on channel PWM_CM2. (Alarm Configuration Parameter, for details see PR 2.8008.100)
474	2.8006.655	AL Wiring FO	Open load or short circuit on frequency output (FO) channel. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
475	1.8010.009	AL CR Trigger Engine Stop	Released in case of an engine stop in order to trigger the crash recorder. (Alarm Configuration Parameter, for details see PR 2.8008.100)
476	1.8010.007	AL Crash Rec. Init. Error	Initial error of crash recorder. (Alarm Configuration Parameter, for details see PR 2.8008.100)
478	2.8006.001	AL Comb. Alarm Yel (Plant)	Combined Alarm YELLOW (Plant). (Alarm Configuration Parameter, for details see PR 2.8008.100)
479	2.8006.002	AL Comb. Alarm Red (Plant)	Combined Alarm RED (Plant). (Alarm Configuration Parameter, for details see PR 2.8008.100)
480	2.0291.921	AL Ext. Engine Protection	External Engine Protection function active. (Alarm Configuration Parameter, for details see PR 2.8008.100)
482	1.8004.596	SD T-Exhaust C	Exhaust gas temperature-sensor on A-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.23), if necessary replace it. After Engine restart follows curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
483	1.8004.597	SD T-Exhaust D	Exhaust gas temperature-sensor on A-side defect. ==> short circuit or cable breakage ==> Check sensor and cable (B4.24), if necessary replace it. After Engine restart follows curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
484	2.0133.931	HI T-Exhaust C	Exhaust gas temperature (C-side) too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
485	2.0133.932	SS T-Exhaust C	Exhaust gas temperature (C-side) too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
486	2.0134.931	HI T-Exhaust D	Exhaust gas temperature (D-side) too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
487	2.0134.932	SS T-Exhaust D	Exhaust gas temperature (D-side) too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
488	2.3014.931	HI ETC3 Overspeed	Speed of 2nd switcheable charger too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
489	2.3014.932	SS ETC3 Overspeed	Speed of 2nd switchable charger too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
490	2.3015.931	HI ETC4 Overspeed	Speed of 3rd switchable charger too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
491	2.3015.932	SS ETC4 Overspeed	Speed of 3rd switchable charger too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
492	1.8004.202	AL ETC4 CutIn Failure	Switching of charger ETC4 failed. (Alarm Configuration Parameter, for details see PR 2.8008.100)
493	1.8004.203	AL ETC3 CutIn Failure	Switching of charger ETC3 failed. (Alarm Configuration Parameter, for details see PR 2.8008.100)
500	1.4500.900	AL Wiring POM Starter 1	A wiring fault has been detected in the connection of starter 1 of POM. This could be an open load, cable break or short circuit. ==> Check connection between POM and starter. (Alarm Configuration Parameter, for details see PR 2.8008.100)
501	1.4500.901	AL Wiring POM Starter 2	A wiring fault has been detected in the connection of starter 2 of POM. This could be an open load, cable break or short circuit. ==> Check connection between POM and starter. (Alarm Configuration Parameter, for details see PR 2.8008.100)
502	1.4500.902	AL Open Load POM Alternator	An open load on POM's alternator output has been detected. ==> Check connection between POM and alternator. (Alarm Configuration Parameter, for details see PR 2.8008.100)
503	1.4500.903	AL Battery Not Charging	Battery is not being charged by alternator. ==> Check alternator and connection. (Alarm Configuration Parameter, for details see PR 2.8008.100)
504	1.4500.904	AL CAN POM Node Lost	POM is missing on CAN bus. ==> Check connection and POM. If additional Alarm 508 is active, there is a resistor in the harness missing (Alarm Configuration Parameter, for details see PR 2.8008.100)
506	1.4500.906	AL Low Starter Voltage	Battery voltage is too low for starting. ==> Check starter battery and cabling. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
507	1.4500.907	AL POM Error	Fault of POM identification resistor or internal recognition or connection problem. ==> Check POM cabling, ID resistor and DI3 bridge in plug X21. (Alarm Configuration Parameter, for details see PR 2.8008.100)
508	1.4500.908	AL Wrong POM-ID	POM sends a different identification number (ID) than expected. If additional Alarm 504 is activ, there is a rsistor in the harness missing ==> Check POM harness. (Alarm Configuration Parameter, for details see PR 2.8008.100)
510	2.7002.010	AL Override applied	Override applied. (Alarm Configuration Parameter, for details see PR 2.8008.100)
515	2.1090.926	AL Starter Not Engaged	Starter of POM could not be engaged. => New starting attempt. If the number of automatic starting attempts from PR 1.1090.134 Number of Starting Attempts has been executed, starting procedure is aborted. Check POM, starter and cabling. (Alarm Configuration Parameter, for details see PR 2.8008.100)
519	1.0158.921	Oillevel Calibration Error	Calibration value could not write to flash or SD-Oilniveau (Alarm Configuration Parameter, for details see PR 2.8008.100)
531	1.1044.900	AL Wiring PWM_CM1	Open load or short circuit on channel PWM_CM1. (Alarm Configuration Parameter, for details see PR 2.8008.100)
532	1.1046.900	AL Wiring PWM1	Open load or short circuit on channel PWM1. (Alarm Configuration Parameter, for details see PR 2.8008.100)
533	1.1047.900	AL Wiring PWM2	Open load or short circuit on channel PWM2. (Alarm Configuration Parameter, for details see PR 2.8008.100)
543	2.0555.005	AL Multiple FDH Slaves	There is more than one device which is configured as Backup for FDH-Functionality. (Alarm Configuration Parameter, for details see PR 2.8008.100)
544	2.0555.003	AL Configuration Changed	Gets active in case of changing system configuration e. g. by changing ECU- or SAM-Device. Remains until undo procedure or data is transfered by a valid maintenance case. Is cancelled automatically. (Alarm Configuration Parameter, for details see PR 2.8008.100)
549	2.7001.952	AL Power Cut-Off detected	This is the alarm from the function Emergency Stop Counter. ECU power was disconnected while the engine was still running. This could lead to a possible overpressure in the high pressure system which might damage the engine. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
551	2.2510.933	SS Engine Overspeed Camshaft	Engine Overspeed Camshaft (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
555	2.0555.001	AL Call MTU Field Service	Gets active in case of completing a maintenance-case which manipulates Engine-Parameters. Remains also after switching on-off ECU until a valid release code is entered via Display- and Button-Control of SAM-Device. Release Code is available via Internet by a special procedure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
576	1.1075.083	AL ESCM Override	Exceeding of the corrected current MCR- odr DBR/MCR value. Engine Overload! (Alarm- Configurations- Parameter, for details see PR 2.8008.100)
577	1.0137.900	SD T-Lube Oil Pan	T-Lube Oil Pan sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
582	1.1005.006	AL Emergency Stop Failed	The Emergency Stop Alarm appears when motor does not stop after Emergency Signal within a time given by the 1.1005.004 delay Parameter. Alarm Configuration Parameter, for details see PR 2.8008.100
584	2.1090.927	AL CAN startclearance failed	Motorstart impossible due to faulty CAN message: pv_bMotorstartClearance
586	2.0159.911	LO P-Oil Refill Pump	Pressure of oil refill pump too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
588	1.0159.910	SD P-Oil Refill Pump	Pressure sensor and cable , if necessary replace it./c
593	2.1090.929	AL T-Lube Oil Pan Low	T-Lube Oil Pan temperature too low (Alarm Configuration Parameter, for details see PR 2.8008.100)
596	1.8004.645	AL Develop PR Set	The used parameter set is a develop parameter set. The alarm remains set until a series parameter set is loaded. (Alarm Configuration Parameter, for details see PR 2.8008.100)
600	1.8004.646	SD T-Exhaust A+B	SD T-Exhaust A and T-Exhaust B (Alarm Configuration Parameter, for details see PR 2.8008.100)
601	1.3011.227	SD ETC1+ETC2	SD ETC1 and ETC2 (Alarm Configuration Parameter, for details see PR 2.8008.100)
602	2.1090.930	AL CAN Engine Start Lock	Alarm is set if PV 2.090.414 is set and a start request is active. Reset of the alarm is performed if start request is inactive. (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
606	2.0500.691	AL Double Nodes Lost CAN 1 + 2	A node is lost at both busses (Alarm Configuration Parameter, for details see PR 2.8008.100)
614	2.0119.001	AL L1 P-Fuel Add.sec.fuelfilt. Diff	Fuel Prefilter Difference to hight (Alarm Configuration Parameter, for details see PR 2.8008.100)
625	1.8004.600	SD P-Fuel bef. Add.sec.fuelfilter	Analog input for pressure P-Fuel before Prefilter defect. ==> short circuit or cable breakage ==> Check transmitter of pressure and cable, if necessary replace it. After Engine restart follows curing of failure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
641	1.8012.902	AL System Reset by Watchdog	System Restart by Watchdog detected. (Alarm Configuration Parameter, for details see PR 2.8008.100)
687	1.0150.920	SD Lube Oil Level Switch	Levelsensor for lube oil defect. ==> short circuit or cable breakage ==> Check sensor and cable (B24), if necessary replace it. Alarm is moved back with fault cure. (Alarm Configuration Parameter, for details see PR 2.8008.100)
690	1.0150.921	AI Lube Oil Level Low	Alarm Level Lube Oil too low (Alarm Configuration Parameter, for details see PR 2.8008.100)
759	2.0080.921	AL L1 T-Fuel b.Engine	Fuel temperature before Engine too high (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
760	2.0080.922	AL L2 T-Fuel b.Engine	Fuel temperature before Engine too high (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
761	1.0080.900	SD T-Fuel b.Engine	T-Lube Oil Pan sensor defect. ==> short circuit or cable breakage ==> Check sensor and cable, if necessary replace it. (Alarm Configuration Parameter, for details see PR 2.8008.100)
782	1.0222.920	SD-P-Lubeoil ETC A	SD Lubrication Oil Pressure Turbocharger (Alarm Configuration Parameter, for details see PR 2.8008.100)
788	1.3000.069	ZA ETC Speed Failure detected	Cylinder Cutout Modul has detected a failure of the ECT 1 or 2 Speed (Alarm Configuration Parameter, for details see PR 2.8008.100)
850	2.0900.002	SD Alive FIP	Frequency input defect ==> short circuit or cable breakage or Failure in Backup ECU ==> no Alive-Signal (Alarm Configuration Parameter, for details see PR 2.8008.100)



	Alarms	FSW-No 2_2_33_1_11_3	FSW Plant	
		FSW-No 2_1_1_1_20_3	FSW Engine	.

No	ZKP-No	Name	Description
856	1.0223.920	SD-P-Lubeoil ETC B	(Alarm Configuration Parameter, for details see PR 2.8008.100)
858	2.0223.921	AL L1 P-Lubeoil ETC B	Pressure of lube oil too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
867	2.0222.923	AL L1 P-Lubeoil ETC A	Pressure of lube oil too low (limit 1). (Alarm Configuration Parameter, for details see PR 2.8008.100)
868	2.0222.924	AL L2 P-Lubeoil ETC A	Pressure of lube oil too low (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)
869	2.0223.922	AL L2 P-Lubeoil ETC B	Pressure of lube oil too low (limit 2). (Alarm Configuration Parameter, for details see PR 2.8008.100)

