





Update 11/6/18 Dave Shinsel











Dynamixel Servo Connection



3.6v-5v SDA SCL Mode Factory use 0v Ground



To enter the I2C mode of operation leave the mode pin unconnected