




ANT SWITCH



B34/39 LPF




B1 Duplexer

B2 Duplexer


B3 Duplexer

B5 Duplexer


B8 Duplexer




B7 TRX



PRX B7 & B38_B41 Switch




GPS




B4/B17/B20/B28 TRX



B20 TRX




B20/B28A/B28B PRX SW









GPS+WIFI+BT




PM8916 CHARGING




GPIO&MPP




BATT CONNECTOR





Circuit of Ext. Charge



PM8916 GND









1

2

3

4

5

6


7

8

モジュール 一覧



部品番号	部品名	HW_VER_5	HW_VER_4	HW_VER_3
15393	4G01A	1	1	0
15397	4G01E	0	0	1
15398	4G01K	0	1	0
15399	4G01A	1	0	0


部品番号	部品名	HW_VER_2	HW_VER_1
-SA	Ver1.0	1	1
-SB	Ver1.1	1	0
-0	Ver1.2	0	1
-1	Ver1.3	0	0



メモリADCは、このリレーを介して接続されています。

GPIO 111 will be in O/P mode on Power On Reset, After Power On Reset, SW can configure





A

B

C

D

E

F

A


B

C

D

E

F



1

2

3

4

5

6

7

8

A

B

C

D

E

F

A


B


C


D

E

F











SPEAKER PA

YDA_5v_POWER




ツ贏アIC」ヤラ「メ箭シセヨサヨテモヲヲ


LCD 0.75V Driver



LCM CONN




LCD LDO




LCD BACKLIGHT

LM3630A slave address_10x38




LCM CONN EMI


MIPIイ築や才羸。チソソス鮎TBカヒ




USB SWITCH




UPDATE




OVP




Test Confige




TEST POINT




JTAG DEBUG




G - sensor




M - sensor	
------------	--




CTP COB




A.L.S.+P.S sensor module






SIM1 Card




SIM2 Card




TF_CARD



TF_LDO



POWER&VOL KEY



MAIN_Camera

A


B

C

D

E

F



IMX179 slave address 0X21

SUB_Camera

A


B

C

D


E

F




OV5695 slave address 0X6D

Camera_LDO




Camera_VDDIO



Camera_DVDD

Flash LED Driver



LM3642 slave address 0X63

