

Electronics Customer Service Guide

Common problems and step-by-step solutions for 5 home appliances

1. Refrigerator

Problem:

Interior light not working

Solution:

Open the fridge door and press the door switch several times to reset it. If the bulb is accessible, replace it with the correct wattage LED bulb. If the light still fails, unplug the fridge for 60 seconds and plug back in.

Problem:

Not cooling properly

Solution:

Check that the temperature dial is not set to 0 or Off. Clean the condenser coils at the back or underneath using a vacuum brush. Ensure at least 5 cm clearance around the unit for ventilation.

Problem:

Loud noise or vibration

Solution:

Level the fridge using the adjustable feet so all four corners contact the floor. Check that no item inside is rattling against shelves. If humming continues, the compressor may require a service call.

Problem:

Water leaking inside or on floor

Solution:

Clear the defrost drain hole at the back interior wall with warm water and a small brush. Check the door gasket for tears, as a damaged seal allows warm air in and causes excess condensation.

2. Washing Machine

Problem:

Machine not starting

Solution:

Confirm the door is firmly closed until it clicks. Most machines lock before starting. Check the power plug and reset the circuit breaker if tripped. Press and hold the Start button for 3 seconds on some models.

Problem:

Excessive vibration during spin

Solution:

Redistribute the laundry load evenly inside the drum. Use a spirit level and adjust the levelling feet until all four contact the floor. Avoid washing a single heavy item alone; add a few towels to balance the load.

Problem:

Foul smell from drum

Solution:

Run a hot 90 degree empty cycle with a washing machine cleaner tablet or 250 ml of white vinegar. Leave the door ajar between washes to allow air circulation. Wipe the rubber door seal weekly to prevent mould buildup.

Problem:

Water not draining at end of cycle

Solution:

Check and clear the pump filter behind the small access panel at the front base. Remove any coins, lint, or debris. Inspect the drain hose for kinks and confirm it is not inserted more than 15 cm into the standpipe.

3. Microwave Oven

Problem:

Not heating food

Solution:

Ensure the door latches fully so both safety switches engage. Run a test with a cup of water on full power for 1 minute. If the water stays cold, the magnetron may have failed and requires a certified technician.

Problem:

Turntable not rotating

Solution:

Remove the turntable glass plate, ring guide, and roller wheels. Wash and refit them correctly, making sure the ring sits in the groove. If the motor is silent, unplug the unit for 2 minutes then retry.

Problem:

Display or buttons not responding

Solution:

Unplug the microwave from the wall for 5 minutes to perform a hard reset, then plug back in. If a child lock indicator is lit, hold the Stop or Cancel button for 3 seconds to deactivate it.

Problem:

Sparking or arcing inside

Solution:

Immediately stop the microwave. Remove any metallic utensils, foil, or containers with metallic trim. Clean any dried food residue from the interior walls and waveguide cover, as burnt deposits cause arcing.

4. Air Conditioner

Problem:

Not cooling the room

Solution:

Set the mode to Cool and the temperature at least 4 degrees below room temperature. Clean or replace the air filter since a clogged filter reduces airflow significantly. Keep all doors and windows closed while the unit is running.

Problem:

Water dripping inside the room

Solution:

The condensate drain line may be blocked. Flush it with warm water and one tablespoon of bleach using a wet-dry vacuum or thin brush. Ensure the indoor unit is tilted very slightly toward the drain side.

Problem:

Remote control not working

Solution:

Replace the remote batteries with fresh ones of the correct type. Point the remote directly at the receiver on the indoor unit from within 6 metres. If still unresponsive, clean the remote IR emitter tip with a dry cloth.

Problem:

Unusual smell when AC is on

Solution:

Clean the filter and evaporator coil fins with a coil cleaner spray. Run fan-only mode for 30 minutes to dry out moisture in the unit. A persistent chemical smell may indicate a refrigerant leak and requires a technician.

5. Television

Problem:

TV not turning on

Solution:

Check the power cord connection at both the TV and the wall socket. Try a different socket to rule out a tripped outlet. Unplug the TV for 60 seconds, hold the physical Power button on the TV body for 15 seconds, then plug back in.

Problem:

No picture but sound is working

Solution:

Press the Input or Source button to cycle through HDMI ports and other inputs. Increase the backlight setting in the display menu. If the screen remains completely black, the backlight or main board may need professional repair.

Problem:

Poor or pixelated image quality

Solution:

Check the HDMI cable for damage and try a replacement cable. Go to Settings, select Picture, and reset picture settings to defaults. For antenna-based channels, re-scan for channels in the Channels menu.

Problem:

Smart TV Wi-Fi keeps disconnecting

Solution:

Move the router closer to the TV or use a Wi-Fi extender. Forget the network in TV settings and reconnect. Change the router channel to a fixed channel such as 6 or 11. If possible, connect via an Ethernet cable for a stable connection.
