User Manual: Air fryers

Safety

Please read all instructions before using your ShopAI Home air fryer. This appliance is for household use only. Keep it away from water and other liquids. Do not immerse the cord, plug, or unit in water. Unplug when not in use and before cleaning. Allow it to cool before putting on or taking off parts. Do not operate with a damaged cord or plug. If it malfunctions or is dropped or damaged in any way, contact our support team at support@shopai-home.example or use the chat on our website. Do not attempt to repair it yourself.

Place the air fryer on a stable, level, heat-resistant surface. Keep it at least 15 cm away from walls and other objects. Do not place it under overhead cupboards or near curtains. Never cover the air vents. Hot air comes out of the exhaust during cooking; keep hands and face away. Use the handle to remove the basket. The basket, tray, and inside of the appliance get very hot. Always use oven gloves or a heat-proof pad.

Do not fill the basket with oil or any liquid. This is not a deep fryer. Only put food in the basket. Never put the appliance on a hob, even an induction one, or in a heated oven. Do not put anything on top of the appliance while in use. Do not leave it unattended. Keep the cord away from hot surfaces and do not let it hang over the edge of the worktop. This appliance can be used by children aged 8 and above and persons with reduced physical, sensory or mental capabilities if they have been given supervision or instruction concerning use in a safe way and understand the hazards. Children must not play with the appliance. Cleaning and user maintenance should not be done by children unless they are older than 8 and supervised. Keep the appliance and cord out of reach of children under 8.

Setup

Before first use, remove all packaging, stickers, and labels from the air fryer. Check that the voltage on the rating label matches your mains supply. Wash the basket and tray in warm soapy water, rinse and dry fully. Wipe the inside and outside of the main unit with a soft damp cloth. Do not immerse the main unit in water.

Place the air fryer on a stable, level, heat-resistant surface, away from walls, curtains, and other appliances. Leave at least 15 cm of space on all sides and above. Plug it in. The display or control dials will light up. Your model may have digital touch controls or manual dials, but the basic process is the same.

Before cooking food, run the air fryer empty for about 10 minutes at 200°C to burn off any manufacturing residue. This may produce a slight odour or light smoke; that is normal. Open a window or turn on an extractor fan. After this, let it cool, then wipe the inside again.

You do not need to preheat the air fryer for most foods. If your model has a preheat function, it will tell you when it is ready. Place the food in the basket; do not overfill. For best results, leave space between pieces for air to circulate. Insert the basket fully into the unit. Set the temperature and time according to the recipe or the guide that came with your model. Press start. You can remove the basket at any time to shake or check food; cooking will pause on most models and resume when you replace the basket. When done, remove the basket carefully and place it on a heat-proof surface. Use tongs or a spoon to remove food. Always unplug after use.

Everyday use

Using your air fryer every day is simple. Place the food in the basket and slide it back into the unit. Select the temperature and time using the controls. As a guide, most foods cook well at 180°C to 200°C. For chips or other small items, shake the basket halfway through cooking. For larger items, turn them over. Cooking

times vary by model and food amount. Check food a few minutes before the set time to avoid overcooking. You can always add more time if needed.

Do not put wet batter or very wet food in the basket; it will drip. Pat food dry before cooking. Brush or spray a little oil on food for a crispier result. Do not use aerosol cooking spray inside the basket; it can damage the non-stick coating. Use a refillable oil sprayer or brush a thin layer of oil.

Some models have preset programmes for common foods like chips, chicken, fish, or cake. These are starting points; adjust if needed. If your model has a digital display, use the + and - buttons to set time and temperature. For manual dials, turn the dials to the desired settings.

The air fryer works best when the basket is not overcrowded. Stacking too much food results in uneven cooking. For best results, cook in a single layer. If you have a large amount, cook in batches.

After cooking, remove the basket carefully. The basket and food are very hot. Place the basket on a heat-proof mat or trivet. Do not put it directly on a delicate worktop. Use silicone or wooden utensils to remove food to protect the non-stick coating. Never use metal tongs or forks inside the basket. Empty any crumbs or oil from the basket after it cools.

Cleaning and care

Clean your air fryer after every use to prevent build-up of grease and food residue. Always unplug the appliance and let it cool completely before cleaning. Do not immerse the main unit, cord, or plug in water or any liquid. Wipe the outside and inside of the main unit with a soft, damp cloth. For stubborn stains, use a mild detergent on the cloth, then wipe with a clean damp cloth. Dry thoroughly.

The basket and tray are usually dishwasher safe on the top rack; check the care label on your model. Alternatively, wash them in warm soapy water with a soft sponge or brush. Do not use steel wool, abrasive cleaners, or scouring pads; they will scratch the non-stick coating. If food is stuck, soak the basket in warm soapy water for 10–15 minutes, then wash. Rinse and dry fully before placing back in the unit.

The heating element inside the top of the unit may collect grease over time. To clean it, let the unit cool, then wipe the element gently with a soft, dry brush or a damp cloth. Do not use water directly on the element. If you notice any odour, mix a paste of bicarbonate of soda and water, apply to the basket and tray, leave for 10 minutes, then rinse and dry.

Do not use metal utensils or sharp objects in the basket. Store the air fryer in a dry, cool place. Do not wrap the cord tightly around the unit; use the cord storage area if provided. Ensure everything is completely dry before storing to prevent mould or odours.

Troubleshooting

Here are common issues and how to fix them.

The air fryer does not switch on. Check that it is plugged in and the socket is switched on. Ensure the basket is fully inserted; most models have a safety switch that prevents operation if the basket is not locked in place. If it still does not work, try another socket. If the problem continues, contact our support team.

White smoke comes out during cooking. This can happen when cooking fatty foods; fat drips onto the hot element and causes smoke. This is normal but can be reduced by patting food dry, using less oil, and cleaning the basket and heating element regularly. If smoke is excessive or has a strong burning smell, stop using and contact support.

The basket does not slide in smoothly. Check for food debris or crumbs blocking the tracks. Clean the

outside of the basket and inside cavity. Do not force it. Ensure the tray is seated correctly inside the basket.

Food is not cooked evenly. Shake or turn food halfway through cooking. Do not overfill the basket. Cook in batches for large amounts. Cut food into similar sizes for even cooking.

Food is not crispy or is too dry. Lightly brush or spray food with a little oil before cooking. Adjust temperature and time. For chips, soak in water for 30 minutes, dry, then toss in a teaspoon of oil before air frying.

Error code on display. Note the code, unplug the appliance, wait 30 seconds, plug it back in. If the code persists, contact support with the code and your order number.

The air fryer is noisy. A gentle fan sound is normal. If there is rattling, ensure the tray is in place and no loose parts are inside. If the noise is very loud or grinding, stop use and contact support.

The basket handle is loose. Stop using and contact support. Do not attempt to fix it yourself.

Warranty

All ShopAI Home air fryers come with a one-year warranty from the date of delivery. This covers manufacturing defects in materials and workmanship under normal household use. The warranty does not cover damage from misuse, neglect, commercial use, or normal wear and tear. It also does not cover cosmetic damage such as scratches or dents, or damage from not following the instructions.

If your air fryer becomes defective within the warranty period, contact our support team at support@shopai-home.example or use the chat on our website. Please have your order number ready. You may need to provide photos or a video showing the fault. Our team will guide you through the next steps, which may include a replacement, repair, or refund, at our discretion.

If you receive a damaged or defective air fryer, please contact us within 10 days of delivery and keep the original packaging. For damaged-in-transit claims, you must provide a photo of the damage. If the item is approved for return or replacement, we will arrange pickup or provide instructions.

As a reminder, if delivery took 8 days or more, you may receive a goodwill store credit of about 10% of the order value. This is separate from the warranty.

Please see our returns policy for details on change-of-mind returns; such items must be unused and in original condition, and returns are inspected before approval. This warranty is in addition to your statutory rights as a consumer.