User Manual: Coffee makers

Safety

Read all instructions before using your ShopAI Home coffee maker. This appliance is for household use only. Do not use outdoors. Place the coffee maker on a flat, stable, dry surface away from the edge. Keep it away from water sources, such as sinks or areas where it may get splashed. Ensure the area around the coffee maker is clear, especially above it, as steam and hot air will be released during brewing. Plug the coffee maker directly into a wall socket. Do not use an extension cord or adaptor. Always switch off and unplug the coffee maker before cleaning, moving, or when not in use. Never pull the cord to unplug; grip the plug itself. If the cord is damaged, stop using the machine immediately and contact us. Do not let the cord hang over the edge of counters, where it can be pulled or tripped over. Keep children away from the coffee maker while it is in use. Supervise them around it at all times. The carafe, hot plate, and steam areas become very hot. Do not touch hot surfaces. Use handles and knobs. Let the machine cool before touching or cleaning. Never immerse the main body, cord, or plug in water or any liquid. Do not use the coffee maker if it has been dropped, damaged, or is not working correctly. Return it for inspection and repair. Only use accessories and parts supplied or recommended by ShopAI Home. Other attachments may cause fire, electric shock, or injury. Do not open the water tank lid or remove the carafe during brewing. Wait until the cycle is complete. The carafe is designed for this coffee maker. Do not use it on a hob, in a microwave, or in an oven. Do not place an empty carafe back on a hot plate immediately after emptying it while the plate is still hot; let it cool slightly. Do not use the machine without water in the tank. Descale regularly as described in the Cleaning and care section. Failure to descale may cause overheating or damage. Do not clean with abrasive pads, harsh chemicals, or solvent-based cleaners. Use a soft, damp cloth for the body. Wash removable parts in warm soapy water and dry thoroughly before use. If the coffee maker malfunctions or shows signs of damage, stop using it and contact our support team.

Setup

Before first use, remove all packaging, stickers, and protective films from the coffee maker and its parts. Keep the box and packing materials for safe transport if needed later. Wash all removable parts, such as the carafe, filter basket, and water tank lid, in warm soapy water. Rinse well and dry completely. Wipe the outside of the machine with a clean, damp cloth. Do not immerse the main body in water. Place the coffee maker on a dry, flat, stable surface near a wall socket. Ensure there is at least 10 cm of space on all sides for airflow. Do not place it under cupboards; steam may damage them. Fill the water tank with clean, cold water using the markings on the tank or the water level window. Do not exceed the maximum line. Use only cold, fresh water. Do not use milk, flavoured liquids, or hot water. Insert the reusable filter or a paper filter into the filter basket as per your model. If using a paper filter, ensure it fits flat and does not fold over. Add ground coffee to the filter. Use medium-grind coffee recommended for drip coffee makers. As a starting guide, use one heaped tablespoon (about 7 grams) of ground coffee per 150 ml of water. Adjust amount to your taste. Close the filter basket and make sure the carafe is correctly placed on the hot plate with the lid closed. Ensure no part of the machine is touching the carafe except the designated support. Plug the coffee maker into a wall socket. Switch on the socket if it has a switch. Press the power button. The indicator light will turn on, and brewing will start within a minute. The first brew may take slightly longer as the system primes. We recommend discarding the first full carafe of coffee after setup to clean the internal pipes. After brewing, the machine may keep the hot plate on to keep the coffee warm. For models with auto shut-off, the machine will turn off automatically after the set time. If your model has a timer or strength selector, set these according to the instructions in the quick start guide provided with your model. Always unplug the

coffee maker after use if you leave home for an extended period.

Everyday use

Each time you use the coffee maker, start by ensuring it is clean and dry. Fill the water tank with fresh, cold water up to the desired level using the cup markings. Do not fill above the maximum line. Use the carafe itself to measure water if your model does not have a tank marking. Open the filter basket and place the permanent filter or a fresh paper filter inside. Add the desired amount of ground coffee. Use medium-ground coffee suitable for drip machines. A standard ratio is one heaped tablespoon (about 7 grams) per 150 ml of water. Adjust to suit your taste. If using pre-ground coffee, make sure it is not too fine, as this can clog the filter and cause overflow. If you prefer stronger coffee, add slightly more grounds rather than overfilling the water tank. Close the filter basket securely. Place the empty carafe on the hot plate with its lid closed. Ensure the carafe is centred. Plug in and switch on the coffee maker. Press the start or brew button. The indicator light will glow. The machine will begin to drip hot water over the coffee grounds within a minute. Do not open the filter basket or remove the carafe during brewing. Wait until the dripping stops and the water tank is empty. Once brewing is complete, the hot plate will keep the carafe warm for a set period. If your model has a keep-warm function, the time may be preset or adjustable. If your model has a pause-and-serve feature, you may remove the carafe briefly to pour a cup while brewing, but replace it within 20 seconds to prevent overflow. After you have poured all the coffee, switch off the coffee maker and unplug it. Let the machine cool down before cleaning. Discard the used coffee grounds. If you use paper filters, dispose of them with the grounds. If you use a permanent filter, empty the grounds into a bin and wash the filter. Rinse the carafe and filter basket with warm water after each use. Wipe the exterior with a soft damp cloth if there are any spills. Do not leave stale coffee in the carafe for long periods. Always store the machine clean and dry.

Cleaning and care

Regular cleaning keeps your coffee maker working well and your coffee tasting fresh. Always unplug the machine and let it cool completely before cleaning. Never immerse the main body, power cord, or plug in water or any liquid. Clean the outside with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or chemical sprays. These can damage the surface. Wipe up spills immediately. Remove the carafe, filter basket, and any other removable parts. Wash them in warm, soapy water after each use. Rinse thoroughly and dry with a soft cloth or allow to air dry. Do not wash removable parts in a dishwasher unless your model's manual states it is dishwasher safe. The filter basket may have small crevices; use a soft brush to remove coffee oils. If your carafe develops coffee stains, fill it with warm water and add a little baking soda or mild detergent. Let it sit for 15 minutes, then scrub gently with a soft sponge. Rinse well. Descale the coffee maker regularly. How often depends on the hardness of your water and how frequently you use the machine. As a general guide, descale every 1 to 2 months, or when you notice longer brewing times, unusual noises, or white mineral deposits. Use a commercial descaling solution suitable for coffee makers, or a mixture of equal parts white vinegar and water. Fill the water tank with the descaling solution up to the maximum level. Place the empty carafe on the hot plate. Run a brew cycle without coffee grounds. After the cycle, discard the solution. Run two more full cycles with fresh, clean water only to rinse internal parts. Wipe the exterior after descaling. If your model has a water filter, replace it according to the manufacturer's instructions, usually every 2 to 3 months. Do not use the coffee maker while it is being descaled. Never submerge the carafe in cold water when it is hot, as it may crack. Let it cool naturally. Store the coffee maker in a dry place, with the lid open to allow air circulation and prevent odours.

Troubleshooting

If you have a problem with your coffee maker, check this list before contacting support.

- Coffee maker does not turn on: Ensure it is plugged into a working wall socket and switched on. Check that the power button is pressed. Try a different socket. If it still does not start, contact support.
- Coffee is not brewing: Check that the water tank has water. Make sure the filter basket is closed properly and the carafe is on the hot plate. If it still will not brew, the machine may need descaling or have a faulty element.
- Coffee is too weak: Use more ground coffee. Increase the amount by one tablespoon per 150 ml. Ensure you are using a medium grind suitable for drip machines. If the grind is too coarse, extraction will be weak.
- Coffee is too strong or bitter: Use less ground coffee. Check that the grind is not too fine. If using dark roasted coffee, try a lighter roast. Clean the machine, as old coffee oils can make brew bitter.
- Brewing takes too long: The machine may need descaling. Mineral build-up slows heating. Run a descaling cycle. If the problem continues, contact support.
- Coffee grounds in the carafe: If using a paper filter, check it is properly seated and not folded. If using a permanent filter, clean it thoroughly. If the grind is too fine, use a slightly coarser grind.
- Water or coffee overflows from the filter basket: You may have used too much water or too fine a grind. Remove the carafe too long during pause-and-serve can cause overflow. Reduce the water level or use a coarser grind.
- Carafe leaks or drips: Check for cracks or chips. The carafe lid may not be on correctly. If damaged, stop using it and order a replacement.
- Coffee is not hot enough: The hot plate may be turned off or set to a low temperature. Switch on the keep-warm function if available. Pre-heat the carafe with hot water before brewing. If problem persists, contact support.
- Strange noise during brewing: The water pump or heating element may be making noise when the tank is nearly empty. Descale if noise continues.
- Display or lights not working: Unplug the machine, wait one minute, plug it back in. If problem remains, contact support.
- Leaking from the bottom of the machine: Stop using immediately, unplug, and contact support. Do not attempt to open the base.

If none of these solve the issue, contact ShopAI Home support for help. Do not try to repair the machine yourself.

Warranty

Your ShopAI Home coffee maker comes with a 1-year warranty from the date of delivery. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage caused by misuse, neglect, accidents, improper cleaning, descaling, or use with incorrect voltage. Normal wear and tear, such as scratches, staining, or fading, is not covered. The warranty is valid only for the original purchaser and is not transferable. This warranty does not affect your statutory rights under Indian consumer law. If your coffee maker develops a fault within the warranty period, please contact us at support@shopai-home.example with your order number, delivery date, and a description of the problem. Include photos or a video if possible. Our support team will help diagnose the issue. We may ask you to try troubleshooting steps or send additional photos. If a repair or replacement is required, we will arrange collection of the faulty unit. We will provide a replacement unit or repair the product. Replacement units may be new or refurbished to the same model or an equivalent if the original is unavailable. The replacement unit carries the remaining warranty from the original purchase date. The warranty does not

cover delivery costs for the return unless the fault is covered under warranty. We will advise you of the process when you contact us. Keep your proof of purchase, such as the invoice or order confirmation email, as you may need it to claim warranty service. If you have modified or attempted to repair the coffee maker, the warranty becomes void. Use only authorised service or support from ShopAI Home. For out-of-warranty products, we may still offer repair or a discount on a new model at our discretion. Contact support for more information. This warranty is in addition to and does not limit your rights under the Consumer Protection Act, 2019.