User Manual: Headphones and earbuds

Safety

Please read all instructions before using your ShopAI Home headphones or earbuds. Keep this manual for future reference.

- Do not listen at high volumes for long periods. This can damage your hearing. A safe level is one where you can still hear people around you.
- Be careful when using headphones or earbuds while walking, cycling, or driving. They can block out traffic sounds and cause accidents. Do not use them where being unaware of your surroundings is dangerous.
- Keep the product away from water and moisture. Do not use in rain, near sinks, or in humid places. If they get wet, dry them completely before use.
- Do not use damaged headphones or earbuds, especially if the cable is frayed or the casing is cracked. This can lead to electric shock or injury.
- Keep small parts, such as ear tips, away from children. They are a choking hazard.
- Do not insert earbuds too deeply into your ears. If they feel uncomfortable, try a different size ear tip or adjust the fit.
- Stop using if you feel discomfort, pain, or irritation in your ears or skin. See a doctor if symptoms continue.
- Use only the charging cable or case provided or bought from ShopAI Home. Using the wrong charger can damage the battery or cause fire.
- Do not expose the product to extreme heat, such as inside a car on a hot day, or to open flames.
- The built-in battery should be charged before first use and if not used for a long time. Do not leave the device plugged in for days continuously.
- If the battery leaks or swells, stop using immediately and contact ShopAI Home support. Do not try to repair or replace the battery yourself.
- Keep away from pacemakers and other medical devices. The magnets and electronics may cause interference.

Setup

Thank you for buying ShopAI Home headphones or earbuds. Follow these steps to start using them.

- Unbox: Take the product out of the box. Check that all parts are present. You should have the headphones or earbuds, a charging cable, and any extra ear tips (for earbuds). Some models include a carry case.
- Charge: Before first use, charge the device fully. Connect the supplied cable to a USB charger (not included). A light on the device may turn on. For earbuds, place them in the charging case and connect the case to power. Let them charge until the light shows full, usually 1-2 hours.
- Pair with phone or computer: Turn on Bluetooth on your phone, tablet, or computer. For headphones, press and hold the power or Bluetooth button until the LED flashes quickly. For earbuds, take them out of the case; they usually enter pairing mode automatically. If not, press and hold the button on the case or earbuds. Look for the device name in your Bluetooth list and select it. If asked for a passcode, enter 0000.
- Fit: For headphones, adjust the headband so it sits comfortably. The ear cushions should cover your ears fully. For earbuds, try the different sizes of ear tips to find the one that fits snugly and blocks outside noise.
- Controls: Learn the buttons or touch areas. Common controls: short press to play/pause, long press for voice assistant, double press for next track. Volume may be controlled by buttons or swipes. See the quick start guide in the box for model-specific details.
- Charge again when low: A voice or beep may warn you. Recharge using the cable or case. Keep the

charging contacts clean.

• Update firmware if needed: Some models can be updated using a mobile app. Check the ShopAI Home website for more information.

Everyday use

Your ShopAI Home headphones or earbuds are designed for easy daily use.

• Power and connection: Headphones have a power button. Press and hold to turn on or off. Earbuds turn on when taken out of the case and off when placed back. They will automatically connect to the last paired device if Bluetooth is on.

• Play music and calls: Use the controls to play, pause, skip tracks, and answer or end calls. The microphone is built-in. For best call quality, keep the device within 10 metres of your phone.

• Volume: Adjust volume from your phone or on the device. Be careful not to set it too high.

• Voice assistant: Many models support Google Assistant or Siri. Press and hold the main button to activate.

• Battery life: Battery life varies. On average, headphones last 15-20 hours of playback. Earbuds last 4-6 hours, with extra charges from the case (usually 2-3 full charges). Check the product page for exact figures.

• Charging: Use the supplied cable. Plug into any USB power source. A full charge takes about 1-2 hours. The LED will show red while charging and blue or off when complete.

• Pairing a new device: Turn off Bluetooth on the old device, then put the headphones or earbuds into pairing mode and select them on the new device.

• Reset if needed: If the device is not working properly, you can reset it. Usually, press and hold the power and volume up buttons together for 10 seconds. The LED will flash. Then pair again.

• Using with multiple devices: Some models can connect to two devices at once, e.g., phone and laptop. Refer to the model guide for details.

• Storage: When not in use, keep the device in its case or a clean, dry place. Turn off headphones to save battery.

Cleaning and care

Regular cleaning keeps your headphones or earbuds working well and hygienic.

• Before cleaning, turn off the device and unplug any cables. For earbuds, remove the ear tips.

• Wipe the outside: Use a soft, dry, lint-free cloth. Dampen it slightly with water, but do not let water enter any openings. Do not use alcohol, solvents, or abrasive cleaners.

• Clean the ear cushions (headphones): Remove them if possible. Wipe with a dry or slightly damp cloth. Let them dry completely before reattaching.

• Clean the ear tips (earbuds): Remove the silicone tips. Wash them in warm soapy water. Rinse well and dry fully before putting them back. Replace them if they are torn or misshapen. You can buy replacements from ShopAI Home.

• Clean the mesh and nozzles: Gently brush away earwax or dust with a dry, soft-bristled brush (like a clean toothbrush). Do not push dirt inside. Never insert pins or sharp objects.

• Charging contacts: Wipe the metal contacts on the earbuds and inside the case with a dry cotton swab. If dirty, the earbuds may not charge.

• Storage: Keep in the case (for earbuds) or a pouch (for headphones). Avoid damp or very dusty places. Do not wrap the cable tightly around the device; this can damage wires.

• Avoid extreme temperatures: Do not leave in direct sunlight or a hot car. Heat can damage the battery.

• Battery care: The battery lasts longer if you keep it between 20% and 80%. Avoid full discharge often. If not using for a month or more, charge it to about 50% first.

• Water resistance: Most models are not waterproof. Do not wear them in the shower or rain. If they get wet, wipe immediately and let dry for 24 hours before use.
• If you notice reduced sound quality, check for earwax build-up in the mesh and clean as directed. If the problem continues, contact ShopAI Home support.

Troubleshooting

Here are common problems and how to fix them. If your problem continues, contact support@shopai-home.example or use the chat on our website.

• Problem: Headphones or earbuds do not turn on.
Fix: Charge them for at least 30 minutes. Make sure the charger and cable are working. Try a different USB port. For earbuds, ensure the case has charge and the earbuds are seated correctly.

• Problem: Not pairing with phone.
Fix: Turn off Bluetooth on your phone and on again. Put the device in pairing mode: for headphones, hold power button until LED flashes; for earbuds, take them out of case and hold the case button if needed. Forget the device in your phone's Bluetooth list, then search again. Ensure no other device is connected.

• Problem: Sound cuts in and out.
Fix: Move closer to your phone, ideally within 5 metres. Remove obstacles like walls or bodies. Check for interference from Wi-Fi routers or other Bluetooth devices. Recharge the battery; low battery can cause drops. Reset the device and pair again.

• Problem: One earbud is not working.
Fix: Put both earbuds back in the case for 10 seconds, then take them out. Check if they are charged. Clean the charging contacts. Reset the earbuds as per the manual.

• Problem: Low volume or muffled sound.
Fix: Increase volume on both the device and your phone. Clean the ear tips and mesh. Try a different size ear tip for better seal. Check if your phone's audio balance is centred.

• Problem: Microphone not working during calls.
Fix: Ensure the microphone holes are not blocked or dirty. Clean gently with a dry brush. Check your phone settings to allow the device as microphone. Move away from wind or noise.

• Problem: Headphones not charging.
Fix: Check the cable and port for damage. Try another charging brick. Clean the charging port on the headphones. The LED should light up. If not, contact support.

• Problem: Earbuds not charging in case.
Fix: Clean the metal contacts on the earbuds and inside the case with a dry cloth. Close the case lid properly. Charge the case itself; if the case battery is empty, it won't charge the earbuds.

• Problem: Device pairs but no audio.
Fix: In your phone's Bluetooth settings, ensure media audio is enabled. Restart the phone. Disconnect and reconnect. Try playing from a different app.

• If none of these solve the issue, please contact ShopAI Home support. Do not open or repair the device yourself, as this voids the warranty.

Warranty

ShopAI Home offers a 1-year warranty on all headphones and earbuds from the date of delivery. This covers manufacturing defects and faults that are not caused by misuse.

• What is covered: Defects in materials or workmanship, such as speaker units failing, Bluetooth modules malfunctioning, battery not holding charge within reasonable levels, and buttons or ports not working under normal use.
• What is not covered: Damage from accidents, drops, water, or improper use. Cosmetic wear, torn ear pads, lost ear tips, and damage from third-party chargers. Battery capacity naturally reduces over time and is not covered unless it fails early.
• Making a claim: Contact support@shopai-home.example or use the chat. Provide your order number, a description of the fault, and photos or videos if possible. We may ask you to return the item for inspection.
• Repair or replacement: We will either repair the product at no cost or replace it with an equivalent model if repair is not possible. The replacement may be new or refurbished.
• Warranty period remains: The warranty continues from the original delivery date. A replacement does not restart the 1-year period.
• Shipping for warranty service: ShopAI Home will arrange collection at no cost if the item is within warranty and the claim is accepted.
• Exceptions: If the product is opened or repaired by anyone not authorised by ShopAI Home, the warranty is void.
• For products bought during sales or offers, the warranty remains the same.
• If you have a problem after the warranty period, we may still offer paid repair services. Contact us for details.