User Manual: Electric kettles

Safety

Please read all instructions before using your ShopAI Home electric kettle. This appliance is intended for household use only, for boiling water. Do not use it for any other purpose. Always place the kettle on a flat, stable, dry surface away from the edge of the counter. Keep the kettle, base, and cord away from hot surfaces, open flames, and water splashes. Do not immerse the kettle, base, cord, or plug in water or any other liquid. Ensure your hands are dry before connecting or disconnecting the appliance. Never operate the kettle with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any way. Contact our support team for examination or repair. Do not attempt to repair the appliance yourself; doing so will void the warranty. Use only the base provided with the kettle. Do not use the kettle without water, and do not overfill beyond the maximum mark; boiling water may spill out. Always ensure the lid is securely closed before switching on. Never open the lid while the water is boiling or immediately after, as escaping steam can cause burns. Keep the kettle out of reach of children. Children should be supervised to ensure they do not play with the appliance. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard. The kettle will automatically switch off once the water reaches a rolling boil, but you may also switch it off manually by lifting the switch to the off position. Always unplug the base from the wall socket when not in use and before cleaning. Allow the kettle to cool down completely before cleaning or storing. Do not fill the kettle when it is hot. Do not use an extension cord unless it is rated for the power consumption of the kettle. Use only in dry indoor locations. Save these instructions.

Setup

Remove all packaging materials from the kettle and base. Check that the voltage indicated on the rating label matches your mains supply. Place the base on a flat, stable, heat-resistant surface. Unwind the power cord from the storage area under the base and route it through the cord exit slot so the base sits level. Plug the cord into the base if it is detachable, then plug the base into a wall socket. Before first use, clean the kettle by filling it with water to the maximum mark, boiling, and then discarding the water. Repeat this process once more to remove any manufacturing residues. Your kettle is now ready for everyday use. To remove the kettle from the base, lift it vertically. To place it back, align the kettle with the base and set it down gently; it will connect automatically. Some models have a 360-degree rotational base, allowing you to place the kettle at any angle. If your model has a water level window, check that it is clearly visible and clean. For kettles with a removable filter, ensure the filter is fitted correctly before use. The kettle should only be connected to a power supply after being correctly placed on its base. Do not operate the kettle on a tilted surface. Ensure the lid is closed securely before switching on. Some models have a power indicator light that illuminates when the kettle is on. The switch may be located on the handle or the base, depending on the model. Read the symbols on the switch: 'I' means on and 'O' means off. After boiling, lift the kettle from the base before pouring. Never pour water while the kettle is still on the base. Ensure the base is unplugged when not in use. If your kettle has a cord wrap, wind the cord loosely around it to avoid damage.

Everyday use

Open the lid and fill the kettle with the desired amount of fresh, cold water. Use the water level indicator to avoid overfilling; never exceed the maximum mark or go below the minimum mark if your model has one.

Close the lid firmly. Place the kettle on the base. Insert the plug into the wall socket and switch on if there is a separate power switch on the base. Press the on/off switch to start heating; the indicator light will glow. The kettle will automatically switch off once the water boils. You may also switch it off manually at any time. Wait a few seconds for the water to settle before pouring. Lift the kettle by the handle and pour slowly to avoid splashes. Keep the lid closed while pouring. If you want to reboil, check the water level and add more if necessary. Always use fresh water for boiling; do not reboil water more than once for best taste. Never operate the kettle with an empty heating chamber. If the kettle accidentally switches on with no water, the boil-dry protection will turn it off. Allow it to cool for at least 15 minutes before refilling. The outside of the kettle becomes hot during use; touch only the handle and controls. Do not cover the kettle or base with any cloth or object while in operation. Unplug the kettle from the wall socket when not in use. For safety, do not leave the kettle unattended while boiling. If you hear unusual sounds such as popping or crackling, this is normal scale expansion; clean the kettle regularly. Store the kettle in a dry place, with the cord loosely coiled. If your model has a cordless design, ensure the kettle is fully cooled before storing it on the base. Use the kettle only for boiling water; do not heat milk, tea, or other liquids directly in it.

Cleaning and care

Always unplug the base from the wall socket and allow the kettle to cool completely before cleaning. Never immerse the kettle, base, cord, or plug in water or any other liquid. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or chemical solvents, as they may damage the surface. To remove stubborn stains, use a mild detergent on the cloth, then wipe with a clean damp cloth and dry thoroughly. Clean the interior regularly to prevent limescale build-up. Fill the kettle with a solution of equal parts white vinegar and water to the maximum mark, boil, and let it stand for 30 minutes. Empty the solution and rinse the kettle thoroughly with clean water. For heavy scaling, repeat the process. Alternatively, use a commercial descaler suitable for kettles, following the manufacturer's instructions. Always rinse well after descaling. Some models have a removable scale filter at the spout; clean it periodically under running water. If the filter is not removable, brush it gently with a soft brush. Wipe the base with a dry or slightly damp cloth only. Ensure the electrical connections on the base and kettle are completely dry before use. Do not use the kettle if the power cord or plug is wet. Store the kettle with the lid open to allow air circulation when not in use for long periods. If the exterior is made of stainless steel, you may use a stainless steel cleaner to maintain shine, but ensure it does not come into contact with the interior or electrical parts. For plastic exteriors, avoid exposure to strong sunlight to prevent discoloration. Never place the kettle or base in a dishwasher. Do not attempt to disassemble the kettle; there are no user-serviceable parts inside. If the kettle shows signs of damage, stop using it and contact support.

Troubleshooting

Problem: Kettle does not turn on. Fix: Check that the plug is inserted correctly and the wall switch is on. Ensure the kettle is seated properly on the base. If the model has a separate power switch on the base, turn it on. If it still does not work, try a different wall socket. Problem: Kettle switches off before water boils. Fix: This may be due to limescale build-up. Descale the kettle. If the problem persists, the thermostat may be faulty; contact support. Problem: Water takes too long to boil. Fix: Descale the kettle. Excessive limescale slows heating. Also, ensure you are not overfilling beyond the maximum mark. Problem: Kettle does not switch off automatically. Fix: Make sure the lid is closed properly. If the lid is open or loose, steam escapes and the thermostat may not activate. If the problem continues, stop using the kettle and contact support. Problem: Kettle leaks from the bottom. Fix: Do not overfill beyond the maximum mark. Check for cracks or damage; if found, discontinue use and contact support. Problem: Water tastes or smells odd. Fix: Clean the kettle with vinegar solution as described, then rinse thoroughly. Use fresh water for each boil. Problem:

Indicator light does not glow. Fix: If the kettle heats but the light is off, the light may be faulty but the kettle is safe to use. However, if the kettle does not heat, follow the 'Kettle does not turn on' steps. Problem: Kettle makes unusual noises. Fix: Normal popping or crackling is due to scale; descale the kettle. If you hear loud electrical buzzing, unplug and contact support. Problem: Base gets hot. Fix: Some warmth on the base is normal, but if it is excessively hot, unplug and let it cool. Clean the base contacts with a dry cloth. If it overheats again, contact support. Problem: Power cord feels warm. Fix: If the cord is warm but not hot, it is normal. However, if it is hot or shows damage, stop using the kettle and contact support. Do not attempt to replace the cord yourself.

Warranty

Your ShopAI Home electric kettle comes with a limited warranty of 1 year from the date of delivery, covering defects in materials and workmanship under normal household use. This warranty does not cover damage caused by misuse, abuse, neglect, lack of cleaning, accidents, unauthorized repairs, or use other than boiling water. The warranty is void if the kettle is opened, disassembled, or modified by anyone other than an authorized ShopAI Home service centre. To claim warranty service, contact our support team with your order details and a description of the issue. You may be asked to provide photos or videos to help diagnose the problem. If the issue is confirmed as a manufacturing defect, we will repair or replace the kettle, or provide a refund as deemed appropriate. The warranty is non-transferable and applies only to the original purchaser. Cosmetic damage such as scratches, dents, or discoloration from normal wear and tear is not covered. Accessories such as filters are covered only if defective at the time of delivery. The warranty does not cover the cost of shipping the product to a service centre unless required by law. We are not liable for incidental or consequential damages arising from the use of this product. For warranty claims beyond the initial return window, please provide your order number, delivery date, and a clear description of the fault. Our support team will guide you through the process. This warranty is in addition to your statutory rights under Indian consumer law, which remain unaffected. ShopAI Home reserves the right to inspect the product before approving any warranty claim. If a replacement is provided, the warranty continues from the original delivery date. Keep your purchase receipt or order confirmation as proof of purchase. For any questions, contact ShopAI Home support through the website chat or the given email address.