User Manual: Mixer grinders

Safety

Please read all instructions before using your ShopAI Home mixer grinder. This appliance is intended for household use only. Do not use it outdoors or for commercial purposes. Always place the appliance on a flat, stable, dry surface away from the edge. Keep it away from water, direct sunlight, and hot surfaces such as gas stoves or ovens. Ensure the voltage of your power supply matches the rating on the appliance before plugging it in. Do not operate the mixer grinder with wet hands. Never immerse the motor base, cord, or plug in water or any other liquid. If the cord is damaged, stop using the appliance and contact customer support. Always unplug the appliance when not in use, before assembling or disassembling parts, and before cleaning. Do not let the cord hang over the edge of a table or touch hot surfaces. Keep the appliance and its cord out of reach of children. Children should be supervised to ensure they do not play with the appliance. Do not operate the mixer grinder if any part is broken or missing. Use only attachments and jars supplied by ShopAI Home. Do not use the appliance if the jar is cracked or the blades are bent or damaged. Do not run the mixer grinder empty. Always ensure the jar lid is locked securely before switching on. Do not open the lid or touch the blades while the appliance is running. Wait until the blades stop completely before removing the jar. Do not exceed the maximum capacity marked on the jar. Avoid contact with moving parts. Keep hands, hair, clothing, and utensils away from the blades during operation. Do not use the appliance to blend hot liquids or hot ingredients; allow them to cool to room temperature first. The blades are sharp; handle them with care during cleaning and assembly. Do not leave the appliance unattended while it is in use. If the appliance overheats, the thermal cut-out may switch it off. Unplug it and allow it to cool for at least 30 minutes before using again. Do not use an extension cord unless it is rated appropriately. Do not attempt to repair or modify the appliance. For any faults, contact ShopAI Home support. Save these instructions for future reference.

Setup

Before using your mixer grinder for the first time, remove all packaging materials and check that all parts are present. Your package includes the motor base, one or more jars with lids, and a user manual. Wash all jars, lids, and blades with warm soapy water, rinse well, and dry thoroughly. Wipe the motor base with a soft, dry cloth. Never immerse the motor base in water or any other liquid. Place the motor base on a clean, dry, level surface such as a kitchen counter. Ensure there is enough space around the appliance for air circulation. Plug the power cord into a suitable electrical socket. Do not switch on the appliance until the jar is correctly assembled and placed on the motor base. To assemble a jar, first place the blade assembly onto the jar base if it is not already fixed. Screw the jar base firmly onto the jar. Ensure the rubber gasket is in place to prevent leakage. Fill the jar with ingredients, but do not exceed the maximum capacity mark. Place the lid on the jar and press it down firmly. Some models have a safety interlock; ensure the lid is properly locked in place. Place the assembled jar onto the motor base, aligning the jar handle with the arrow or marking on the base. Turn the jar clockwise until it locks into position. If the jar is not seated correctly, the motor will not start. You are now ready to use the appliance. For the initial use, it is recommended to run the mixer grinder empty for a few seconds to ensure it operates smoothly. Do not run it for more than a few seconds empty. After this quick test, switch off and unplug the appliance. Now fill the jar with your ingredients and proceed as described in the Everyday use section. If you find that the jar does not lock easily, check for any obstruction and try again. Never force the jar onto the base. Keep the appliance clean and dry at all times. Read the Safety section thoroughly before first use.

Everyday use

To use your mixer grinder, first ensure the appliance is unplugged. Select the appropriate jar for your task: use the large jar for wet grinding, such as batters and chutneys; the medium jar for dry grinding spices; and the small jar for chutneys or small quantities. Add your ingredients to the jar. For best results, cut large ingredients into smaller pieces before adding. Do not fill the jar beyond the maximum level. Close the lid securely. Place the jar onto the motor base and turn it to lock. Plug in the appliance. Switch on the power using the main switch, if provided. Then select the desired speed or function: low, medium, high, or pulse. For most tasks, start with a low speed and increase as needed. Use the pulse function for short bursts to control the texture. For wet grinding, add a little water or oil to aid blending. Do not run the appliance continuously for more than 3 minutes at a time; allow it to rest for a minute between cycles. If the motor stops suddenly, it may have overheated. Switch off, unplug, and allow it to cool for 30 minutes before resuming. While the appliance is running, do not insert any utensils into the jar. To add ingredients during operation, remove the small cap from the lid (if available) and drop them through the opening, then replace the cap. When the desired consistency is achieved, switch off the appliance, unplug it, and wait for the blades to stop completely. Then unlock and remove the jar from the base. Open the lid and pour out the contents. Use a spatula to remove any remaining mixture, being careful of the sharp blades. Never put your fingers inside the jar. After use, clean the jar and lid as described in the Cleaning and care section. For dry grinding, ensure the jar is completely dry before adding ingredients. Grind in short bursts to avoid overheating the ingredients. If the mixture sticks to the sides, stop and scrape down with a spatula. Do not run the appliance empty. Follow these simple steps for efficient and long-lasting performance.

Cleaning and care

Always unplug the appliance and wait for the blades to stop before cleaning. Do not immerse the motor base in water or any other liquid. To clean the motor base, wipe it with a soft, damp cloth and dry with a clean towel. Never use abrasive cleaners, steel wool, or harsh chemicals on any part of the appliance. Clean the jars, lids, and blade assemblies after each use to prevent staining and odours. For jars with fixed blades, fill the jar halfway with warm water and a drop of mild dish soap. Place the jar on the motor base, secure the lid, and run the appliance for a few seconds. Then pour out the soapy water and rinse thoroughly with clean water. Alternatively, wash the jar by hand with a soft brush, being careful of the sharp blades. Do not put the jars in a dishwasher unless specifically marked as dishwasher safe. For jars with detachable blades, unscrew the blade assembly from the jar base. Wash all parts in warm soapy water, rinse, and dry completely before reassembling. Ensure the rubber gasket is cleaned and replaced correctly to prevent leakage. Dry all parts completely before storing. Store the appliance with the jars unlocked and the lids off to prevent odours. If stubborn stains remain, make a paste of baking soda and water, apply to the stain, leave for 10 minutes, and scrub gently. For unpleasant smells, blend a mixture of water and lemon juice or vinegar in the jar, then rinse well. Do not use the appliance to blend hot liquids. Never place any part of the mixer grinder in a microwave oven. Keep the appliance away from direct sunlight and moisture. Check the power cord regularly for damage. If the cord is damaged, discontinue use and contact ShopAI Home support. Follow these guidelines to maintain your mixer grinder in good working condition and to ensure food safety.

Troubleshooting

Here are some common problems you may encounter with your mixer grinder and how to fix them.

• Problem: The appliance does not start. Fix: Check that the power cord is plugged into a working socket. Ensure the jar is correctly placed and locked on the motor base; the safety interlock prevents operation if

the jar is not seated properly. Check the lid is closed correctly. If the motor is overheated, wait 30 minutes for it to cool.

- Problem: The motor hums but the blades do not turn. Fix: Switch off immediately and unplug. Remove the jar and check for blockages. If the blades are jammed by hard ingredients, remove some contents and add a little water. Never force the blades.
- Problem: The jar leaks during use. Fix: Ensure the rubber gasket is properly seated and not damaged. Tighten the blade assembly or jar base firmly. Do not overfill the jar beyond the maximum mark.
- Problem: The appliance vibrates excessively. Fix: Ensure the appliance is on a flat, stable surface. Do not overload the jar. Check that the jar is locked straight and not tilted.
- Problem: Food is not ground evenly. Fix: Cut ingredients into smaller pieces before grinding. Fill the jar to an appropriate level—not too full or too empty. Use short pulse bursts for better control.
- Problem: The appliance stops suddenly during use. Fix: The thermal cut-out may have tripped due to overheating. Unplug and let it cool for at least 30 minutes before trying again. Reduce the batch size or running time.
- Problem: The blades are dull or damaged. Fix: Do not use the appliance if blades are damaged. Contact ShopAI Home support for replacement advice.
- Problem: Unpleasant odour in the jar. Fix: Blend a solution of water and lemon juice or baking soda, then rinse thoroughly. Dry completely before storing with the lid off.

If the problem persists, do not attempt to repair the appliance yourself. Contact ShopAI Home support at support@shopai-home.example or use the chat on our website.

Warranty

Your ShopAI Home mixer grinder is covered by a warranty against manufacturing defects for a period of one year from the date of delivery. The motor of the mixer grinder is covered for two years from the date of delivery. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage caused by misuse, abuse, neglect, accidents, modifications, or unauthorised repairs. It also does not cover normal wear and tear of parts such as blades, gaskets, and jars. To make a warranty claim, you must provide proof of purchase, such as the order number or invoice. Please contact our customer support team at support@shopai-home.example or use the chat on our website. You may be required to provide photos or a description of the defect. If a defect is confirmed, we will repair or replace the product or part at our discretion. The warranty is valid only in India. This warranty is in addition to, and does not limit, your statutory rights under Indian consumer law. Please retain your order details for future reference.