User Manual: Toasters and sandwich makers

Safety

When using your toaster or sandwich maker, always follow these safety instructions to reduce the risk of fire, electric shock or injury. Read all instructions before first use. This appliance is for household use only. Do not use outdoors. Do not immerse the appliance, power cord or plug in water or any other liquid. Unplug the appliance when not in use and before cleaning. Allow it to cool before putting on or taking off parts. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact ShopAI Home support for assistance. The use of accessory attachments not recommended by ShopAI Home may cause injuries. Do not let the cord hang over the edge of a table or counter, or touch hot surfaces. Do not place the appliance on or near a hot gas or electric burner, or in a heated oven. To disconnect, turn any control to the off position, then remove the plug from the wall outlet. Do not use the appliance for anything other than its intended use. Oversized foods, metal foil packages or utensils must not be inserted in the toaster, as they may involve a risk of fire or electric shock. A fire may occur if the toaster is covered with or touching flammable material, including curtains, draperies, walls and the like, when in operation. Do not attempt to dislodge food when the toaster is plugged in. For sandwich makers, do not touch the hot cooking plates; always use the handle or knobs. Ensure the lid is securely closed during cooking. Keep the appliance out of reach of children. Children should be supervised to ensure they do not play with the appliance. Do not leave the appliance unattended during use. Unplug from the outlet when not in use and before cleaning. Do not clean with metal scouring pads; pieces can break off the pad and touch electrical parts, creating a risk of electric shock. Save these instructions.

Setup

Before using your ShopAI Home toaster or sandwich maker for the first time, please follow these steps carefully. Remove all packaging materials, including any plastic covers, cardboard or stickers from the appliance and its cord. Check that the appliance is clean and free of dust; wipe the exterior with a soft, damp cloth and dry thoroughly. For sandwich makers, open the lid and wipe the non-stick cooking plates with a damp cloth. Do not immerse the appliance in water.

Place the appliance on a dry, flat, heat-resistant surface, away from the edge of the counter and out of reach of children. Ensure there is at least 10 cm of clear space on all sides for proper air circulation. Do not place the appliance under overhead cabinets or near flammable materials.

Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the rating label on the bottom of the appliance. The toaster or sandwich maker is now ready for use.

For toasters, before toasting bread for the first time, run a browning cycle without bread to burn off any protective oils from the heating elements. This may cause a slight odour or smoke; this is normal and will disappear after one or two cycles. For sandwich makers, lightly coat the cooking plates with a small amount of cooking oil or butter, then close the lid and heat for about five minutes. Let it cool, then wipe away any excess oil with a paper towel. This helps condition the non-stick surface.

Read the Everyday use section of this manual for operating instructions. If you have any questions or notice any damage to the appliance or cord, do not use it and contact ShopAI Home support at support@shopai-home.example or via the website chat.

Everyday use

Using your ShopAI Home toaster:

- Place the toaster on a flat, stable surface and plug it in.
- Set the browning control to your desired level. A lower setting gives lighter toast; a higher setting gives darker toast. For the first use, start with a medium setting to see results.
- Insert one or two slices of bread into the slots. Do not force thick or irregularly shaped bread into the slots; if it does not fit, use thinner slices.
- Press down the lever until it locks into place. The heating elements will turn on and the bread will toast.
- To stop toasting early, press the cancel button. The lever will pop up and the toaster will switch off.
- When the toast is ready, the lever will pop up automatically. Carefully remove the toast, as it and the toaster surfaces will be hot. Do not use metal utensils to remove toast; use wooden or heat-proof plastic tongs.
- Unplug the toaster after use and allow it to cool before moving or cleaning.

Using your ShopAI Home sandwich maker:

- Close the lid and plug in the appliance. The indicator light will turn on, showing that it is heating.
- Wait until the indicator light goes off or changes to the ready colour (per your model) before adding food.
- Open the lid carefully using oven mitts or a dry cloth; the plates are hot.
- Lightly brush the cooking plates with a little oil or butter if desired (especially if your plates are not fully non-stick).
- Place your prepared sandwich or ingredients on the bottom plate. Do not overfill; a thin layer is best.
- Close the lid gently and lock the latch if provided. Do not force the lid shut.
- Cook for 3 to 5 minutes, depending on your recipe and desired crispness. Check occasionally; the indicator light may cycle on and off as the thermostat maintains temperature.
- When cooked, open the lid carefully and remove the food with a plastic or wooden spatula. Never use metal utensils as they can scratch the non-stick surface.
- Unplug the appliance and let it cool completely before cleaning.

Always supervise the appliance while in use. Do not leave it unattended.

Cleaning and care

Regular cleaning keeps your toaster or sandwich maker in good working condition and prevents unpleasant odours or smoke. Always unplug the appliance and allow it to cool completely before cleaning. Never immerse the appliance, cord or plug in water or any other liquid.

For toasters:

- Remove and empty the crumb tray after each use or at least once a week. Most models have a removable tray at the bottom; slide it out, discard crumbs, wipe with a damp cloth, dry thoroughly and slide it back.
- If your toaster does not have a removable crumb tray, turn the toaster upside down over a bin and gently shake out the crumbs. Do not tap the toaster hard or insert any objects into the slots.
- Wipe the exterior with a soft, slightly damp cloth. Do not use abrasive cleaners, scouring pads or chemical sprays. Avoid getting any liquid inside the toaster.
- Do not clean the inside of the toaster with water or any cleaning solution. The heating elements will burn off any small crumbs.

For sandwich makers:

- After the appliance has cooled, wipe the cooking plates with a paper towel or a soft, damp cloth to remove any food residue. For stubborn stains, apply a small amount of mild dish soap to a damp cloth and wipe gently; then wipe with a clean damp cloth to remove soap.

• Never use metal scourers, sharp objects or abrasive cleaning powders; they will damage the non-stick coating.
• Do not put the appliance in a dishwasher.
• Wipe the exterior and the handle with a damp cloth and dry.
• If food is baked on, close the lid and heat the appliance for a minute or two to soften the residue, then wipe carefully with a damp cloth while warm (but not hot enough to burn).
Always ensure all parts are completely dry before storing or using the appliance. Store in a clean, dry place with the cord loosely coiled; do not wrap the cord tightly around the appliance.

Troubleshooting

If you experience a problem with your ShopAI Home toaster or sandwich maker, check the list below for common issues and solutions. If the problem continues, please contact support@shopai-home.example or use the website chat.

• Toaster does not turn on / no heating: Check that the appliance is plugged in and the outlet is working. Try another outlet. Ensure the lever is fully pressed down. If still no heat, the appliance may be faulty; stop using it and contact support.
• Toast comes out too light or too dark: Adjust the browning control to a higher or lower setting. Different breads toast differently; fresher bread needs a higher setting. If you are toasting cold bread, allow it to come to room temperature first.
• Toaster smell or smoke on first use: This is normal for a new toaster due to burning off manufacturing oils. Run two or three empty toasting cycles in a well-ventilated area. If smoke persists, unplug and check crumbs.
• Toast is unevenly browned: Crumbs may have accumulated on one side; clean the crumb tray. Ensure bread slices are of even thickness. If the problem persists, the heating elements may be faulty; contact support.
• Lever does not stay down: The toaster is not plugged in, or the bread is too thin and has lifted the lever. Plug in the toaster. If the lever still pops up immediately, contact support.
• Food stuck in toaster: Unplug the toaster and let it cool. Turn it upside down over a bin and gently shake. Do not use metal objects to remove food.
• Sandwich maker does not heat up: Check the power connection and outlet. The indicator light should be on when heating. If not, the appliance may be faulty; contact support.
• Sandwich maker indicator light never goes off: This is normal for some models; the thermostat cycles the light. If the plates do not heat, contact support.
• Food sticks to the plates: Lightly oil the plates before each use. Do not use metal utensils. If the non-stick coating is scratched, the appliance may still work but more oil will be needed.
• Smoke or burning smell during sandwich making: Some oil or butter may have dripped onto the heating element. Wipe the edges of the plates. Reduce the amount of filling or butter.

Warranty

ShopAI Home provides a limited warranty on all toasters and sandwich makers. The warranty period is 1 year from the date of delivery. For mixer grinder motors, the warranty is 2 years, but this does not apply to toasters or sandwich makers.

This warranty covers defects in materials and workmanship under normal household use. It does not cover damage caused by accident, misuse, abuse, negligence, failure to follow the instructions in this manual, commercial use, or unauthorized repair or modification. It also does not cover normal wear and tear,

cosmetic damage, or damage to the non-stick coating from improper use.

If your appliance becomes defective within the warranty period, please contact ShopAI Home support at support@shopai-home.example or through the website chat. You will need to provide your order number, proof of purchase, and a description of the problem. If the defect is covered, we will either repair the appliance, replace it, or provide a store credit, at our discretion. The warranty is only valid for the original purchaser and is not transferable.

This warranty is in addition to, and does not affect, your statutory rights as a consumer under Indian law. For any warranty claim, you may be required to send photos or videos of the defect. We aim to resolve warranty claims within 10 days of receiving the required information.