Amperia Electrical Lockout and Permit Procedure

Facility access to a live electrical panel requires a valid permit before entry.

Permit ID: 27-A.

If the permit is missing or expired, the technician must stop work and notify dispatch.