

# Arduino Yun 無線網路 設定






















Step1




以YUN當AP










## Step2


#### 選擇AP





http://192.168.240.1








Step3



For more advanced network configuration features, see the <u>advanced configuration panel</u> (<u>luci</u>)

#### 選擇自己的手機分享熱點並輸入密碼








Step3



#### 以手機為AP







# 馬達校正

### 停止

```
void backward() {
  servoRight.writeMicroseconds(1500);
  servoLeft.writeMicroseconds(1500);
}
Full Stop
```

### 上傳程式 MotorTest.ino

圖待補!

### 行進控制

```
void forward() {
    servoRight.writeMicroseconds(1300);
    servoLeft.writeMicroseconds(1700);
}

Top speed clockwise

Top speed counterclockwise
```

### 後退

```
void backward() {
  servoRight.writeMicroseconds(1700);
  servoLeft.writeMicroseconds(1300);
}
```

### 原地左轉?原地右轉?