

DAY-3:

Tasks

1.

List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

No.	Common Issue	Possible Solution
1	Keyboard or mouse is not detected	Unplug the USB device and connect it to another USB port.
2	Keyboard or mouse stops responding	Restart the laptop and reconnect the device.
3	USB connection keeps disconnecting	Check the USB cable for damage and try another USB port.
4	Mouse cursor moves slowly or freezes	Clean the mouse sensor and check the mouse settings/surface.
5	Some keyboard keys do not work	Clean around the affected keys and test the keyboard on another computer. If it still fails, replace the keyboard.

2.

Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step 1: Check the headphones

- Make sure the headphones are turned on.
- Check the battery level.

- Look for the Bluetooth indicator light or sound that confirms pairing mode.

Step 2: Enable Bluetooth on the phone

- Open Settings → Bluetooth.
- Turn Bluetooth ON.
- Check whether the headphones appear under Available Devices.

Step 3: Put the headphones into pairing mode

- Press and hold the Bluetooth/power button until the indicator starts flashing.
- Check if the headphones now appear on the phone.

Step 4: Check if they are connected to another device

- Turn Bluetooth off on nearby laptops, tablets, or other phones.
- Some headphones automatically connect to the last device they used.

Step 5: Forget and reconnect

- On the phone, tap the headphones in the Bluetooth settings.
- Select Forget/Unpair.
- Turn Bluetooth off and back on.
- Put the headphones into pairing mode again and select them from the device list.

Step 6: Restart both devices

- Turn the headphones off and back on.
- Restart the phone.
- Try pairing again.

Step 7: Reset the headphones

- If they still do not connect, perform the manufacturer's Bluetooth/factory reset procedure.
- Then put them back into pairing mode.

Step 8: Test

- Play music or a video and check whether sound comes through the headphones.
- If they still won't connect, test the headphones with another phone to determine whether the problem is with the headphones or the original phone.

3.

A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.

Check the physical connection

- Make sure the webcam's USB cable is firmly connected.
- Try a different USB port.

Check Device Manager

- Right-click Start → Device Manager.
- Look under Cameras, Imaging devices, or Sound, video and game controllers.
- If the webcam has an error symbol, update or reinstall its driver.

Check Windows privacy settings

- Go to Settings → Privacy → Camera.
- Turn on Allow access to the camera on this device.
- Also enable Allow apps to access your camera.

Allow desktop apps to use the camera

- In the Camera privacy settings, make sure Allow desktop apps to access your camera is enabled.

- Zoom needs this permission on Windows 10.

Select the correct camera in Zoom

- Open Zoom → Settings → Video.
- Check the Camera dropdown.
- Select the external USB webcam instead of the built-in webcam.

Close other apps and restart

- Close Camera, Teams, Skype, or any other application that may be using the webcam.
- Restart Zoom and, if necessary, restart the computer.

4.

You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Step 1: Open Windows Settings

- Click Start → Settings.

Step 2: Open printer settings

- Go to Devices → Printers & scanners.

Step 3: Select the printer

- Find the printer showing Offline.
- Click the printer and select Manage.

Step 4: Run the troubleshooter

- Select Run the troubleshooter if the option is available.
- Windows will check the printer and its configuration for common problems.

Step 5: Follow the recommended fixes

The troubleshooter may check things such as:

- Printer connection
- Printer status
- Driver problems
- Print queue problems
- Default printer settings
- Communication between Windows and the printer

Step 6: Apply the suggested solution

- If Windows finds a problem, it explains what was detected and may offer to automatically fix it.
- Follow the instructions shown on screen.

Step 7: Test the printer

- After troubleshooting, return to Printers & scanners.
- Check that the printer now shows Ready/Online.
- Print a test page to confirm that the problem is fixed.

What information does the Troubleshooter provide?

The Windows Troubleshooter tells you what problems it checked, whether it found an issue, and whether it was able to fix it. If it cannot fix the problem, it may provide additional information or recommend further steps, such as checking the connection, drivers, or printer configuration.