


# Qualcomm Technologies International, Ltd.



#### Confidential and Proprietary – Qualcomm Technologies International, Ltd.

(formerly known as Cambridge Silicon Radio Ltd.)

**NO PUBLIC DISCLOSURE PERMITTED:** Please report postings of this document on public servers or websites to: DocCtrlAgent@qualcomm.com.

**Restricted Distribution:** Not to be distributed to anyone who is not an employee of either Qualcomm Technologies International, Ltd.or its affiliated companies without the express approval of Qualcomm Configuration Management.

Not to be used, copied, reproduced, or modified in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm Technologies International, Ltd.

Any software provided with this notice is governed by the Qualcomm Technologies International, Ltd. Terms of Supply or the applicable license agreement at https://www.csrsupport.com/CSRTermsandConditions.

Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. All Qualcomm Incorporated trademarks are used with permission. Other product and brand names may be trademarks or registered trademarks of their respective owners.

This technical data may be subject to U.S. and international export, re-export, or transfer ("export") laws. Diversion contrary to U.S. and international law is strictly prohibited.

© 2015 Qualcomm Technologies International, Ltd. All rights reserved.

Qualcomm Technologies International, Ltd.
Churchill House
Cambridge Business Park
Cambridge, CB4 0WZ
United Kingdom



# BlueCore ®



TrueTest® Toolkit Introduction Prepared for customer about the prepared for customer and customer and customer and customer and customer and customer and **Application Note** 

Issue 11



# **Contacts**

General information

Information on this product

Customer support for this product

Prepared for customer. David Ba Koweki. grail.com. 39. Dec. 2011 More detail on compliance and standards

Help with this document

www.csr.com

sales@csr.com

www.csrsupport.com

product.compliance@csr.com



# **Document History**

Revision	Date	Change Reason
Draft A	05 JUL 04	Original publication of this document. (CSR reference: bcore-an-051Pa)
Draft B	08 AUG 06	Updated for latest DLLs and wrappers
Draft C	05 SEP 06	Updated example application code
4	31 OCT 06	Updated with details of VB2005 API file and unsigned parameter issues with VB6/7. Corrected details regarding installation. (CSR reference: CS-101531-ANP4)
5	06 FEB 07	Added LabView examples
6	24 SEP 07	Removed references to /unsafe compiler option for C# apps. Updated the application code and LabView examples
7	26 SEP 07	Update to application code example
8	11 FEB 11	Updates for BlueSuite 2.4
9	13 SEP 12	Updates for BlueSuite2.5 and to latest CSR style
10	26 SEP 14	Minor updates and updated to latest CSR style
11	28 APR 15	Minor updates for BlueSuite 2.6 and latest template
	redicor	Minor updates for BlueSuite 2.6 and latest template



## **Trademarks, Patents and Licences**

Unless otherwise stated, words and logos marked with ™ or ® are trademarks registered or owned by CSR plc and/or its affiliates.

Bluetooth® and the Bluetooth logos are trademarks owned by Bluetooth SIG, Inc. and licensed to CSR.

Other products, services and names used in this document may have been trademarked by their respective owners.

The publication of this information does not imply that any licence is granted under any patent or other rights owned by CSR plc or its affiliates.

CSR reserves the right to make technical changes to its products as part of its development programme.

While every care has been taken to ensure the accuracy of the contents of this document, CSR cannot accept responsibility for any errors.

#### Life Support Policy and Use in Safety-critical Compliance

CSR's products are not authorised for use in life-support or safety-critical applications. Use in such applications is done at the sole discretion of the customer. CSR will not warrant the use of its devices in such applications.

#### Performance and Conformance

Refer to www.csrsupport.com for compliance and conformance to standards information.



# **Contents**

	Con	tacts		2
1	True	Test Ov	/erview	6
	1.1	TestEr	ngine	6
	1.2	TestFla	ash	6
	1.3	TestE2	)	7
	1.4	Installa	ation Files	7
2	Insta	alling Tru	ueTest	8
3	Usin	g TrueT	'est	9
	3.1	Genera	al Points	9
		3.1.1	Building a C/C++ Application Using Borland	9
		3.1.2	Visual Basic and Unsigned Function Arguments	9
		3.1.3	Execution Path	9
	3.2	Using t	the TestEngine API	
		3.2.1	Building a C/C++ Application	10
		3.2.2	Building a Visual BasicApplication	10
		3.2.3	Building a Delphi Application	10
		3.2.4	Building a C# Application	10
		3.2.5	Example Application	
	3.3	Using 1	the TestFlash API	
		3.3.1	Building a C/C++ Application	11
		3.3.2	Building a Visual Basic Application	
		3.3.3	Building a Delphi Application	11
		3.3.4	Building a C# Application	11
		3.3.5	Example Application	12
	3.4	Using t	the TestE2 API	12
		3.4.1	Building a C/C++ Application	12
		3.4.2	Building a Visual Basic Application	13
		3.4.3	Building a Delphi Application	13
		3.4.4	Building a C# Application	13
		3.4.5	Example Application	
	3.5	Using	LabView	14
		3.5.1	Introduction	14
		3.5.2	Basic Function Calling	14
		3.5.3	Reading Values Using Pointers	16
		3.5.4	Passing a String to a LabView DLL Function	
		3.5.5	OpenTestEngine, OpenTestEngineSpi and CloseTestEngine	
4	Tern	ns and [	Definitions	20
Lie	st of	f Figi	ures	
Fia	ıra 2 1		TrueTest Directory Structure	Q

Figure 2.1	TrueTest Directory	Structure
1 19u1 0 Z. I	Tructost Directory	Otractare



#### TrueTest Overview 1

The HCI, radiotest, Persistent Store (PS), Flash and EEPROM software tools released with BlueSuite (BTCli, BlueTest3, PSTool, BlueFlash, E2CMD) are generally used during development and design validation. These programs are not intended for use during production testing, as they require multiple button presses or manual data entry that may lead to operator error in a busy production environment.

The TrueTest toolkit contains a set of library files that allow CSR's customers access to BlueCore test and configuration functionality using programmer APIs. The APIs are very simple and support most programming languages, including Microsoft Visual Basic (VB 6, 7 and 8 (2005) or later), C/C++, C#, Delphi and LabView.

This document is an introduction to the TrueTest libraries. Each library is released with its own compiled HTML (.chm) help file, which provides further user information, including the API reference.

### **TestEngine**

TestEngine allows a test application to be developed that can communicate with one or more BlueCore devices from the same PC.

The TestEngine library supports access to BlueCore using:

- UART, i.e. BCSP, H4, H4DS, and H5 protocols
- USB
- SPI, i.e. LPT or USB-SPI

TestEngine allows the programmer to control various test modes and to configure each device. TestEngine supports various command sets such as:

- HCI, Device Danager (DM)
- BlueCore Commands (BCCMDs)
- Host query commands (HQCMDs)

The SPI interface is limited in the command sets it supports and does not support HCI or DM. Support for HQCMD over SPI is present in firmware version 23 and later. It may also be the case that some BlueCore firmware versions do not support certain command sets. See the relevant firmware release note for confirmation of command set support.

TestEngine is comprised of the following files:

- TestEngine.dll: The dynamically linked library file
- TestEngine.lib: The library file required for linking with certain programming languages
- TestEngine.h: C header file containing function declarations
- TestEngine.chm: Help file containing function descriptions and example code
- TestEngineAPI.bas: VB6 file containing function declarations
- TestEngineAPI.vb: VB7 file containing function declarations
- TestEngineAPI\_05.vb: VB 2005 file containing function declarations
- TestEngineAPI.pas: Delphi file containing function declarations
- TestEngineAPI.cs: C# class wrapper file for TestEngine functions

#### 1.2 **TestFlash**

TestFlash allows a programming utility to be developed.

The TestFlash library supports flash programming over the SPI interface. The library can be used to program:

- Single devices
- Multiple devices using multiple connections
- Up to sixteen devices using the CSR designed gang programmer (DEV-PC-1140B)

TestFlash includes the following files:



- TestFlash.dll: The dynamically linked library file
- TestFlash.lib: The library file required for linking with certain programming languages
- TestFlash.h: C header file containing function declarations
- TestFlash.chm: Help file containing function descriptions and example code
- TestFlashAPI.bas: VB6 file containing function declarations
- TestFlashAPI.vb: VB7 file containing function declarations
- TestFlashAPI\_05.vb: VB 8 (2005) file containing function declarations
- TestFlashAPI.pas: Delphi file containing function declarations
- TestFlashAPI.cs: C# class wrapper file for TestFlash functions

#### 1.3 TestE2

TestE2 allows an EEPROM programming utility to be developed.

The TestE2 library supports full manipulation of an EEPROM connected to a BlueCore IC using the SPI interface.

#### It supports:

- EEPROM configuration
- Clearing and programming of single devices or up to sixteen devices attached to the CSR designed gang programmer (DEVPC-1140B)

TestE2 is the replacement for the E2Api library, which is no longer released

TestE2 includes the following files:

- TestE2.dll: The dynamically linked library file
- TestE2.lib: The library file required for linking with certain programming languages
- TestE2.h: C Header file containing function declarations
- TestE2.chm: Help file containing function descriptions and example code
- TestE2API.bas: VB6 file containing function declarations
- TestE2API.vb: VB7 file containing function declarations
- TestE2API\_05.vb: VB 2005 file containing function declarations
- TestE2API.pas: Delphi file containing function declarations
- TestE2API.cs: C# class wrapper file for TestE2 functions

#### 1.4 Installation Files

The TrueTest toolkit is released as part of BlueSuite, and is therefore installed by the BlueSuite installer. The required drivers for SPI and the host transports as well as support libraries used by the TrueTest libraries are installed as part of the BlueSuite installation.



# 2 Installing TrueTest

The TrueTest toolkit is installed as part of BlueSuite, shows the directory structure:




Figure 2.1: TrueTest Directory Structure

#### Note:

When building a LabView executable, the DLLs should be included in the data directory that resides in the same location as the executable.



# 3 Using TrueTest

#### 3.1 General Points

#### 3.1.1 Building a C/C++ Application Using Borland

The supplied import libraries for the DLLs are in COFF format. Borland users should use <code>implib.exe</code> to extract an OMF import library from the DLL.

#### 3.1.2 Visual Basic and Unsigned Function Arguments

Some of the functions in the TrueTest APIs take arguments of type uint16 or uint32 or return values of these types. These are unsigned 16 or 32-bit values. While Visual Basic 8 (2005 .NET) and later supports these types, Visual Basic versions 6 and 7 (.NET) do not have any equivalent unsigned data types, so it is necessary to work around the limitation in code.

This section describes a workaround for this issue, using the uint16 type as an example. The same principle can be applied for uint32 values, but with different values for the limits of 32-bit signed / unsigned types. The workaround is not required for VB2005 (.NET) and later as the new unsigned types (such as UShort and UInteger) are used in the VB2005 API file.

Arguments of type uint16 are represented in Visual Basic as the signed Short data type, which is 16-bits wide but represents the values -32768 to 32767. This presents a problem when trying to pass values greater than 32767 to functions that take uint16 (Short) arguments because the Visual Basic compiler does not accept these values as valid for that type. Therefore, unsigned values greater than 32767 must be represented by their equivalent negative value.

For example, to pass the unsigned value 32768 as a Short, the value -32768 must be passed and to pass the unsigned value 65535, the value -1 must be passed.

The equivalent Short value can be found as shown in this example which converts the required unsigned value represented as a 32-bit Integer to itsShort equivalent:

```
Function AsUShort(ByVal intVal As Integer) As Short
AsUShort = intVal Mod 32768
   If intVal > 32767 Then
        AsUShort = AsUShort Or &H8000S
   End If
End Function
```

Applying the function yields the following results:

```
AsUShort(1) ==> 1
AsUShort(32767) ==> 32767
AsUShort(32768) ==> -32768
AsUShort(65535) ==> -1
```

A similar function is required to convert signed Short values from functions that return a uint16 as a Short.

However, an alternative exists for passing constants into a function, which is to pass them as a hexadecimal literal suffixed with the Short character S e.g:

```
Const FOO As Short = &H8000S
```

Which Represents 32768 as a Short.

#### 3.1.3 Execution Path

Irrespective of the programming language used, the application must be executed in a folder containing all of the required DLLs.



### 3.2 Using the TestEngine API

#### 3.2.1 Building a C/C++ Application

To build a C or C++ application the TestEngine.h header file needs to be included in the source files. The application also needs to be linked to the TestEngine.lib import library. The file locations are:

- TestEngine.h: Include file TestEngine.h in%TrueTestDir%\include
- TestEngine.lib: Import library TestEngine.lib in%TrueTestDir%\lib

#### 3.2.2 Building a Visual BasicApplication

To build a Visual Basic application add the TestEngine function declarations module to the project. There are modules for three versions of Visual Basic, these are:

- VB6 function declarations TestEngineAPI.bas in %TrueTestDir%\include\VB6
- VB7 (.NET) function declarations TestEngineAPI.vb in %TrueTestDir%\include\VB7
- VB8 (2005 .NET) and later function declarations TestEngineAPI\_05.vb in %TrueTestDir%linclude\VB2005

#### 3.2.3 Building a Delphi Application

To build a Delphi application, add the TestEngineAPI.pas function declarations unit to the project. The unit file is in the following location:

Delphi function declarations TestEngineAPI.pas in %TrueTestDir%\include\Delphi

#### 3.2.4 Building a C# Application

To build a C# application, first add the TestEngineAPI.cs unit to the project. The unit file is in the following location:

C# class wrapper file TestEngineAPI.cs in %TrueTestDir%\include\C#

Add the declaration using  $\mathtt{TestEngineAPI}$ ; to the top of any code files that call  $\mathtt{TestEngine}$  functions. Call the static class member functions using the class name, e.g.  $\mathtt{TestEngine.openTestEngine}(...)$ ;

#### 3.2.5 Example Application

This section gives an example C++ program showing how to use the functions in the TestEngine API to write a value to the Persistent Store:

```
#include <iostream>
#include "testengine.h"

const uint16 PSKEY_USR0 = 650;
const uint16 MAX_KEY_SIZE = 20;

int main(int argc, char** argv)
{
    uint32 devHandle = openTestEngine(BCSP, "COM1", 115200, 5000, 0);

    if(devHandle != 0)
    {
        std::cout << "Device Handle = " << devHandle << std::endl;
        uint16 keySize;
        if(psSize(devHandle, PSKEY_USR0, PS_STORES_IFR, &keySize) == TE_OK)
        {
            std::cout << "Size of PSKEY_USR0 = " << keySize << std::endl;
        }
        else
        {
            std::cout << "psSize returned error" << std::endl;
            closeTestEngine(devHandle);
            return -1;
        }
}</pre>
```



```
if(keySize == 0)
        /* Doesn't exist, so need to create it */
        keySize = 1;
    uint16 data[MAX KEY SIZE];
    for(uint16 i = 0; i < keySize; ++i)</pre>
        data[i] = i;
    if(psWrite(devHandle, PSKEY_USR0, PS_STORES_I, keySize, data) != TE_OK)
        std::cout << "psWrite returned error" << std::endl;
        closeTestEngine(devHandle);
        return -1;
    closeTestEngine(devHandle);
}
else
    std::cout << "openTestEngine returned invalid handle" << std::endl;
    return -1;
}
return 0;
```

### 3.3 Using the TestFlash API

}

There are currently two flash programming APIs supported by TestFlash, the legacy API, and the newer, multiple connection API. The multiple connection API allows multiple device connections per process, e.g. to multiple BlueCore devices using multiple USB-SPI interfaces. The functions in one API should not be interleaved with those from the other API. See the TestFlash help file for more information.

#### 3.3.1 Building a C/C++ Application

To build a C or C++ application you need to include the TestFlash.h and/or TestPS.h header files in the source files. The application also must be linked against the import libraries. These files are in the following locations:

- Include files TestFlash.h and TestPS.h in %TrueTestDir%\include
- Import library TestFlash.lib in %TrueTestDir%\lib

#### 3.3.2 Building a Visual Basic Application

To build a Visual Basic application add the TestFlash function declarations module to the project. There are modules for three versions of Visual Basic. The files are in the following locations:

- VB6 function declarations TestFlashAPI.bas in %TrueTestDir%\include\VB6
- VB7 (.NET) function declarations TestFlashAPI.vb in %TrueTestDir%\include\VB7
- VB8 (2005 .NET) and later function declarations TestFlashAPI 05.vb in %TrueTestDir%\include\VB2005

#### 3.3.3 Building a Delphi Application

To build a Delphi application, add the TestFlashAPI.pas function declarations unit to the project. The unit file is in the following location:

Delphi function declarations TestFlashAPI.pas in %TrueTestDir%\include\Delphi

#### 3.3.4 Building a C# Application

To build a C# application, first add the TestFlashAPI.cs unit to the project. The unit file is in the following location:

C# class wrapper file TestFlashAPI.cs in %TrueTestDir%\include\C#



Add the declaration using <code>TestFlashAPI</code>; to the top of any code files that call <code>TestEngine</code> functions. Call the static class member functions using the class name, e.g. <code>TestFlash.fileInit(...)</code>;

#### 3.3.5 Example Application

This section gives a sample C++ program showing how to use the functions in the TestFlash legacy API to program Flash (non-blocking method for a single device):

```
#include <iostream>
#include <windows.h>
#include "testflash.h"
int main(int argc, char** argv)
    if(flInit(1, 26, 1, TFL_SPI_LPT) != TFL_OK)
        std::cout << "Failed to initialise flash" << std::endl;
        return -1;
    if(flReadProgramFiles("testBuild\\default") != TFL_OK)
        std::cout << "Failed to read flash program files" << std::endl;
        flClose();
        return -1;
    if(flProgramSpawn() != TFL_OK)
        std::cout << "Failed to spawn flash program thread" << std::endl;</pre>
        flClose();
        return -1;
    int32 progress = flGetProgress();
   while(progress < 100)</pre>
        std::cout << "Programming..." << progress << "%" << std::endl;
        Sleep(1000);
        progress = flGetProgress();
    }
    std::cout << "Completed" << std::endl;</pre>
    int32 error = flGetLastError();
    if(error != TFL_OK)
        std::cout << "Programming failed with error: " << error <<
        std::endl;
        flClose();
        return -1;
   std::cout << "Successfully programmed device" << std::endl;</pre>
   flClose();
    return 0;
```

# 3.4 Using the TestE2 API

#### 3.4.1 Building a C/C++ Application

To build a C or C++ application include the TestE2.h header file in the source files. The application also must be linked against the import libraries. These files are in the following locations:

- Include file TestE2.h in %TrueTestDir%\include
- Import library TestE2.lib in %TrueTestDir%\lib



#### 3.4.2 Building a Visual Basic Application

To build a Visual Basic application add the TestE2 function declarations module to the project. There are modules for three versions of Visual Basic. The files are in the following locations:

- VB6 function declarations TestE2PI.bas in %TrueTestDir%\include\VB6
- VB7 (.NET) function declarations TestFlashAPI.vb in %TrueTestDir%\include\VB7
- VB8 (2005 .NET) and later function declarations TestE2API\_05.vb in %TrueTestDir%linclude\VB2005

#### 3.4.3 Building a Delphi Application

To build a Delphi application, add the TestE2API.pas function declarations unit to the project. The unit file is in the following location:

Delphi function declarations TestE2API.pas in %TrueTestDir%\include\Delphi

#### 3.4.4 Building a C# Application

To build a C# application add the TestE2API.cs unit to the project. The unit file is in the following location:

C# class wrapper file TestE2API.cs in %TrueTestDir%\include\C#

Add the declaration using TestE2API; to the top of any code files that will call TestE2 functions. Call the static class member functions using the class name, e.g. TestE2.te20pen(...);

#### 3.4.5 Example Application

This section gives an example C++ program showing how to use the functions in the TestE2 API to program and verify the contents of an EEPROM in non-blocking mode. The device being accessed is attached to port LPT1:

```
#include "TestE2.h"
#include <iostream>
#include <windows.h>
using namespace std;
int main(int argc, char* argv[])
    if(te2Open(TE2_SPI_LPT, 1,0) != TE2_OK)
        cout << "Error opening connection: " << te2GetLastError() << endl;</pre>
        return -1;
    // Program the device from an image file, don't wait for completion
    if(te2Program("eeImage.xpv", 0) != TE2_OK)
        cout << "Error programming: " << te2GetLastError() << endl;</pre>
        te2Close();
        return -1;
    // Wait for programming completion
    cout << "Programming";</pre>
    while(te2IsBusy() != 0)
        cout << '.';
        Sleep(100);
    cout << endl;</pre>
    if(te2GetResult() != TE2_OK)
        cout << "Error programming: " << te2GetLastError() << endl;</pre>
        te2Close();
        return -1;
```



```
// Verify the contents
if(te2Verify("eeImage.xpv", 0) != TE2_OK)
    cout << "Verify failed: " << te2GetLastError() << endl;</pre>
    te2Close();
    return -1;
// Wait for verify completion
cout << "Verifying";</pre>
while(te2IsBusy() != 0)
    cout << '.';
    Sleep(100);
}
cout << endl;</pre>
if(te2GetResult() != TE2_OK)
    cout << "Error verifying: " << te2GetLastError() << endl;</pre>
    te2Close();
    return -1;
}
cout << "Device programming successful" << endl;</pre>
te2Close();
return 0;
```

## 3.5 Using LabView


#### 3.5.1 Introduction

This section describes calling the TestEngine DLL functions from the LabView Development Environment. The examples use LabView Professional Development System 8.2 but the same principles apply for versions 8.0, 7.1, 7.0 and 6.0. The same methods can be used when using TestFlash or TestE2 with LabView.


#### 3.5.2 Basic Function Calling

Use the LabView Call Library Function Node to call the TestEngine DLL contained in c:\Program Files\CSR\Bluesuite. A handle to a device is obtained by calling one of the openTestEngine... functions.






Right-click on the **Call Library Function Node** and configure the **Function** tab as shown. Select the function name from the drop-down list, making sure the calling convention is set to **stdcall(WINAPI)**.




On the Parameters tab, add parameters to match those defined in c:\Program Files\CSR\BlueSuite\include\TestEngine.h:

TESTENGINE\_API(int) radiotestCfgXtalFtrim(uint32 handle, uint16 ftrim);






Ensure that no callbacks are set for the function:




### 3.5.3 Reading Values Using Pointers

When reading values using pointers, use an array as the data structure e.g. for psReadXtalFtrim:






Use the initialise array function to allocate memory before calling the DLL function.




#### 3.5.4 Passing a String to a LabView DLL Function

To pass a string to a DLL function, use an array of unsigned chars:





Use the string to byte array function to convert a LabView string to a byte array before passing this to the TestEngine DLL.




#### 3.5.5 OpenTestEngine, OpenTestEngineSpi and CloseTestEngine

To obtain a handle to a device, call <code>openTestEngine</code>. Wire the output of <code>openTestEngine</code> to any function that you want to call. This handle should be passed through all functions that are called while testing.


Ensure that closeTestEngine is called after testing is completed.





To communicate with a device using the SPI interface, call <code>openTestEngineSpi</code> and wire the output to the function that you want to call. Some <code>TestEngineIneSpi</code>, further information is contained in the <code>TestEngine help</code> files.

Ensure that closeTestEngine is called when any operation(s) are complete.





# 4 Terms and Definitions

API	Application Programming Interface	
BCCMD	BlueCore Command	
BCSP	BlueCore Serial Protocol	
BlueCore <sup>®</sup>	Group term for CSR's range of Bluetooth wireless technology ICs	
BlueSuite <sup>®</sup>	Suite of development tools that contains BlueCore utilities	
BlueTest3	Software for executing BlueCore's Built-in Self-test functions	
Bluetooth®	Set of technologies providing audio and data transfer over short-range radio connections	
BTCli	Bluetooth Command Line Interface	
COFF	Common Object File Format	
CSR	Cambridge Silicon Radio	
DLL	Dynamically Linked Library	
DM	Device Manager	
e.g.	exempli gratia, for example	
EEPROM	Electrically Erasable Programmable Read Only Memory	
etc.	et cetera, and the rest, and so forth	
H4	UART-based HCl transport, described in section of H4 of v1.0b of Bluetooth Specification	
HCI	Host Controller Interface	
HQCMD	Host Query Command	
i.e.	id est, that is	
IC	Integrated Circuit	
OMF CONTRACTOR	Object Module Format	
Persistent Store (PS)	Storage of BlueCore's configuration values in non-volatile memory	
RFCOMM	Protocol layer providing serial port emulation over L2CAP; element of Bluetooth	
SPI	Serial Peripheral Interface	
TrueTest <sup>®</sup>	A set of libraries for developing production test applications for BlueCore-enabled devices	
UART	Universal Asynchronous Receiver Transmitter	
USB	Universal Serial Bus	

**CSR** 

Prepared for customer El David Ba kowski - drail.com - 30 Dec 2011