



BLINKY

FRONT PANEL DRILL TEMPLATE - PRINT AT ACTUAL SIZE

PC

+ + + + + + + + + + + + +

IR

+ | + + + + + + + | + + + + + + + +
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

RTOS

+ + + + + + + + + + + + +

TOS

+ + + + + + + +

DSP

+ + + + + + + +

BP

+ + + + + + + + + + + + +

NOS

+ + + + + + + +

RSP

+ + + + + + + +

D-ADDR

+ + + + + + + + + + + + +
12 11 10 9 8 7 6 5 4 3 2 1 0

OUT

+ + + + + + + +
7 6 5 4 3 2 1 0

PCSEL

+ + + +
SEQ JMP RET VEC

FLAGS

+ + + +
N Z C I

CLOCK

| | | | | | |
|------------|-----------|----------------|---------------|----------------|------------|
| +
POWER | +
OSC | +
RUN | +
RUN MODE | +
STEP MODE | +
RESET |
| +
POWER | +
STEP | +
STEP MODE | +
RUN MODE | +
RESET | |

INTERRUPTS

| | |
|---------------|---------------|
| +
IRQ PEND | +
NMI PEND |
| +
IRQ | +
NMI |

INPUT PORT

| | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| +
IN7 | +
IN6 | +
IN5 | +
IN4 | +
IN3 | +
IN2 | +
IN1 | +
IN0 |

BREAKPOINT

| | | | | | | | | | | | | | |
|------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| +
BP EN | +
BPC | +
BPB | +
BPA | +
BP9 | +
BP8 | +
BP7 | +
BP6 | +
BP5 | +
BP4 | +
BP3 | +
BP2 | +
BP1 | +
BP0 |
|------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

100 mm SCALE CHECK

