

CoolHome 200 Refrigerator Manual

Model CH-200 | Detailed training manual | Page 1 of 5

Document	CoolHome 200 Refrigerator Manual
Page topic	1. Safety and product overview
Status	Approved fictional business information

1. Safety and product overview

Product description. The CoolHome 200 is a fictional 200-litre household refrigerator with a fresh-food compartment, freezer compartment, adjustable shelves, vegetable drawer, and mechanical temperature control.

Intended use. The appliance stores normal household food. It is not designed for medical samples, laboratory materials, flammable chemicals, or outdoor use.

Electrical safety. Connect directly to an earthed outlet that matches the rating label. Do not use a damaged cable, multi-plug adapter, or light-duty extension lead.

Ventilation. Keep ventilation openings clear. Do not cover the back or place the refrigerator against a heat source. Poor airflow increases power use and may damage the compressor.

Children. Do not allow children to climb inside or hang on the door. Store the key away from children if the model has a lock. Remove doors before disposal.

Abnormal conditions. Unplug and contact support if there is smoke, exposed wiring, repeated electric shock, refrigerant smell, severe cabinet damage, or unusual compressor noise.

Do not damage refrigerant pipes. Keep flames and sparks away if a pipe is damaged, ventilate the room, unplug only if safe, and contact qualified service.

CoolHome 200 Refrigerator Manual

Model CH-200 | Detailed training manual | Page 2 of 5

Document	CoolHome 200 Refrigerator Manual
Page topic	2. Transport, installation, and first start
Status	Approved fictional business information

2. Transport, installation, and first start

Transport. Keep the refrigerator upright. If it was tilted, stand it upright for at least four hours before switching it on so compressor oil can settle.

Location. Choose a dry, level area away from direct sun, cookers, and water. Leave at least 10 cm behind, 5 cm at each side, and enough space above for airflow.

Levelling. Adjust the front feet so the cabinet stands firmly and the door closes naturally. An unlevel cabinet may vibrate or leave the door partly open.

Cleaning before use. Wipe the interior with warm water and mild soap, then dry it. Do not use petrol, bleach, abrasive powder, or sharp tools.

First start. Connect the refrigerator and select the middle temperature setting. Allow it to cool empty for at least four hours before adding food.

Temperature targets. Keep the fresh-food compartment between 3°C and 5°C and the freezer near -18°C. Use an appliance thermometer when accurate monitoring matters.

After a new installation, the sides may feel warm and the compressor may run for several hours. This can be normal while the cabinet reaches the selected temperature.

CoolHome 200 Refrigerator Manual

Model CH-200 | Detailed training manual | Page 3 of 5

Document	CoolHome 200 Refrigerator Manual
Page topic	3. Food storage and energy efficiency
Status	Approved fictional business information

3. Food storage and energy efficiency

Air circulation. Leave space around food and do not block internal vents. Poor circulation creates warm areas and makes the compressor run longer.

Food preparation. Cover liquids, wrap strong-smelling food, and cool cooked food before storage. Divide large amounts into smaller containers so they cool safely.

Door storage. Use door shelves for items that tolerate slight temperature changes. Store highly perishable food toward the back of the main compartment, not in the door.

Freezing. Use freezer-safe packaging, label dates, and avoid placing large amounts of warm food beside already frozen items. Do not refreeze food that fully thawed unless it has been safely cooked.

Energy saving. Keep door openings short, check that the seal is clean, leave ventilation space, and avoid an unnecessarily cold setting. Dust around the condenser area carefully when unplugged.

Overloading. Do not pack shelves beyond their safe capacity. Heavy containers should sit on lower shelves. A blocked or overloaded compartment cools unevenly.

Recommended arrangement: ready-to-eat food on upper shelves, covered leftovers in the middle, raw meat sealed on the lowest shelf, and vegetables in the drawer.

CoolHome 200 Refrigerator Manual

Model CH-200 | Detailed training manual | Page 4 of 5

Document	CoolHome 200 Refrigerator Manual
Page topic	4. Cleaning, defrosting, and power interruptions
Status	Approved fictional business information

4. Cleaning, defrosting, and power interruptions

Routine cleaning. Unplug the appliance, remove food, and wash removable shelves with warm water and mild soap. Wipe the interior and dry before reconnecting.

Door seal. Clean the seal with a soft cloth. Check that paper held in the closed door has gentle resistance. A loose or damaged seal can cause condensation and weak cooling.

Manual defrost. If thick ice forms, move food to a cooler, unplug, open the door, and allow ice to melt naturally. Do not use knives, heaters, or boiling water.

Drainage. Keep the interior drain opening clear using a soft cleaning tool. Water inside the cabinet may indicate a blocked drain or food touching the back wall.

Power interruption. Keep doors closed. A full freezer normally stays cold longer than a partly filled one. Discard unsafe perishable food when temperature history is uncertain.

Long absence. For a short trip, leave the refrigerator running. For long shutdown, remove food, unplug, clean, dry, and leave doors partly open to prevent mould.

After power returns, wait five minutes before reconnecting if the plug was removed. Rapid restarting can place unnecessary pressure on the compressor.

CoolHome 200 Refrigerator Manual

Model CH-200 | Detailed training manual | Page 5 of 5

Document	CoolHome 200 Refrigerator Manual
Page topic	5. Troubleshooting, service, and warranty
Status	Approved fictional business information

5. Troubleshooting, service, and warranty

Not operating. Check the outlet, plug, household breaker, and temperature control. If lights work but the compressor never runs after the cabinet warms, contact support.

Weak cooling. Confirm a suitable setting, close the door fully, clean the seal, reduce overloading, clear vents, and leave space around the cabinet. Hot weather can increase running time.

Water or condensation. Check the door seal, reduce frequent opening, cover liquids, clear the drain, and ensure warm food has cooled before storage.

Noise. Gentle humming, clicking, and refrigerant flow can be normal. Rattling may come from an unlevel cabinet or containers touching. Loud grinding or repeated clicking needs service.

Specifications. Nominal storage capacity is 200 litres. Target fresh-food temperature is 3°C to 5°C and freezer temperature is approximately -18°C. Exact electrical ratings appear on the label.

Warranty. The CoolHome 200 has a 24-month manufacturer warranty for manufacturing defects. It excludes transport damage after customer collection, power-surge damage, pests, misuse, and unauthorized repair.

For service, provide model CH-200, serial number, purchase date, proof of purchase, temperature observations, error symptoms, and photographs when useful.