

**A350 MEMORY ITEMS TRAINING AID - FOR
TRAINING USE ONLY**


Revision: 0.0.0
Date: 30-Aug-2024

- 1 A350 MEMORY ITEMS TRAINING AID
- 1.3 EMERGENCY EVACUATION FLOW/PHILOSOPHY

1.3 EMERGENCY EVACUATION FLOW/PHILOSOPHY

Evacuation flow items listed below are not included within the Evacuation checklist. They are meant to refresh the logical pattern of procedures that must occur for a successful evacuation. In the unlikely event that the checklist cannot be read due to smoke/fire, darkness, injury or incapacitation, this simple flow or philosophy should be memorized and lead the pilot to completion of all critical tasks contributing to the safest possible evacuation. The checklist follows the flow pattern of:

STOP
CONFIGURE
SHUTDOWN
EVACUATE



**A350 MEMORY ITEMS TRAINING AID - FOR
TRAINING USE ONLY**

Revision: 1.0.0
Date: 12-Sep-2024

- 1 A350 MEMORY ITEMS TRAINING AID
- 1.2 MEMORY ITEMS

1.2.3 Unreliable Air Speed Indication


- If the safe conduct of the flight is impacted:

A/P.....OFF
A/THR.....OFF
FD.....OFF
PITCH/THRUST:
Below THR RED ALT.....12.5°/TOGA
Above THR RED ALT and Below FL 100.....10°/CLB
Above THR RED ALT and Above FL 100.....5°/CLB
FLAPS (if CONF 0(1)(2)(3)).....MAINTAIN CURRENT CONF
FLAPS (if CONF FULL).....SELECT CONF 3 AND MAINTAIN
SPEED BRAKES.....CHECK RETRACTED
L/G.....UP

1.2.4 Stall Warning at Liftoff

- If stall warnings trigger at liftoff, apply the following immediate actions:

THRUST.....TOGA
At the same time:
PITCH ATTITUDE.....12.5°
BANK.....WINGS LEVEL



1	A350 MEMORY ITEMS TRAINING AID
1.2	MEMORY ITEMS

1.2 MEMORY ITEMS

1.2.1 Loss of Braking

- If no braking:

REV.....MAX
BRAKE PEDALS.....RELEASE
A-SKID OFF.....ORDER
A-SKID.....OFF
BRAKE PEDALS.....PRESS

- If still no braking:

PARK BRK.....USE

1.2.2 Emer Descent

- If the cabin pressure altitude is above 10,000 ft:

CREW OXY MASKS.....USE
SIGNS.....ON
EMER DESCENT.....INITIATE

Initiate the emergency descent with one of the following techniques:

- Use of the AUTO EMER DESCENT function
- Use of selected guidance via the AFS CP.

- If A/THR is not active:

ALL THR LEVERS.....IDLE
SPEED BRAKES LEVER.....FULL

 DELTA	A350 MEMORY ITEMS TRAINING AID - FOR TRAINING USE ONLY	
	1 A350 MEMORY ITEMS TRAINING AID 1.1 FCOM LIMITATIONS	Revision: 0.0.0 Date: 30-Aug-2024

1 A350 MEMORY ITEMS TRAINING AID

1.1 FCOM LIMITATIONS

1.1.1 General

This training document is a cumulative list of Recall Limitations from the FCOM and Memory Items from the QRH. It supports Delta Flight Training and is intended for training use only. The information contained herein is correct as of the publication date; however, it may not reflect future changes in source material. Refer to the appropriate Delta Flight Operations publication for current information.

1.1.2 Airplane General

1.1.2.1 Operational and Environmental Limitations

General Aircraft Limitations	
# Maximum Operating Altitude	43,100 feet pressure altitude
# Maximum Takeoff and Landing Tailwind Component	15 knots, or as permitted by the Company Pages
# Crosswind limit for takeoff	35 knots (including gusts)
# Crosswind limit for landing	40 knots (including gusts)

1.1.3 Autoflight

1.1.3.1 Autopilot Minimum Altitudes

- # On takeoff, the autopilot must not be engaged until at least 5 seconds after lift-off.
- # After a manual go around, the autopilot must not be engaged below a minimum altitude of 100 feet AGL.

1.1.3.2 Automatic Landing

For autoland operations the following wind limits apply:

# Headwind	40 knots
# Tailwind	15 knots
# Crosswind	30 knots

1.1.4 Flight Controls

- # Do not extend flaps above 20,000 feet.