

UA OUT URT IN GND

D6 OUT D7 OUT GND

TRACE ON

PICO RESET

6800 RESET

TRAINER UART

GND D2IN 60HZ SW IRQ NMI

+5V GND 3.3V GND A3 A2 A1