

HONDA Motorcycle Fault Codes DTC list

Code (MIL)	Cause (a, b, c, ...)	Symptoms
Steady on	There is a jumper in the service connector; not faulty control unit (ECM); short circuit in the service connector	Engine is operating normally
No light	a) ECM power failure b) Tilt sensor defective c) Open in the tilt sensor circuit d) Malfunctioning engine stop relay e) Open in the engine stop relay circuit f) Engine breaker not working properly g) Open in engine stop switch circuit h) The ignition switch is not working i) Not good ECM j) Blown fuse PGM-FI (20A) k) Open circuit in engine stop circuit l) Starter / ignition fuse blown (10A)	Engine fails to start
No light	An open in the MIL circuit of the indicator	Not OK ECM Engine running fine
1	a) MAP sensor contact is off or not b) Open in MAP sensor circuit c) Malfunctioning MAP sensor	Engine is operating normally
2	Vacuum hose MAP sensor is removed or disconnected	Malfunctioning MAP sensor Engine is operating normally
7	a) Whether the contact of the FCT sensor moves away b) Open or short in ECT sensor circuit c) Faulty ECT sensor	Heavy engine start at low temperature
8	a) TP contact of the sensor moves away or not b) Open or short in TP sensor circuit c) Faulty TP sensor	Poor engine feedback on throttle opening
9	a) Whether the contact of the IAT sensor moves away or not b) Open or short in IAT sensor circuit c) AT sensor defective	Engine running normally
11	a) The contact of the speedometer sensor b) An open or short in the speedometer sensor circuit c) Speedometer sensor defective	Engine running normally
12	a) The contact of the injector No. 1 connector is removed or not b) Open or short in injector No. 1 connector circuit c) Injector No 1 defective	Engine does not start
13	a) The contact of the injector No. 2 connector is removed or not b) Open or short in injector No. 2 connector circuit c) Injector No. 2 is not working	The engine does not start
14	a) The contact of the injector No. 3 connector is removed or not b) Open or short in injector No. 3 connector circuit c) Injector No. 3 is not working	The engine does not start
15	a) The contact of the injector No. 4 connector is removed or not b) Open or short in the injector No. 4 connector circuit c) Injector No. 4 is not working	The engine does not start
18	a) Whether or not the contact of the pulse generator sensor connector moves away b) Open or short in the pulse generator sensor connector circuit c) Pulse generator sensor defective	Engine does not start
19	a) Whether or not the contact of the pulse ignition sensor departs b) Open or short in the pulse ignition sensor circuit c) Pulse ignition sensor defective	Engine does not start
21	O2 sensor defective (California only)	Engine is operating normally
23	Faulty O2 heating sensor (California only)	Engine is operating normally
33	Damaged E2-PROM in ECM Engine running normally	Self-diagnosis not saved