

KTM Motorcycle Fault Codes DTC

KTM MOTORCYCLE ERROR CODES DTC

DTC (Code) - Blink code - Signal / Component - Description of error Engine

P0201 33 Injection valve, rear cylinder Malfunction Stalls
P0202 34 Injection valve, front cylinder Malfunction Stalls
P0351 37 Ignition coil, rear cylinder Malfunction Stalls
P0352 38 Ignition coil, front cylinder Malfunction Stalls
P0335 02 Pick up Malfunction Stalls
P0032 45 Lambda probe heater Short circuit to positive Continues to run
P0031 45 Lambda probe heater Kurzschluß nach Masse Continues to run
P0130 17 Lambda probe, rear cylinder Malfunction Continues to run
P0052 46 Lambda probe heater, front cylinder Short circuit to positive Continues to run
P0051 46 Lambda probe heater, front cylinder Short circuit to ground Continues to run
P0150 18 Lambda probe heater, front cylinder Malfunction Continues to run
P0122 06 Throttle position sensor Output signal too low (interruption) Continues to run
P0123 06 Throttle position sensor Output signal too high (short circuit) Continues to run
P0107 09 Manifold air pressure sensor, rear cylinder Output signal too low (interruption) Continues to run
P0108 09 Manifold air pressure sensor, rear cylinder Output signal too high (short circuit) Continues to run
P1106 68 Manifold air pressure sensor, rear cylinder Hose pulled off/defective, no vacuum Continues to run
P1687 11 Manifold air pressure sensor, front cylinder Output signal too low (interruption) Continues to run
1688 11 Manifold air pressure sensor, front cylinder Output signal too high (short circuit) Continues to run
P1105 69 Manifold air pressure sensor, front cylinder Hose pulled off/defective, no vacuum Continues to run
P1107 14 Ambient air pressure sensor Output signal too low (interruption) Continues to run
P1108 14 Ambient air pressure sensor Output signal too high (short circuit) Continues to run
P0112 13 Air temperature sensor Output signal too low (interruption) Continues to run
P0113 13 Air temperature sensor Output signal too high (short circuit) Continues to run
P0117 12 Coolant temperature sensor Output signal too low (interruption) Continues to run
P0118 12 Coolant temperature sensor Output signal too high (short circuit) Continues to run
P1232 41 Fuel pump relay Short circuit to positive Stalls
P1231 41 Fuel pump relay Short circuit to ground Stalls
P0413 54 Secondary air valve Short circuit to positive Continues to run
P0414 54 Secondary air valve Short circuit to ground or interruption Continues to run
P0222 07 Sensor for 2nd throttle valve Output signal too low (interruption) Continues to run
P0223 07 Sensor for 2nd throttle valve Output signal too high (short circuit) Continues to run
P0638 72 Stepper motor for 2nd throttle valve Malfunction Continues to run
P0505 49 Idle speed control motor Malfunction Continues to run
P1631 15 Roll angle sensor Output signal too low (interruption) Continues to run
P1632 15 Roll angle sensor Output signal too high (short circuit) Continues to run
P0560 24 Control unit voltage supply Malfunction Continues to run
P1590 25 Side stand switch Output signal too low (short circuit to ground) Continues to run
P0603 65 EEPROM error Malfunction Continues to run