



WORK TIME

Time to Complete System

User Manual -- v1.2

Powered by **SRSSupport** | Hosted by **SRSCloud**

VERSION 1.2

ANDROID TABLET

ALL ROLES

CYBER ESSENTIALS 2FA





What is Work Time?

Work Time is a shopfloor timing system built for Philtronics Ltd. Operators press START when beginning an assembly job and STOP when finished. The system records the duration, workstation, and work order. All elapsed times and final durations reflect net working time -- paused time is never counted.

■ No technical knowledge needed.

If you can use a smartphone you can use Work Time.

User Roles

Every account has a role controlling what it can see and do.

OPERATOR Start/stop own timers Pause own timer View own history Cancel within 60s	SUPERVISOR All Operator actions Home dashboard Wall Board (both) Pause any timer Message operators View all history Adjust timers
MANAGER All Supervisor actions Dashboard Target Times CSV export Requires 2FA	ADMINISTRATOR All Manager actions User management Reset passwords and 2FA Delete timers Requires 2FA

■■ Manager and Administrator accounts require 2FA.

This satisfies Cyber Essentials compliance. Operators and Supervisors use standard password login.

Signing In

Open Chrome on your tablet and go to the Work Time web address your supervisor gave you.

1

Enter your username

Not case-sensitive.

2

Enter your password

Characters appear as dots.

3

Tap Sign In

Operators go to the Timer screen. Supervisors and above go to the Home dashboard. Managers and Administrators also complete a 2FA step if configured.

■■ 10 failed attempts locks the device for 15 minutes.

Two-Factor Authentication (2FA)

Setting up 2FA for the first time

A setup screen appears automatically after your first login as a Manager or Administrator.



- 1 Download an authenticator app**
Google Authenticator or Microsoft Authenticator -- free from the App Store or Google Play.
- 2 Scan the QR code shown on screen**
Open the authenticator app, tap +, and scan.
- 3 Enter the 6-digit code and tap Enable 2FA**
Once confirmed, 2FA is active on your account.

Logging in with 2FA

After entering your username and password, a Two-Factor Verification screen appears. Open your authenticator app, find the Work Time entry, and type the 6-digit code. Tap Verify.

■■ Lost your phone?

Contact your administrator -- they can reset your 2FA so you can set it up on a new device.

Starting a Job Timer

Operators land directly on the Timer screen after login. Fill in the job details and tap the green START button.

- 1 Item Number (required)**
Type or scan the part number. Letters, numbers, hyphens and underscores only, max 40 characters.
- 2 Workstation (optional)**
Type or scan your workstation identifier e.g. WS-01.
- 3 W/O Number (optional)**
Type or scan the Work Order number.
- 4 Time Check (optional)**
Tick for a formally measured timing.
- 5 Tap the green START button**
The timer starts immediately.

■■ One timer at a time.

Stop your current job before starting a new one.

Form Fields Explained

Field	Required?	What to enter
Item Number	Required	The part or assembly number. Can be scanned. Letters, numbers, hyphens and underscores only, max 40 characters.
Workstation	Optional	Your workstation or bench e.g. WS-01. Can be scanned. Appears on the Wall Board, history, and exports.
W/O Number	Optional	The Work Order number e.g. WO-10042. Can be scanned. Appears in history and CSV exports.



Time Check	Optional	Marks this as a formally measured timing. Shows as a blue Time Check badge in all history views.
-------------------	----------	--

Scanning a Barcode or QR Code

Every field with a Scan button can be filled using the tablet camera.

- 1 Tap the Scan button next to the field you want to fill**
- 2 Allow camera access (first time only)**
Tap Allow when Chrome asks.
- 3 Point the camera at the barcode or QR code**
The system reads it automatically. Good lighting helps.
- 4 The field fills automatically**
Check the value then continue.

■ Torch button.

In low light a Torch button appears at the bottom of the camera screen.

Stopping a Job Timer

Once started the screen shows a large running clock. Tap STOP as soon as you finish. The duration recorded is net working time only -- any paused time is automatically excluded.

■■■ Timer restores automatically.

If you close the browser or switch devices, your active timer restores when you log back in.

Target Time on the Timer Screen

If a manager has set a target time for the item you are working on, a progress bar appears beneath the running clock.

Green bar	Under 80% of target time elapsed -- on track
Amber bar	Between 80-100% of target -- approaching
Red bar	Target exceeded

Pausing and Resuming Your Own Timer

Operators can pause their own running timer at any time using the Pause button next to the STOP button.

When paused, the clock turns blue and freezes, a blue banner appears, and the header changes to PAUSED. Tap Resume to continue. The STOP button remains active -- you can stop the job even while



paused.

All paused time is excluded from the final duration when you stop the job.

■ ■ **Auto-pause notification.**

If your timer is automatically paused outside working hours, a notification appears on your screen and the pause button updates automatically.

Cancelling a Timer

Within 60 seconds: Tap Cancel next to STOP. Confirm to cancel or tap Keep Running to go back.

After 60 seconds: Only a Supervisor or above can cancel. They must enter a reason, permanently recorded.

■ **All cancellations are permanently recorded.**

Who cancelled, when, and the reason are stored and cannot be deleted.

Viewing Your History

Tap the menu then History to see your completed jobs. The default view shows the last 7 days. Each entry shows the item number, workstation, W/O number, start and end times, net duration, and any Time Check or target time badges.

Supervisor: Home Dashboard

Supervisors, Managers, and Administrators land on the Home dashboard after login. It gives an at-a-glance view of the entire shopfloor.

Active Jobs	All running timers sorted with overdue first. Paused jobs show a pause symbol and blue text. Elapsed times
Today at a Glance	Quick stat tiles: Active Now, Completed Today, This Week, Item Types.
Quick Actions	Large buttons linking to Wall Board, Compact Board, Dashboard, Target Times, History, and User Manager
Performance (Manager+)	Jobs by item with average time, target, and delta column.
User Status (Admin)	Active accounts, disabled accounts, and managers/admins without 2FA.

Wall Board

Tap the menu then Wall Board for the full interactive wallboard. Each tile shows item number, operator, elapsed time (live), workstation, W/O number, target progress bar, and action buttons.

Green border	Running normally, under 80% of target (or under 2 hours if no target)
---------------------	---



Amber border	Between 80-100% of target (or 2-4 hours if no target)
Red border	Target exceeded (or over 4 hours if no target)
Blue pulsing border	Timer is paused

Each tile also has a Pause/Resume button and a Message button at the bottom. The board refreshes every 5 minutes. Tap Refresh for an instant update.

Wall Board Compact

Tap the menu then Wall Board Compact for the TV display mode. Designed for a large shopfloor monitor -- shows as many tiles as possible with operator name, item number, and elapsed time. The same colour logic applies. Paused tiles pulse blue. No action buttons -- this view is for display only.

Presence Indicator

Every operator tile on both wallboards shows a small coloured dot next to the operator name.

Green dot	The operator has an active browser session and will receive messages instantly
Red dot	The operator has closed their browser or logged out -- messages will not be delivered

The dot updates whenever the wallboard refreshes.

Pausing Timers from the Wall Board

Supervisors, Managers, and Administrators can pause or resume any operator timer directly from the Wall Board.

- 1 Find the operator tile on the Wall Board**
- 2 Tap Pause to pause, or Resume to resume**
The wallboard refreshes immediately to reflect the new state.

■ ■ Pause buttons are only on the main Wall Board.

The Compact Wall Board is a display-only view and does not have pause buttons.

Messaging Operators

Supervisors and above can send a real-time message to any operator who is currently logged in.

- 1 Check the presence dot is green**
A red dot means the operator is not connected -- messages will not be delivered.
- 2 Tap the Message button on the wallboard tile or the Home dashboard**



3

Type your message and tap Send

Up to 500 characters. The message appears instantly on the operator screen with an audio ping. It stays until dismissed or after 60 seconds.

Supervisor: Viewing All History

The History screen has additional filters for Supervisors -- search by Operator ID, Item Number, and Status. Leave fields blank to see all records.

■ Finding stuck timers.

In the Status dropdown select Active (stuck timers) and tap Search. This removes the date filter so any stuck timer appears regardless of age.

Manager: Dashboard

Tap the menu then Dashboard for production statistics across all operators. Use the date range and other filters then tap Search.

Column	What it shows
Avg Actual	The average net working time for completed jobs in the selected period. Excludes paused time.
Min / Max	Fastest and slowest recorded net times.
Target	The set target time for this item. Blank if no target set.
Avg Delta	Difference between average actual and target. Green if under, red if over.

Manager: Target Times

Tap the menu then Target Times to manage completion targets per item number. Targets appear on the Wall Board tiles, operator timer screen, and history entries.

1

Tap + Add Target Time

2

Enter or scan the Item Number

3

Set the target hours and minutes

4

Tap Add Target Time

Saved immediately and visible on all active tiles for that item.

To edit an existing target tap Edit next to the item. To remove a target tap the delete button.

Manager: CSV Export



On the Dashboard, set your filters and tap Export CSV. The file downloads to your device and opens in Excel or Google Sheets. The export includes Item Number, Operator, Workstation, W/O Number, Start and End times, net Duration, Time Check flag, and Status.

Administrator: Managing Users

Adding a user: Tap Admin, then + New User. Fill in Username, Full Name, Password (8+ characters) and Role. Tap Create User.

Resetting a password: Find the user in the list and tap Reset PW. Enter a new password and tap Reset Password.

Disabling an account: Tap Edit next to the user, untick Account Active, tap Save Changes. History records are kept.

Resetting 2FA: Find the user in the list and tap Reset 2FA. Confirm. They will be prompted to set up 2FA again on next login.

■ **Only reset 2FA when you are certain of the user identity.**
Resetting 2FA temporarily reduces account security until the user completes setup.

Deleting a timer record: Go to History, find the record, and tap the delete button. Deletion is permanent and cannot be undone.

■ **Cancel All Stuck Timers.**
In the Admin page there is an emergency tool to cancel all currently active timers at once.

Working Hours Auto-Pause

Work Time automatically pauses all active timers outside working hours and resumes them when the working day begins.

Condition	Behaviour
16:30 Mon-Fri	All active timers auto-paused with reason "Outside working hours"
07:45 next working day	All schedule-paused timers auto-resumed
Saturday and Sunday	All active timers remain paused all weekend
Manually paused timers	NOT auto-resumed -- must be resumed manually by operator or supervisor

All elapsed times always reflect net working time only. A job started on Friday at 15:00 and stopped Monday at 09:00 will record approximately 1.5 hours of actual work, not 66 hours of clock time.



■■ **Operator notification.**

When a timer is auto-paused or auto-resumed, a notification appears on the operator Timer screen automatically.

Troubleshooting

I cannot sign in

Check username and password. Passwords are case-sensitive. After 10 failed attempts wait 15 minutes.

I am not being asked for my 2FA code

2FA is required for Manager and Administrator accounts only. If you have not yet set it up you will see a setup prompt after login.

The Scan button is not working

Make sure you are using Google Chrome version 83 or later. If camera permission was denied, tap the padlock icon in the address bar, change Camera to Allow, then refresh.

My active timer is not showing after a refresh or on a different device

Tap the menu then Timer. The system restores your active timer automatically. If you see an error but no STOP button, sign out and back in.

My timer was auto-paused unexpectedly

Timers are automatically paused outside working hours (07:45-16:30 Mon-Fri). A supervisor may also have manually paused it from the Wall Board. Contact your supervisor.

I sent a message but the operator did not receive it

Check the presence dot on the operator wallboard tile. A red dot means they are not currently logged in. Ask them to log in and try again.

The page is not loading

Check the tablet is connected to Wi-Fi. Pull down to refresh. Wait 30 seconds and try again.



WORK TIME

Time to Complete System -- User Manual v1.2

Powered by **SRSSupport** | Hosted by **SRSCloud**



Philtronics Ltd