

AquaClean Pro 500 Washing Machine

User Manual

Product Overview

The AquaClean Pro 500 is a high-efficiency washing machine designed for modern households. It features a large 8kg load capacity, 15 wash programs, and an A++ energy rating to provide superior performance while minimizing energy consumption.

Installation Instructions

Tools Required:

- Adjustable wrench
- Screwdriver
- Spirit level

Step-by-Step Installation:

1. **Unpack the Washing Machine:** Carefully remove packaging and check for any damages. Ensure all accessories are included.
2. **Position the Machine:** Place the machine on a stable, level surface using a spirit level to avoid vibrations.
3. **Connect Water Supply:** Attach the inlet hoses to the corresponding water supply taps. Ensure the connections are secure.
4. **Drain Hose Setup:** Secure the drain hose to the designated drainage pipe. Adjust the height to prevent backflow.
5. **Electrical Connection:** Plug the machine into a grounded 110V outlet. Avoid using extension cords.
6. **First Run:** Perform an initial wash with an empty drum to check for leaks and ensure proper installation.

User Guide

Operating Instructions:

1. **Loading the Washer:** Open the drum and load clothes. Avoid overloading to maintain efficiency.
2. **Selecting a Wash Program:** Turn the program dial to select desired wash cycle (e.g., Cotton, Delicate, Quick Wash).
3. **Adjusting Settings:** Use buttons to modify temperature, speed, and add features like 'Extra Rinse' or 'Delay Start'.
4. **Starting the Cycle:** Press 'Start' to begin washing. The display will show remaining time.
5. **Pausing:** Press 'Pause' to add items mid-cycle, if necessary.

Fabric Care Tips

- **Cotton:** Use higher temperature settings for whites and towels.
- **Delicates:** Choose low spin and low temperature settings.
- **Wool:** Utilize the 'Wool' program to prevent shrinking.

Maintenance and Care

- **Monthly Maintenance:** Clean the detergent drawer and rubber door seal using mild detergent to prevent mold build-up.
- **Filter Cleaning:** Check and clean the filter every 3 months to avoid blockages.
- **Exterior Cleaning:** Wipe down the machine surface with a damp cloth.

Troubleshooting

- **Machine Won't Start:** Check power connection; ensure the door is closed securely.
- **Excessive Noise:** Ensure machine is level; check for foreign objects inside the drum.
- **Stops Mid-Cycle:** Check water supply; make sure the machine isn't overloaded.
- **Water Leaks:** Verify hose connections and check door gasket for damages.

Warranty and Support

The AquaClean Pro 500 includes a 2-year warranty covering parts and labor for mechanical and technical defects. Additional coverage options are available through our extended warranty plans.

Claiming Warranty

For warranty claims, contact our support center with your purchase receipt and model number.

Customer Support

For assistance, call our toll-free number or visit our website for live chat support.

FAQs

Q: How do I know if the machine is energy efficient? A: The washing machine has an A++ energy efficiency rating, using less water and power per cycle.

Q: Can I wash my woolen sweaters? A: Yes, use the 'Wool' program with appropriate temperature settings.

For more help, consult the contact options provided in this manual.