

Product Overview

The **BlendMaster Elite 4000** combines power, versatility, and style to deliver a superior blending experience. Powered by a 1200-watt motor, it is capable of tackling a wide range of blending tasks from smoothies to soups and beyond.

Key Features

- **Three-Speed Settings:** Low, Medium, High for tailored blending.
- **Pulse Function:** Perfect for quick blending, chopping, and controlled tasks.
- **Durable Construction:** With a shatterproof 2-liter Tritan plastic jar.
- **Stainless Steel Blades:** Six angled blades designed to crush ice and puree fruits with ease.
- **Quiet Operation:** Engineered with noise reduction technology.
- **Smart LED Display:** Offers clear settings indication and timer functionality.

Specifications

- **Motor:** 1200 Watts
- **Dimensions:** 16 x 8 x 8 inches
- **Weight:** 8 pounds
- **Material:** BPA-free Tritan plastic jar, stainless steel blades
- **Warranty:** 2-year limited warranty

Setup Instructions

1. **Unboxing:** Carefully remove the blender and all components from packaging.
2. **Assembly:** Insert the blade assembly into the jar base, twist to secure.
3. **Placement:** Position the jar on the motor base, ensuring it clicks into place.

4. **Initial Cleaning:** Wipe down the motor base with a damp cloth, wash the jar, lid, and blade assembly with warm soapy water.

Operating Instructions

- **Basic Use:**

- Place ingredients into the jar.
- Secure the lid, ensuring the tamper opening is sealed if not in use.
- Select desired speed or press 'Pulse'.
- Use the tamper for thick mixes, inserting through the lid.
- Upon completion, switch off and unplug.

- **Making a Smoothie:**

- Add liquid (water, milk, juice) first.
- Add fruits, yogurt, and other ingredients.
- Blend on 'Medium' for 30-45 seconds.

Maintenance and Cleaning

- **After Each Use:** Rinse the jar with warm water.
- **Deep Clean Per Week:** Fill the jar halfway with water and a drop of dish soap, run on 'Low' for 30 seconds.
- **Blade Care:** Handle blades with caution; use provided brush for cleaning.

Troubleshooting

- **Blender Won't Start:**

- Ensure plugged in and base securely clicked in.
- Check for tripped circuit.

- **Unusual Noise:**

- Check for improperly secured components.
- Contact support if persistent.

- **Uneven Blending:**

- Adjust the ingredient ratio, ensuring enough liquid present.

Warranty and Support

For any issues not covered above or assistance with warranty claims:

- Contact us at support@blendmaster.com or call 1-800-555-0199.

Our goal is to ensure you get the most out of your BlendMaster Elite 4000 each time it's used!