

Introduction

Welcome to the BrownBox ZX-2021, a smartphone designed to meet all your technological needs with elegance and simplicity. The ZX-2021 offers leading-edge features such as a powerful octa-core processor, ultra-high-resolution 108MP camera, and a vibrant 6.7-inch display.

Specifications

- **Processor:** Octa-core 2.84 GHz
- **RAM:** 8GB
- **Storage:** 128GB (expandable up to 512GB)
- **Display:** 6.7-inch Super AMOLED (2400x1080)
- **Camera:** 108MP rear, 32MP front
- **Battery:** 5000mAh
- **Operating System:** Android 12
- **Connectivity:** 5G, Wi-Fi 6, Bluetooth 5.1

Setup & Installation

1. **Unboxing:** Carefully unpack your BrownBox ZX-2021 and ensure all components such as charger, earphones, and manuals are included.
2. **Insert SIM Card:** Use the ejector tool to open the SIM tray and place your nano-SIM card inside.
3. **Power Up:** Hold the power button until the BrownBox logo appears on the screen.
4. **Follow On-screen Setup:** Complete the setup wizard, entering Wi-Fi information and your Google account details.
5. **Software Update:** Navigate to 'Settings' > 'Software Update' to ensure your device runs the latest Android version.

Using Your BrownBox ZX-2021

- **Calls & Texts:** Open the Phone app to dial numbers or access your contacts. Use the Messages app for SMS.
- **Internet Browsing:** Open Chrome, and enter a URL or search term to explore the web.
- **Email Setup:** Use the Email app to configure your email accounts.
- **Camera Use:** Launch the Camera app. Explore features like Night Mode, Portrait Mode, and 4K video.

Maintenance & Care

- **Cleaning:** Use a microfiber cloth to gently wipe the screen. Avoid using water or cleaning agents.
- **Battery Care:** Optimize battery life by reducing screen brightness and disabling background apps.

Troubleshooting Guide

- **Wi-Fi Connection Issues:** Verify router settings, restart your smartphone, or reset network settings.
- **Software Update Problems:** Ensure enough storage space, restart the phone, and reconnect to a stronger Wi-Fi signal.
- **Battery Not Charging:** Try using a different cable or charger, reset the device, or check for debris in the charging port.

Customer Support

For support, visit our website at www.brownboxsupport.com or call 1800-555-0199. Warranty details and service center locations are available on the website.

FAQs

- **How to perform a factory reset?** Navigate to 'Settings' > 'System' > 'Reset' > 'Factory Data Reset'. Confirm the action.
- **Can I expand the storage?** Yes, up to 512GB through the microSD slot.

Visual Aids

Refer to the included visual guide on page 11 for images related to setup and troubleshooting.