

Welcome to the CleanCare SonicBrush X200 user manual. This comprehensive guide will provide you with all the necessary information to make the most of your SonicBrush experience.

Product Overview The CleanCare SonicBrush X200 is designed for superior oral care with advanced sonic technology, offering up to 31,000 strokes per minute for deep cleaning and healthier gums. Its ergonomic design ensures comfortable handling, while the dual-speed setting caters to different cleaning needs.

Package Contents - 1 SonicBrush X200 Handle - 2 Interchangeable Brush Heads - 1 Charging Base (Model CB234) - User Manual - 1 Travel Case

Initial Setup 1. Remove the toothbrush and components from the packaging. 2. Attach the brush head to the handle by aligning it with the metal shaft and pressing until it clicks. 3. Place the toothbrush on the charging base, ensuring it aligns with the charging pins. 4. Plug the charging base into an electrical outlet. Charge the toothbrush for at least 24 hours before first use.

Usage Instructions 1. Wet the toothbrush head and apply a small amount of toothpaste. 2. Place the brush head on your teeth and press the power button. 3. Move the brush gently in a back-and-forth motion. 4. Use the mode button to switch between standard and gentle cleaning. 5. The built-in timer signals every 30 seconds to change the brushing quadrant.

Charging and Battery - The X200 uses a lithium-ion battery designed to last up to 2 weeks on a full charge. - Recharge every 14 days by placing the handle on the charging base.

Compatibility - Compatible with all CleanCare brush heads. - Supports charging through CleanCare model CS1234 charging station.

Troubleshooting - Toothbrush Not Turning On: Ensure the handle is charged. If not, place it on the charger for 24 hours. - **Unusual**

Noise: Clean the brush head and handle to remove debris. - **Weak Vibration:** Replace the brush head if worn. Check for full charge.

Maintenance and Cleaning - Clean the brush head and handle under running water after each use. - Remove the brush head weekly and rinse the shaft, avoiding water on the metal part.

Warranty Information The SonicBrush X200 comes with a two-year warranty covering defects in material and workmanship. Warranty does not cover damage due to misuse or unauthorized repairs.

Customer Support For assistance, contact CleanCare support at 1-800-555-0199 or visit our website at cleancare.com/support. Our support team is available 24/7 to help with any questions or concerns.

Thank you for choosing CleanCare SonicBrush X200. We hope it brings you a cleaner, brighter smile every day!