

Product Overview

The EchoSound 5 Elite is a cutting-edge smart speaker designed to enhance your home audio experience. It offers robust sound quality, voice-activated assistance, and seamless integration with smart home devices. Whether you're streaming your favorite tunes or managing your daily tasks, the EchoSound 5 Elite is your innovative companion.

Key Features:

- **Voice Control:** Hands-free convenience with built-in voice assistant.
- **Smart Home Integration:** Connect and control compatible smart home devices effortlessly.
- **High-Fidelity Audio:** Superior sound quality for an immersive listening experience.
- **Connectivity:** Wi-Fi and Bluetooth capabilities.

Setup and Installation

Unboxing Your Device:

1. Carefully remove the EchoSound 5 Elite from its packaging.
2. Ensure the following items are included:
3. EchoSound 5 Elite speaker
4. Power adapter
5. Quick start guide

Connecting to Wi-Fi:

1. Plug in your EchoSound 5 Elite to a power source using the provided adapter.
2. Download and install the 'EchoSound App' from your device's app store.

3. Open the app and follow the on-screen instructions to connect your speaker to your home Wi-Fi network. Make sure your phone is connected to the same Wi-Fi.

First-Time Setup:

1. Once connected, the app will guide you through voice assistant setup.
2. Customize your speaker by linking music streaming services and smart home devices via the app.

Using the Product

Voice Commands:

- Activate your voice assistant by saying, "Hey Echo," followed by your command.
- Examples include: "Play jazz music," "What's the weather today?", "Turn off the living room lights."

Streaming Music:

- Use voice commands or the app to stream music from supported services like Spotify, Apple Music, or Amazon Music.

Smart Home Control:

- Manage compatible devices such as lights, thermostats, and locks using voice commands.

Troubleshooting and FAQs

Wi-Fi Connectivity Issues:

- Ensure your EchoSound 5 Elite is within range of the router.
- Verify that the Wi-Fi password is entered correctly in the app.
- Try resetting your speaker by pressing the reset button located at the bottom for 10 seconds.

Resetting the Device:

- To reset the EchoSound 5 Elite, hold down the reset button for approximately 10 seconds until the LED indicator flashes.

Error Messages:

- If you encounter messages like 'Network Not Found,' ensure all networking equipment is functioning properly and restart both router and speaker.

Maintenance and Care

Cleaning the Speaker:

- Use a soft, dry cloth to clean the exterior.
- Avoid using liquids or abrasive materials.

Software Updates:

- Check the EchoSound App regularly for firmware updates to enhance performance and features.

Warranty and Support

The EchoSound 5 Elite comes with a one-year limited warranty. For further assistance, please contact our support team at support@brownbox.com or call 1-800-555-1265.

We hope you enjoy your new EchoSound 5 Elite. For additional help, access our online support pages or reach out directly.