

EchoSound Model X Smart Speaker Documentation

Product Overview

The EchoSound Model X is a state-of-the-art smart speaker designed to seamlessly integrate into your smart home environment. With advanced voice recognition technology, it allows you to control various aspects of your life simply by using your voice. Its features include high-fidelity audio output, Wi-Fi and Bluetooth connectivity, compatibility with popular smart home ecosystems such as Amazon Alexa and Google Assistant, and a sleek, modern design.

Specifications: - **Dimensions:** 6.5 inches in height, 3.9 inches in diameter - **Weight:** 1.2 pounds - **Connectivity:** Wi-Fi 802.11b/g/n/ac, Bluetooth 5.0 - **Audio:** 360-degree audio with noise-canceling microphones - **Colors:** Available in Black, White, and Silver

Initial Setup

1. **Unboxing:** Carefully remove your EchoSound Model X from its packaging. Ensure that all components are included: the smart speaker, power adapter, and quick start guide.
2. **Connecting to Power:** Plug the included power adapter into the EchoSound Model X and then into a power outlet nearby. The LED ring will light up, indicating that the device is powered on.
3. **Downloading the App:** Download the 'EchoSound App' from the App Store or Google Play. Install it on your smartphone or tablet.
4. **Setting Up Wi-Fi:**
5. Open the 'EchoSound App'.
6. Follow the on-screen instructions to connect to your home Wi-Fi network. Ensure to use the correct Wi-Fi password.

7. **Completing the Setup:** Once connected, follow any additional setup instructions in the app, which may include signing into various smart home services.

Wi-Fi Connectivity Troubleshooting

- **Common Issues:** If the smart speaker cannot connect to Wi-Fi, ensure the network is active and the password is correct. Move the speaker closer to the router if needed.
- **Reset Wi-Fi Settings:** Press and hold the reset button on the bottom of the speaker for 10 seconds until the LED ring flashes orange, then attempt reconnection.
- **Check Signal Strength:** Use the EchoSound app to check Wi-Fi signal strength. A weak signal might cause connectivity issues. Move the speaker closer to the router.

Troubleshooting Guide

- **Error: 'Unable to Connect to Network':**
 - Ensure the Wi-Fi router is functioning and try resetting the router.
 - Restart the smart speaker by unplugging it for 10 seconds and then restarting.
 - Update the speaker's firmware via the app.
- **Device Not Responding:**
 - Check for firmware updates in the app.
 - Perform a factory reset (see Wi-Fi reset).

Using Voice Commands

Simply say "Hey EchoSound" followed by your command, such as "play music", "what's the weather", "set an alarm for 7 AM", etc. Explore more commands in the app.

Integration with Smart Home

- **Amazon Alexa:** Enable the EchoSound skill in the Amazon Alexa app.
- **Google Assistant:** Link your device through the Google Home app by following integration instructions.

Maintenance and Care

- Avoid placing the EchoSound Model X in areas with high moisture.
- Clean the exterior with a soft cloth; avoid using harsh chemicals.

Frequently Asked Questions (FAQs)

- **How do I know if I need a firmware update?**
 - The EchoSound app will notify you of any available updates.
- **Can I use multiple EchoSound speakers?**
 - Yes, through the group feature in the app, you can synchronize audio across devices.

Customer Support

If you encounter any issues not covered in the documentation, contact EchoSound Support via the app or at support@echosound.com. Our team is available 24/7 to assist you.