

EchoSound Pro Smart Speaker - User Manual

Product Overview

The EchoSound Pro is a versatile smart speaker designed to deliver high-fidelity audio and seamless voice assistant interaction. With its sleek design and robust functionality, it lets you control music, smart home devices, and access a world of information hands-free.

Key Features

- **Voice Control:** Integrates with popular voice assistants to answer questions, play music, and control compatible devices.
- **Wireless Connectivity:** Supports Wi-Fi and Bluetooth for versatile streaming and connectivity options.
- **High-Quality Sound:** Delivers rich audio with deep bass and clear vocals.

Setup Instructions

1. **Unboxing:** Carefully remove the speaker from the packaging. Ensure that all components, including the power adapter and quick start guide, are included.
2. **Power On:** Connect the EchoSound Pro to a power outlet using the included adapter and press the power button. The speaker will indicate start-up with a chime.
3. **Wi-Fi Connection:**
4. Download the "EchoSound" app from your device's App Store or Google Play.
5. Open the app, create an account, or log in if you already have one.
6. Select "Add Device" and choose "EchoSound Pro."
7. Follow on-screen instructions to connect to your Wi-Fi network.

8. Once connected, the speaker will announce successful connection.

9. Bluetooth Pairing:

10. Ensure your mobile device has Bluetooth enabled and is discoverable.

11. Press and hold the Bluetooth button on the speaker until the indicator light blinks.

12. Search for “EchoSound Pro” in your device's Bluetooth settings and select to pair.

Usage Instructions

- **Playing Music:** Use voice commands or the EchoSound app to play music. Connect your preferred music streaming service for integrated playback.
- **Voice Commands:** Say the wake word (default: “Echo”) followed by your command, e.g., “Echo, play jazz music.”
- **Smart Device Control:** Link your smart home devices in the app to control them using your voice, e.g., “Echo, turn off the lights.”

Troubleshooting

- **Wi-Fi Connection Issues:**
 - Ensure the speaker is within range of your Wi-Fi router.
 - Double-check your Wi-Fi password.
 - Restart the router and the speaker.
- **Bluetooth Connectivity Problems:**
 - Delete existing pairings and attempt to reconnect.
 - Restart both the speaker and the mobile device.
 - Confirm no other devices are interfering with the connection.
- **Resetting the Device:**

- Press and hold the reset button located at the bottom of the speaker for 10 seconds.
- The speaker will power cycle and restore factory settings.

Maintenance and Care

- Keep the speaker away from moisture and extreme temperatures.
- Clean the exterior with a soft, dry cloth; avoid using liquid cleaners.
- Regularly update the app and speaker firmware for optimal performance.

Technical Specifications

- **Audio Output:** 360-degree speaker with dual woofers and tweeters.
- **Connectivity:** Wi-Fi 802.11a/b/g/n, Bluetooth 5.0.
- **Power Supply:** AC adapter included, input: 100-240V.

FAQs

- **How do I change the wake word?**
 - Open the app, go to device settings, and select “Wake Word.” Choose from the available options.
- **Can I use the speaker with multiple accounts?**
 - Yes, guest access can be set up through the app to allow multiple users.
- **What do I do if the speaker’s voice assistant does not respond?**
 - Ensure the microphone is not muted (check the mic button) and that the speaker is connected to Wi-Fi.

For further assistance, please contact our customer support through the EchoSound app or visit our website at www.echosoundprosupport.com.