

EchoSound X1 Smart Speaker Documentation

Introduction

Welcome to your EchoSound X1 Smart Speaker! This cutting-edge device combines superior audio performance with advanced voice recognition technology. It's designed to make your life easier, whether you're controlling your smart home devices, streaming music, or managing your daily tasks via voice commands.

Technical Specifications

- **Dimensions:** 6.5 x 3.5 x 3.5 inches
- **Weight:** 1.2 lbs
- **Connectivity:** Dual-band Wi-Fi support (2.4 GHz and 5 GHz), Bluetooth 5.0
- **Supported Audio Formats:** MP3, AAC, WAV, FLAC
- **Voice Assistant:** Integrated with Alexa Voice Service
- **Power Requirement:** AC power adapter included

Setup Guide

Step 1: Unbox Your EchoSound X1 Unpack the box and ensure all components are present: - EchoSound X1 Speaker - Power Adapter - Quick Start Guide

Step 2: Connect the Power Adapter Plug the included power adapter into the EchoSound X1 and then into a power outlet. Wait for the light ring on top of the speaker to turn orange, indicating it's in setup mode.

Step 3: Download the EchoSound App Available on iOS and Android, the app will guide you through connecting the speaker to your home Wi-Fi network.

Step 4: Connect to Wi-Fi Open the app, select 'Add Device,' and follow the on-screen instructions to connect the speaker to your Wi-Fi. Make sure your phone is connected to the same network.

Step 5: Complete the Setup Once connected, personalize your speaker by selecting default music services and setting your location preferences.

Operational Instructions

Voice Commands Use the wake word “Alexa” followed by your command. Example commands: - “Alexa, play my jazz playlist.” - “Alexa, what's the weather today?” - “Alexa, turn off the living room lights.”

Controlling Smart Devices Ensure your EchoSound X1 is linked with compatible smart home devices through the app. You can control lighting, thermostats, and more.

Music and Entertainment - Stream from popular services like Spotify, Apple Music, and Amazon Music. - Use multi-room audio to play music across compatible devices.

Reminders and Alarms Set reminders and alarms to keep track of tasks and appointments. Example: “Alexa, set a 10-minute timer.”

Troubleshooting

Wi-Fi Connection Issues: - Ensure the speaker is within range of the router. - Restart both your router and the speaker. - Check if the Wi-Fi password is correctly entered.

Device Not Responding: - Confirm the speaker is powered on and the mute button is not activated. - Restart the speaker. Press and hold the reset button if necessary.

Maintenance Tips

- Regularly clean the speaker with a soft, dry cloth. Avoid water or chemical cleaners.
- Keep the software updated via the EchoSound app to access the latest features and improvements.

Customer Support

For further assistance, contact our support team: - Phone: 1-800-XXX-XXXX - Email: support@echosound.com - Live Chat available on our website

Prepare the following information for faster assistance: Model number, purchase date, and a detailed description of the issue.

Thank you for choosing EchoSound X1. We are committed to delivering an exceptional audio and smart home experience. Explore the endless possibilities with your new smart speaker!