

Product Overview

The EcoBlade Pro 4500 is a state-of-the-art lawn mower designed for efficiency, performance, and environmental sustainability. Equipped with the innovative SmartCut technology, it automatically adjusts to varying grass densities, optimizing cutting performance and battery life. Its eco-friendly design includes a powerful rechargeable battery, durable cutting blades, and a user-friendly interface, making it perfect for maintaining medium to large lawns with ease.

Key Features

- **SmartCut Technology:** Automatically adjusts the cutting power based on grass thickness.
- **Cutting Width:** 21-inch deck for efficient mowing.
- **Height Adjustment:** 7-position height adjustment ranging from 1.5 to 4 inches.
- **Power Source:** Rechargeable lithium-ion battery providing up to 90 minutes of run time on a full charge.
- **Mulching Capability:** 3-in-1 functionality offering mulching, bagging, and side discharge.
- **Warranty:** 2-year warranty covering parts and labor.

Usage Instructions

1. **Assembly:** Refer to the included assembly guide to set up the handle, connect the battery, and ensure the cutting deck is secure.
2. **Starting the Mower:** Insert the battery, engage the safety key, and press the start button.
3. **Operating:** Adjust the cutting height using the lever located on the side of the mower. For optimal performance, start on the highest setting.
4. **Battery Charging:** Plug the charger into a standard outlet. It is recommended to fully charge the battery before each use.
5. **Storage:** Store in a dry, secure area. Detach the battery if not in use for prolonged periods.

Troubleshooting Guide

- **Mower Won't Start:** Ensure the battery is charged, the safety key is engaged, and all connections are secure.
- **Uneven Cuts:** Check the blade for sharpness and adjust the cutting height.
- **Battery Issues:** Confirm the charger is working. Replace the battery if runtime decreases significantly.

Warranty and Support

The EcoBlade Pro 4500 comes with a comprehensive 2-year warranty covering any manufacturing defects. For support, reach out via support@ecobladetech.com or call our helpline at 1-800-555-4500. Returns are accepted within 30 days of purchase under our return policy.

Safety Guidelines

- Always wear appropriate footwear and eye protection while operating the mower.
- Do not operate the mower on steep slopes to avoid tipping.
- Keep hands and feet away from the cutting deck while in operation.

Environmental Considerations

Designed with sustainability in mind, the EcoBlade Pro 4500 offers reduced emissions and energy-efficient performance. Enjoy quieter mowing sessions with our advanced motor technology.

Customer Support

For further assistance, visit our FAQ section on www.ecoblade.com/faq or explore community forums for tips and advice from fellow EcoBlade users.