

EcoChef 10-Piece Cookware Set

Documentation

Product Overview

The EcoChef 10-Piece Cookware Set is designed for home cooks who demand quality, durability, and style. Constructed with high-quality stainless steel and an aluminum core, this set ensures even heat distribution, reducing cooking time and energy use. The EcoChef set includes all the essential pots and pans needed for a wide variety of recipes.

What's Included

- 8-inch Fry Pan
- 10-inch Fry Pan
- 1.5-Quart Saucepan with Lid
- 2.5-Quart Saucepan with Lid
- 6-Quart Stock Pot with Lid
- Steamer Insert

Key Features

- **Material:** High-quality stainless steel with an aluminum core for fast, even heating.
- **Non-Stick Coating:** PFOA-free non-stick interior ensures easy food release and cleanup.
- **Ergonomic Handles:** Comfortably designed for easy handling.
- **Dishwasher Safe:** Easy to clean and maintain.
- **Induction Compatible:** Suitable for all stovetop types, including induction.

Usage Instructions

Before First Use

1. Remove all packaging and labels.
2. Wash with warm, soapy water, and dry thoroughly.
3. Optionally, season non-stick surfaces by rubbing a thin layer of oil and heating on medium heat for a few minutes.

Cooking Tips

- Preheat pans gradually to prevent warping.
- Use low to medium heat settings for optimal performance.
- Avoid using metal utensils to extend the life of the non-stick coating.

Care and Maintenance

Cleaning

- Allow cookware to cool before washing.
- Hand wash recommended for long-term care, though dishwasher safe.
- Use non-abrasive pads or sponges.

Storage

- Stack carefully using soft protectors between pieces to prevent scratches.

Troubleshooting

- **Food Sticking:** Ensure appropriate heat settings or re-season cookware.
- **Discoloration:** Use a non-abrasive cleaner to remove stains.
- **Unstable Handles:** Tighten screws regularly.

Frequently Asked Questions

Q: Are these pans oven-safe? A: Yes, up to 400°F.

Q: Can I use metal utensils? A: It's best to use wooden or silicone utensils to preserve the non-stick surface.

Q: Is there a warranty? A: Yes, a 1-year limited warranty covers defects in material and workmanship.

Customer Support

For questions, comments, or warranty inquiries, please contact our Customer Support: - Email: support@ecochef.com - Phone: 1-800-555-COOK - Hours: Mon-Fri, 9 AM - 5 PM EST

Thank you for choosing EcoChef. We hope you enjoy cooking with us!