

EcoCut Pro 5000 Lawn Mower Documentation

Product Overview:

The EcoCut Pro 5000 is a state-of-the-art cordless lawn mower designed to deliver an effortless and efficient mowing experience. Perfect for small to medium-sized lawns, the EcoCut Pro 5000 combines eco-friendly technology with powerful performance.

Key Features:

- **Cutting Width:** 21-inch deck that ensures a faster mowing process by covering more ground.
- **Power Source:** Equipped with a 160cc high-efficiency electric motor.
- **Battery Details:** Comes with a 60V rechargeable lithium-ion battery, providing up to 70 minutes of runtime on a full charge.
- **Charging Time:** Quick charge capability of up to 90 minutes for a full charge.
- **Height Adjustment:** Adjustable cutting height with 5 different settings ranging from 1.5 to 4 inches.
- **Warranty:** Two-year limited warranty covering parts and labor.

Setup and Assembly:

1. **Unboxing:** Carefully remove the EcoCut Pro 5000 from the packaging. Ensure all parts are present, including the battery and charging unit.
2. **Assembly:** Attach the handle to the main body using the provided bolts. Follow the guide to connect the grass catcher bag.
3. **Battery Installation:** Insert the battery into the compartment until it clicks.

Operating Instructions:

1. **Starting the Mower:** Ensure the battery is charged and properly inserted. Press the safety button while pulling the start lever.
2. **Adjusting Cutting Height:** Use the lever located on the left wheel to set your desired grass length.
3. **Mowing:** Start mowing from the edge of your lawn, moving in straight lines for an even cut.
4. **Shutting Down:** Release the start lever to stop the mower. Remove the battery if storing for extended periods.

Maintenance and Care:

- **Cleaning:** After use, clean the underside of the deck to prevent grass buildup using a brush or hose.
- **Battery Maintenance:** Store the battery in a cool, dry place when not in use. Avoid exposing it to direct sunlight.
- **Blade Care:** Regularly check the blade for wear. Sharpen or replace it as needed.

Troubleshooting:

- **Mower Doesn't Start:** Check the battery charge and its connection. Ensure the safety button is pressed while starting.
- **Uneven Cutting:** Adjust the cutting height and ensure the blade is sharp.
- **Battery Does Not Charge:** Inspect the charger for damage. Contact support if the problem persists.

Safety Guidelines:

- Read all instructions before operating the mower.
- Always wear sturdy footwear and protective eyewear.
- Never mow wet grass, as it may cause slipping or mower damage.

Customer Support and Warranty:

For any questions or warranty claims, please contact our support team at support@ecocut.com or call 1-800-555-0199. Ensure you have your purchase details and mower serial number ready.

The EcoCut Pro 5000 is designed to make lawn care simple, efficient, and environmentally friendly. Enjoy a pristine lawn with less hassle and more freedom.