

EcoSweep Max Vacuum Cleaner

Documentation

Product Overview

The EcoSweep Max is designed with versatility and durability in mind, suitable for a variety of floor types including carpets, hardwood, and tiles. Combining powerful suction with energy efficiency, it is perfect for homes with pets or allergies.

Key Features

- **Suction Power:** 240 Air Watts
- **Weight:** 3.2 kg
- **Battery Life:** 70 minutes on standard mode
- **Recharge Time:** 4 hours
- **Noise Level:** <75 dB
- **HEPA Filtration:** Captures 99.97% of particles
- **Attachments Included:** Pet hair tool, crevice tool, upholstery brush
- **Voltage Compatibility:** Dual (110-240V), with UK adapter included

Box Contents

- EcoSweep Max Vacuum Cleaner
- Lithium-ion Battery
- Charging Dock
- Pet Hair Tool
- Crevice Tool
- Upholstery Brush
- User Manual

Initial Setup

1. **Unbox:** Carefully remove the EcoSweep Max and accessories from the packaging.
2. **Assembly:** Attach the desired nozzle and click the battery pack into place at the rear.
3. **Charging:** Place the device on its charging dock for a minimum of 4 hours before first use.

Operating Instructions

Powering On - Press the main button to activate the vacuum cleaner. Cycle through power settings by continuously pressing the button.

Mode Selection - Eco Mode: Ideal for hard surfaces to save power.
- **Turbo Mode:** For carpets and rugs requiring deep cleaning. - **Pet Mode:** Use with the pet hair tool for removing stubborn hair.

Attachments and Use - Pet Hair Tool: Slide into the main nozzle to capture pet hair efficiently. - **Crevice Tool:** Ideal for corner cleaning and narrow spaces. - **Upholstery Brush:** Use on fabric surfaces to remove dust.

Maintenance

Filter Cleaning - Remove the HEPA filter every 3 months. Rinse with cold water and ensure it's fully dry before reinstallation.

Dust Bin Emptying - Press the bin release button, detach and empty contents into a waste bin.

Battery Maintenance - Avoid complete drainage before recharging. Store at room temperature for longevity.

Troubleshooting

Vacuum Not Powering On - Ensure the battery pack is fully charged and properly connected.

Loss of Suction Power - Check and clear any blockages in the hose or attachments. - Clean or replace the filter if clogged.

Charging Issues - Test using a different outlet or adapter. - Contact customer support if issues persist after trying multiple outlets.

Safety Precautions

- Do not use the vacuum for liquids.
- Keep away from children and pets when in operation.
- Ensure hands are dry when handling electrical components.

Customer Support and Warranty

For support, contact our hotline at 0800-123-4567 or email support@ecosweepmax.com. - **Warranty:** 2-year warranty against manufacturing defects. - **Returns and Refunds:** Initiate through the website portal within 30 days of purchase.

For more detailed inquiries, visit our website at www.ecosweepmax.com.

This documentation provides a comprehensive guide for new users to efficiently operate and maintain their EcoSweep Max, along with ensuring they have access to adequate support channels for any assistance required.