

EcoWash 3000 Dishwasher

Documentation

Introduction

The EcoWash 3000 is a state-of-the-art dishwasher designed to provide an impeccable cleaning experience while maintaining high energy efficiency with minimal water consumption. With its smart connectivity feature, you can control and monitor your dishwasher remotely using the EcoHome mobile app.

Features

- **Energy Efficient:** Uses only 3.5 gallons of water per cycle.
- **Quiet Operation:** Operates at a noise level of 44 decibels, allowing silent operation.
- **Smart Connectivity:** Manage your wash cycles through the EcoHome app.
- **Adjustable Racks:** Flexible racking system to accommodate different dish sizes.
- **Quick Wash Cycle:** Complete a wash cycle in just 30 minutes.

Installation Guide

1. **Unpacking:** Carefully remove the dishwasher from its packaging and ensure all parts are included.
2. **Positioning:** Place the unit under your kitchen counter near water and electrical outlets.
3. **Water Connection:**
 4. Make sure all valves are shut off before connecting.
 5. Use a $\frac{3}{4}$ -inch connection hose to attach to the cold water supply.
6. **Electrical Connection:**
 7. Ensure the dishwasher is plugged into a grounded outlet.
8. **Leveling:** Adjust the feet at the bottom of the dishwasher to ensure it is level.

Usage Instructions

1. **Loading Dishes:**
2. Place dishes in the racks ensuring they don't block the spray arms.
3. **Selecting Cycle:**
4. Choose a wash cycle using the control panel or app.
5. **Starting the Dishwasher:**
6. Press the start button on the machine or use the app to activate the wash cycle.

Troubleshooting

- **Dishwasher Not Starting:**
 - Check power and water supply connections.
 - Ensure the door is closed securely.
- **App Connectivity Issues:**
 - Restart your phone and the dishwasher.
 - Ensure Bluetooth is enabled and try reconnecting through the app.
- **Water Draining Problems:**
 - Check for blockages in the drain hose.
 - Ensure the dishwasher is level to avoid improper draining.

Maintenance and Cleaning

- **Regular Cleaning:** Clean filters and spray arms monthly to maintain efficiency.
- **Door Seals:** Wipe door seals weekly to prevent mold.
- **Detergent and Rinse Aid:** Use recommended amounts for optimal results.

Warranty and Service

- **Standard Warranty:** 2-year warranty covering parts and labor.
- **Extended Warranty:** Available for purchase through the EcoHome website.
- **Service and Support:** Contact us at support@ecohome.com or call (800) 555-0199.

Ensure you register your product on our website to activate the warranty and receive product updates.

Conclusion

The EcoWash 3000 dishwasher combines efficiency, smart technology, and ease of use to provide you with a hassle-free dishwashing experience. For any questions or concerns, our support team is ready to assist you.