

EcoWash 700 User Manual

Product Overview

The EcoWash 700 is an advanced washing machine designed for optimal performance and energy efficiency. Rated A++ for energy consumption, it combines innovative technology with user-friendly operation.

Key Features

- **Energy Efficiency:** A++ rating ensures reduced electricity usage.
- **Capacity:** 7kg drum accommodates medium to large loads.
- **Wash Programs:** 15 diverse wash cycles including Delicate, Quick Wash, and Eco-mode.
- **Smart Features:** Wi-Fi enabled for remote operation with a dedicated mobile app.
- **Safety:** Child lock system to prevent accidental program changes.
- **Inverter Motor:** Offers quieter operation and longer lifespan.

Installation Guide

1. **Unpacking:** Carefully remove the machine from its packaging to avoid damage.
2. **Positioning:** Place the machine on a stable, flat surface.
3. **Connecting Water Supply:**
4. Attach the water inlet hose to the cold water tap.
5. Ensure connections are secure to avoid leaks.
6. **Plugging In:** Use a standard 110V outlet.
7. **Leveling:** Use a spirit level to ensure the machine is balanced.

Using Your EcoWash 700

1. **Loading the Machine:**
2. Open the drum and evenly distribute laundry.

3. **Selecting a Program:**

4. Use the dial to select desired wash setting.
5. Adjust temperature and spin settings using the control panel.

6. **Starting the Wash:**

7. Press the Start button to begin.

8. **Adding Detergent:**

9. Follow the compartment guidelines for detergent and fabric softener.

Maintenance Tips

- **Cleaning the Drum:** Run a maintenance wash monthly using a drum cleaner.
- **Checking the Filters:** Remove and clean the filter every three months.
- **Inspecting Hoses:** Regularly check inlet and outlet hoses for wear and tear.

Troubleshooting

- **Machine Won't Turn On:**
 - Ensure it's plugged into a live socket.
 - Try resetting if a power surge occurred.
- **Loud Noises During Operation:**
 - Check for balance and redistribute laundry.
- **Stops Mid-Cycle:**
 - Examine if door is correctly closed; reset if necessary.

Warranty Information

- **Standard Warranty:** 2 years covering mechanical and technical faults.
- **Extended Options:** Available at additional cost.
- **Claiming Warranty:** Contact customer support for assistance.

Customer Support

For assistance, contact our 24/7 customer helpline via: - **Phone:** 1-800-ECO-WASH - **Email:** support@ecowash.com

Safety Guidelines

- Keep out of reach of children unless supervised.
- Disconnect power before performing any maintenance.

The EcoWash 700 meets all regulatory standards for safety and efficiency, making it a trusted choice for your laundry needs.