

FitTech FlexRun 3000 User Manual

1. Introduction

Welcome to your new FitTech FlexRun 3000 Treadmill. This state-of-the-art machine combines cutting-edge technology with ergonomic design to enhance your fitness regimen. This document covers everything you need to know about setup, features, and troubleshooting.

2. Product Specifications

- **Motor Power:** 3.5 HP
- **Weight Capacity:** 350 lbs
- **Speed Range:** 0.5 - 12 mph
- **Incline:** 0-15% Automatic
- **Display:** 10-inch HD Touchscreen
- **Workout Programs:** 20 pre-installed
- **Connectivity:** Bluetooth, USB port
- **Additional Features:** Heart rate monitor, SmartTrack feature for app syncing

3. Unboxing and Assembly

Start by unpacking your treadmill carefully.

Contents:

- Treadmill frame
- Accessory tray
- Screws and a hex wrench
- Power cable
- User Manual

Assembly Steps:

1. Attach the accessory tray to the console using the provided screws.

2. Connect the handlebars to the console support.
3. Plug in the treadmill using the provided power cable.
4. Ensure all parts are tightly secured before use.

4. Using Your Treadmill

- **Powering On:** Ensure the safety key is attached. Press the power button.
- **Program Selection:** Use the touchscreen to select predefined workouts or manually adjust speed and incline.
- **Heart Rate Monitoring:** Hold the sensors located on the handlebars firmly.

5. Connectivity and Features

- **Bluetooth Setup:** Navigate to 'Settings' on the display and select 'Bluetooth'. Pair with your compatible device.
- **Using SmartTrack:** Download the FitTech app from your device store. Follow prompts to sync workout data.

6. Maintenance

- **Belt Alignment:** Check bi-weekly to ensure even surface movement.
- **Cleaning:** Use a damp cloth and mild detergent for external surfaces monthly.

7. Troubleshooting

- **App Sync Issues:** Ensure your device Bluetooth is active; restart both the treadmill and app if problems persist.
- **Overheating:** Switch off, let the treadmill cool, and ensure proper ventilation.

8. Warranty Information

- **Duration:** 2-year comprehensive coverage, 5-year motor warranty

- **Registration:** Find a warranty card in the packaging. Register online at the FitTech website.

9. Customer Support

For support, visit our website or contact our helpline at 1-800-FIT-TECH.

10. Conclusion

We thank you for choosing the FitTech FlexRun 3000. We are committed to helping you achieve your fitness goals with the utmost safety and satisfaction.

Note: Ensure you retain your proof of purchase for warranty claims or service inquiries.

This documentation ensures you have all necessary information regarding your treadmill, from initial setup to ongoing maintenance and support procedures. For further assistance, the FitTech support team is always ready to help.