

GourmetCraft Non-Stick Frying Pan Documentation

Product Overview

The GourmetCraft Non-Stick Frying Pan is designed for culinary enthusiasts who seek performance and durability in the kitchen. This high-quality frying pan features an advanced non-stick coating, ergonomic handle design, and full compatibility with various heat sources including induction, gas, and electric stovetops.

Features:

- **Premium Non-Stick Coating:** Ensures food slides off effortlessly and promotes healthier cooking with less oil.
- **Ergonomic Handle:** Offers a comfortable grip and stays cool during cooking.
- **Induction Ready:** Safe for use on all types of stovetops, including induction.
- **Oven Safe:** Heat resistant up to 350°F (176°C).

Getting Started

Initial Setup:

1. **Unpacking:** Carefully remove the frying pan from its packaging. Inspect for any visible damage.
2. **Cleaning:** Wash with warm soapy water using a soft sponge. Dry thoroughly.
3. **Seasoning:** Lightly coat with vegetable oil and heat on low for a few minutes before the first use to enhance non-stick properties.

Using Your Frying Pan:

- Set the stovetop element to a moderate heat setting before placing the pan on it.
- For best results, avoid pre-heating the pan dry for extended periods.
- Use wooden, silicone, or heat-resistant plastic utensils to avoid scratching the non-stick surface.

Maintenance and Care

Cleaning Instructions:

- Allow the pan to cool before washing to prevent warping.
- Gently clean with a soft sponge or cloth and mild detergent. Avoid abrasive cleaners or steel wool.
- Dishwasher safe, though hand washing is recommended to maintain the non-stick coating.

Storage Tips:

- Stack with precautions if storing with other cookware. Use felt or fabric protectors between pans.
- Ensure the pan is completely dry to prevent moisture buildup during storage.

Troubleshooting Guide

Common Issues:

- **Food Sticking:** Ensure proper seasoning and avoid cooking on very high heat as it can compromise the coating.
- **Discoloration:** Commonly caused by overheating. Regular cleaning should mitigate surface changes, but be cautious with heat settings.
- **Handle Loose:** Use a Phillips screwdriver to gently retighten screws. Avoid over-tightening.

Safety and Warranty Information

Safety Guidelines:

- Do not exceed temperature limits indicated for oven use.
- Avoid using sharp utensils that may damage the surface.

Warranty:

- Comes with a 5-year limited warranty covering manufacturing defects.
- Return or exchange items by contacting our customer service with proof of purchase.

Customer Support

Our customer support team is available to assist you with any questions or concerns regarding the GourmetCraft Frying Pan.

Contact Us:

- **Phone:** 1-800-555-COOK
- **Email:** support@gourmetcraft.com
- **Website:** www.gourmetcraft.com/support

Whether you need assistance with refunds, exchanges, or general inquiries, our team is here to help. Thank you for choosing GourmetCraft for your culinary needs.