

HarmonySound Ultra Wireless Speaker Documentation

Overview

The HarmonySound Ultra is a top-of-the-line wireless speaker designed for premium audio quality. Seamlessly blend this speaker into your home audio setup with intuitive controls and advanced connectivity options.

Features

- **Bluetooth 5.0 Connectivity:** Connect effortlessly with all your Bluetooth-enabled devices.
- **Dual-Band Wi-Fi:** Supports both 2.4GHz and 5GHz connections for robust streaming.
- **Voice Assistant Integration:** Compatible with Alexa and Google Assistant.
- **Multi-room Audio Capability:** Synchronize speakers across multiple rooms using the Harmony app.
- **Long-lasting Battery:** Enjoy up to 12 hours of uninterrupted sound on a single charge.

Specifications

- **Dimensions:** 10 x 7 x 7 inches
- **Weight:** 3.5 lbs
- **Frequency Response:** 40Hz - 20kHz
- **Battery Capacity:** 4000mAh
- **Ports:** USB-C, Aux-in

What's in the Box

- 1 x HarmonySound Ultra Speaker
- 1 x USB-C Charging Cable
- 1 x Quick Start Guide

- 1 x Warranty Card

Getting Started

1. **Charge Your Speaker:** Connect the USB-C cable to the charging port and plug it into a power source. Allow 3 hours for a full charge.
2. **Power On:** Press and hold the power button until the LED indicator lights up.
3. **Download the Harmony App:** Available on iOS and Android, search 'HarmonySound' in your app store.

Connecting via Bluetooth

1. **Activate Pairing Mode:** Press the Bluetooth button until the LED flashes.
2. **Select Device:** On your phone or computer, go to Bluetooth settings and select 'HarmonySound Ultra'.
3. **Confirmation:** You'll hear a tone indicating successful pairing.

Connecting to Wi-Fi

1. **Open the Harmony App:** Log in to your account or create one.
2. **Follow App Instructions:** Navigate to 'Set up new device' and choose 'HarmonySound Ultra'.
3. **Connect to Wi-Fi:** Enter your Wi-Fi credentials in the app to connect.

Using Voice Control

- **Alexa/Google Assistant Setup:** In the Harmony app, link your preferred voice assistant.
- **Voice Commands:** Use voice commands for hands-free operation, such as playing music, adjusting volume, or querying device status.

Troubleshooting

- **Bluetooth Connection Failed:** Restart both speaker and device, ensure both are in range, and attempt re-pairing.
- **Wi-Fi Issues:** Ensure the speaker is within router range. Reboot the router and speaker.
- **Unresponsive Device:** Perform a factory reset by holding the power button for 10 seconds.

FAQs

- **Q:** How do I perform a factory reset? **A:** Hold the power button for 10 seconds until the LED blinks.
- **Q:** Can I use the speaker while charging? **A:** Yes, the speaker is fully functional while charging.

Customer Support

For further assistance, contact our support team at support@harmonysound.com or call 1-800-555-0199.

Thank you for choosing HarmonySound Ultra. Enjoy unparalleled audio experiences throughout your home!