

ProFit Runner Advance 3000 User Manual

Introduction

Welcome to your new ProFit Runner Advance 3000, designed to enhance your fitness routine with advanced features and robust performance. Perfect for all levels, whether you're beginning your fitness journey or training for a marathon.

1. Setup and Assembly Instructions

1.1 Unpacking Your Treadmill

- Carefully remove the treadmill from the packaging. Retain all packaging materials until the assembly is complete.
- Ensure you have sufficient space to fully unfold the machine.

1.2 Required Tools

- Included Allen wrench
- Phillips screwdriver (not included)

1.3 Assembly Steps

1. **Position Frame:** Open the frame until it clicks into place.
2. **Attach Console:** Secure the console with the screws provided. Use the Allen wrench to tighten.
3. **Connect Electrical Wires:** Fit the console wires into the main body connectors.
4. **Install Handrails:** Use the Phillips screwdriver to attach the handrails.
5. **Power On:** Plug into a dedicated outlet and switch on the power via the main switch.

2. Using the Treadmill

2.1 Starting a Workout

- Press the 'Start' button to begin.
- Select desired speed using up and down arrows.
- Adjust the incline with the incline controls.

2.2 Preset Workout Programs

- Choose from 12 programs available on the control panel.
- Press 'Program' and select your workout.
- The program automatically adjusts speed and incline.

2.3 Monitoring Your Heart Rate

- Use the built-in hand pulse sensors or connect a heart rate monitor via Bluetooth for precise tracking.

3. Connectivity and Software

- Connect to the ProFit App via Bluetooth.
- Sync workout stats and track progress.

4. Troubleshooting

4.1 Common Issues

- **Machine doesn't start:** Check power supply and safety key.
- **Uneven speed:** Ensure the belt is centered.
- **Bluetooth Connectivity Issues:** Restart both the device and treadmill to re-establish connection.

5. Maintenance and Care

- Regularly check and tighten bolts and screws.
- Apply lubricant to the running deck every three months.
- Keep the treadmill clean and free of dust.

6. Safety Information

- Always use the safety key clip during workouts.
- Never dismount the treadmill while it's moving.

7. FAQs

- **How do I reset my treadmill?** – Hold the 'Stop' button for 5 seconds.
- **What is the maximum user weight?** – The treadmill supports up to 300 lbs.

Thank you for choosing the ProFit Runner Advance 3000 to support your fitness goals. For further assistance, contact our support team at support@profit.com or call 1-800-555-0199.