

QuickHeat Pro 30L Microwave Oven

Documentation

Overview:

The QuickHeat Pro 30L Microwave Oven is designed for modern kitchens, blending efficiency with style. This model offers a spacious 30-liter capacity, making it ideal for both small families and entertaining guests. With advanced convection cooking capabilities and a variety of pre-programmed settings, it promises a versatile cooking experience.

Features:

- **Capacity:** 30 Liters
- **Power Levels:** 10 adjustable settings
- **Cooking Functions:** Microwave, Convection, Grill
- **Smart Sensor:** Automatically adjusts cooking time
- **Interior:** Ceramic for easy cleaning
- **Safety:** Child lock feature
- **Energy Efficiency:** Rated A+ for energy savings

Specifications:

- **Dimensions:** 51 cm x 43 cm x 31 cm
- **Weight:** 15.5 kg
- **Power Consumption:** 1200 watts
- **Voltage Compatibility:** 110V/220V
- **Control:** Digital touch panel

Installation Instructions:

1. **Positioning:** Place the microwave on a flat, stable surface.
2. **Ventilation:** Ensure there is at least a 10 cm gap around the microwave for airflow.

3. **Power Source:** Ensure the outlet matches the microwave's voltage requirements.
4. **Turning On:** Plug the microwave in and press the power button on the control panel.

Using Your Microwave:

Basic Microwave Function:

1. Open the door, place the food into the microwave-safe container, and close the door securely.
2. Select the microwave button.
3. Use the touchpad to enter desired time and power level.
4. Press 'Start' to commence cooking.

Convection Cooking:

1. Preheat the oven using the convection mode.
2. Once preheated, insert the convection rack and place the food on it.
3. Follow the same steps as the microwaving process for setting time and temperature.
4. Begin cooking.

Grill Function:

1. Place food on the grill tray and insert it into the microwave.
2. Select the grill function and set the required time.
3. Press 'Start'.

Maintenance and Cleaning:

- **Interior:** Wipe with a damp cloth using mild detergent.
- **Door:** Clean with a soft, damp cloth to remove any food residue.
- **Turntable:** Remove and wash manually or in a dishwasher.

Troubleshooting:

- **Microwave Not Turning On:** Ensure it is properly plugged in and the power outlet is functioning.
- **Not Heating:** Check if the door is firmly closed and the selected power level is appropriate.
- **Error Code E1:** Indicates a sensor malfunction; unplug and reset the appliance.

Warranty Information:

- **Standard Warranty:** 1-year comprehensive warranty
- **Extended Warranty Available:** Extends coverage for an additional 2 years
- **Contact for Claims:** Reach out to our support with proof of purchase for warranty services.

Safety Warnings:

- Do not operate when empty.
- Avoid metal utensils during operation.
- Supervise children near the appliance.

For more details, support, or replacement parts, contact our 24/7 customer service line or visit our website.