

Product Overview

The RoboVac 4000 is a cutting-edge robotic vacuum cleaner designed to simplify your cleaning routine with intelligent technology and powerful suction capabilities. It features a sleek, modern design with advanced sensors to effortlessly navigate your home, avoiding obstacles and adjusting to various floor types. With an extended battery life and quiet operation, the RoboVac 4000 is your perfect home cleaning companion.

Key Features:

- High-efficiency filter system
- Smartphone app control
- Automatic docking and recharging
- Multi-surface cleaning

Setting Up the RoboVac 4000

Unboxing and Assembly

1. Carefully unpack the RoboVac 4000 and all its components.
2. Assemble any attachments such as brushes and the charging dock.
3. Place the charging dock against a wall in an accessible area.
4. Plug the charging dock into a power outlet and place the RoboVac on it to charge fully before the first use.

Initial Setup

1. Download the RoboVac app from your app store.
2. Create an account or log in.
3. Connect the RoboVac 4000 to your Wi-Fi network following the on-screen instructions.
4. Update the firmware if prompted to ensure optimal performance.

Operating Instructions

Starting a Cleaning Session

1. Open the RoboVac app or use the remote control.
2. Choose your desired cleaning mode:
3. **Automatic Cleaning:** The RoboVac 4000 cleans the entire floor on its own.
4. **Spot Cleaning:** Focuses on specific areas that require extra attention.
5. **Edge Cleaning:** Cleans the edges of rooms using wall sensors.
6. Press Start to begin the cleaning session.

Scheduling Cleanings

1. Access the scheduling feature in the RoboVac app.
2. Select the days and times when you want the RoboVac 4000 to clean automatically.
3. Save the schedule to enable hands-free cleaning.

Maintenance

Regular Maintenance

- **Dustbin Cleaning:** Empty the dustbin after each use.
- **Filter Replacement:** Replace the filter every 3 months to maintain suction power.
- **Brush Cleaning:** Remove tangled hair and debris from brushes weekly.

Software Updates

- Keep the RoboVac's firmware updated via the app to access new features and improvements.

Troubleshooting

Common Issues

- **RoboVac Not Charging:** Ensure the dock is plugged in and the RoboVac is properly aligned.
- **Wi-Fi Connectivity Issues:** Restart your router and try reconnecting the RoboVac.
- **Error Messages:** Refer to the app for error explanations and solutions.

Warranty and Service

Coverage

- The RoboVac 4000 is covered by a 1-year warranty for manufacturing defects.
- Does not cover wear and tear or misuse.

Service Procedure

- Contact customer support through the app or at support@robovac.com for claim procedures.
- Provide proof of purchase and details of the issue.

Safety and Compliance

- Do not use the RoboVac 4000 on wet surfaces.
- Keep away from open flames and heat sources.

Customer Support

For further assistance, reach out to our support team: - **Email:** support@robovac.com - **Phone:** 1-800-555-ROBO - **Hours:** Mon-Fri 9 AM - 5 PM EST