

Smart Adjustable Dining Table User Manual

Introduction

Welcome to your new Smart Adjustable Dining Table, a state-of-the-art furniture piece designed to blend modern aesthetics with advanced technology. This table is perfect for both everyday dining and large gatherings, offering flexibility, style, and convenience.

Product Specifications

- **Dimensions:**
 - Height: Adjustable from 28 to 34 inches
 - Length: 60 inches (expandable to 84 inches)
 - Width: 38 inches
- **Materials:**
 - Top: Tempered Glass
 - Frame: Solid Wood
 - Legs: Stainless Steel with adjustable height mechanism
- **Weight:** 90 lbs
- **Finish Options:** Walnut, Espresso, and Ash
- **Features:**
 - Expandable design with manual extension
 - Integrated Bluetooth connectivity for smart home integration
 - USB charging ports under the tabletop

Assembly Instructions

1. **Unpack the Components:** Carefully remove all components from the packaging. Check against the included parts list.
2. **Attach Legs to Frame:**
 3. Position the legs at the corners of the frame.
 4. Use the included screws and an Allen wrench to secure each leg.
 5. Ensure all screws are tightened firmly.
6. **Install Extension Mechanism:**

7. Align the extension rails with the frame grooves.
8. Slide in the extension leaves and secure with the locking mechanism.
9. **Connect Smart Features:**
10. Connect the table's power adapter to the port at the base.
11. Sync Bluetooth with your home system using the "Home Furniture" app available on Android and iOS.

Usage Instructions

- **Adjusting Height:**
 - Press the buttons on the side to raise or lower the table.
 - Set desired height, then release the button to lock in place.
- **Using Extension Feature:**
 - Pull apart the table's two ends.
 - Insert leaf extensions, aligning them correctly.
 - Slide table ends back to the center.
- **Smart Features:**
 - Use the "Home Furniture" app to control height settings and monitor connected devices charging status.

Common Troubleshooting

- **Table Not Powering On:**
 - Ensure the power adapter is securely connected.
 - Check for any network connectivity issues and reset Bluetooth.
- **Height Adjustment Issues:**
 - Check for obstructions blocking leg movement.
 - Reset the system by holding the power button for 10 seconds.
- **Smart Connectivity Problems:**
 - Restart the app and try reconnecting.
 - Consult the app's help section for advanced troubleshooting.

Warranty and Customer Support

- **Warranty:** 1-year manufacturer's warranty covering parts and labor.
- **Contact Support:** Reach out to our customer service at 1-800-555-0199 or support@homefurniture.com for assistance.

Safety Guidelines

- **Stability:** Always lock table legs and extensions firmly after adjustments.
- **Electrical Precautions:** Avoid placing liquids near charging ports and power connections.
- **Usage Limits:** Do not overload the table beyond the recommended weight limit.

Care and Maintenance

- **Cleaning:** Use a damp cloth with mild detergent for surface cleaning. Avoid harsh chemicals.
- **Maintenance Tips:** Check and tighten screws and bolts regularly to ensure stability.

Thank you for choosing the Smart Adjustable Dining Table. Enjoy the perfect dining experience with both sophistication and convenience.