

SmartPro X10 User Manual

Overview

Welcome to the SmartPro X10 experience! The SmartPro X10 is designed with cutting-edge technology to provide an enhanced user experience with superior performance, stunning visuals, and intuitive features. This document serves as your comprehensive guide to making the most of your device.

Features and Specifications

- **Display:** 6.7-inch QHD+ Super AMOLED
- **Camera:** 108MP Rear Quad Camera, 32MP Front Camera
- **Processor:** Octa-core 3.2 GHz
- **RAM:** 12GB
- **Storage:** 256GB, expandable up to 1TB
- **Battery:** 5000mAh with fast charging
- **Operating System:** SmartOS 15
- **Connectivity:** 5G, Bluetooth 5.2, Wi-Fi 6

Getting Started

Unboxing

1. Carefully open the SmartPro X10 packaging.
2. Inside the box, you will find:
3. SmartPro X10 handset
4. USB-C Charger
5. SIM eject tool
6. Quick Start Guide
7. Warranty card

Device Setup

1. **Insert the SIM Card:**
2. Use the SIM eject tool to open the SIM tray.
3. Insert your Nano-SIM card in the designated slot.
4. Reinsert the tray into the device.
5. **Power On and Initial Setup:**
6. Press and hold the power button on the right side.
7. Follow the on-screen instructions to select your preferred language, connect to Wi-Fi, and log into your SmartOS account.

Connecting to Wi-Fi

1. Go to **Settings > Wi-Fi**.
2. Choose your network and enter the password.
3. Confirm the connection.

Using Your SmartPro X10

Key Features

- **Camera Modes:** Access Pro, Night, Panorama, Slow Motion, and more.
- **Smart Assistant:** Activate with a voice command for hands-free tasks.
- **Security:** Facial recognition and fingerprint sensor for quick access.

Setting Up Apps

1. Open the SmartOS App Store.
2. Search and install apps to personalize your device.

Managing Battery Life

- Enable **Battery Saver** mode in **Settings** for extended use.

- Activate **Adaptive Charging** under **Battery Settings** to protect battery health.

Troubleshooting

Wi-Fi Connection Issues

1. Restart your router and reconnect by going to **Settings > Wi-Fi > Forget Network**, and reconnect.

Software Updates Failing

1. Ensure storage space is sufficient: **Settings > Storage**.
2. Restart the device and attempt the update again.

Payment Method Declined

- Verify that billing and account information match.
- Contact your bank to authorize the purchase if necessary.

Maintenance

- Regularly clear cache under **Settings > Storage**.
- Install updates promptly to ensure security and optimal performance.

Customer Support

For further assistance, contact SmartPro Support at: - **Phone:** 1-800-555-0199 - **Email:** support@smartpro.com

Warranty and Returns

- The SmartPro X10 comes with a 1-year manufacturer warranty.
- For returns, contact support within 30 days of purchase.
- Follow on-screen instructions to process returns, provided in your SmartOS account under **Orders and Returns**.

Legal and Safety Information

Please read the safety instructions provided with your SmartPro X10 to avoid potential hazards and ensure safe use of the device.

Thank you for choosing SmartPro X10. We're excited to be part of your journey to a smarter life!