

Product Overview

The StrideMaster Elite 4000 is designed for fitness enthusiasts seeking a robust and feature-rich treadmill for home use. Combining technology and comfort, it ensures a top-notch exercise experience.

Key Features

- **WhisperTech Motor:** Operates at low noise levels, ideal for home environments.
- **10-Inch Touchscreen Display:** Access workouts, track your progress, and stay entertained.
- **Bluetooth Connectivity:** Stream music and synchronize with fitness apps.
- **Integrated Heart Rate Monitor:** Stay within your target heart rate zones with built-in sensors.
- **Foldable Design:** Conveniently designed for easy storage when not in use.
- **350 lbs Weight Capacity:** Durable construction supports various users.

Assembly and Setup

1. **Unboxing:** Carefully unpack the treadmill. Ensure you have all components and assembly tools.
2. **Assembly:**
3. Attach the upright stands to the base using the provided bolts and tools.
4. Secure the console to the uprights and connect the display cables.
5. Attach the handrails and tighten all bolts securely.
6. **Powering On:** Connect to a power source and flip the power switch. The display should turn on immediately.
7. **Calibration:** Follow on-screen prompts to calibrate the speed and incline.

Using the StrideMaster

- **Starting a Workout:**

- Select a workout from the touchscreen. Options include interval training, fat burn, and custom goals.
- Adjust speed and incline to desired levels using quick-access buttons.

- **Using Bluetooth:**

- Enable Bluetooth on your device.
- Select the StrideMaster Elite 4000 from available devices to connect.

Maintenance

- **Regular Cleaning:** Wipe down the frame and console after use. Clean the belt and motor cover monthly.
- **Lubrication:** Apply lubrication beneath the belt every 150 miles walked. Use only manufacturer-approved lubricants.
- **Belt Calibration:** Check belt alignment monthly. Refer to the user manual for adjustment instructions.

Troubleshooting

- **The Treadmill Doesn't Start:**

- Confirm power connection and check if the safety key is in place.
- Reset the circuit breaker if needed.

- **Display Issues:**

- Restart the console and check cable connections between components.
- Update the software via the settings menu.

- **Unusual Noises:**

- Inspect for loose parts and secure any loose bolts.
- Check for debris under the belt and clean accordingly.

Warranty Information

The StrideMaster Elite 4000 comes with a two-year warranty covering parts and labor. An additional extended warranty can be purchased

for comprehensive coverage. Please retain your purchase receipt for warranty claims and visit our website to register your product.

Customer Support

For further assistance, please contact our support center at 1-800-FIT-HELP or visit our website for chat support and FAQ resources.

Safety Instructions

- Always wear appropriate footwear while exercising.
- Keep the area around the treadmill clear of objects.
- Consult a physician before beginning any exercise program on this treadmill, especially if you have pre-existing conditions.