

SyncSound Pro Wireless Headphones

Documentation

Introduction

Welcome to the SyncSound Pro Wireless Headphones by ElectroGadget. These premium headphones offer cutting-edge audio technology with features like advanced noise cancellation, high-definition sound, and up to 30 hours of battery life. Designed for ultimate convenience, they connect seamlessly with most Bluetooth-enabled devices, including smartphones, tablets, laptops, TVs, and gaming consoles.

Key Features

- **Bluetooth 5.0 Technology:** Ensures a stable connection and faster data transfer.
- **Active Noise Cancellation (ANC):** Immersive audio experience by reducing unwanted ambient sounds.
- **Water-Resistant IPX4:** Suitable for workouts and outdoor activities.
- **Built-in Microphone:** For hands-free calls and voice assistant access.
- **Comfort Fit Design:** Over-ear cushioned cups for prolonged listening comfort.

Setup and Installation

Pairing the Headphones

1. Activate pairing mode by pressing and holding the power button until the LED indicator flashes blue and red.
2. Enable Bluetooth on your device and select 'SyncSound Pro' from the list of available devices.
3. Confirm the pairing request on your device. The LED will turn solid blue once connected.

Connecting to a TV

- Ensure your TV supports Bluetooth audio output. Navigate to your TV's Bluetooth settings, initiate pairing, and select 'SyncSound Pro.'

Reconnecting to a Device

- If previously paired, the headphones will automatically reconnect to the last used device when powered on, as long as the device's Bluetooth is enabled.

Usage

Activating Noise Cancellation

- To activate ANC, press and hold the ANC button on the left earcup until you hear a beep.
- To deactivate, repeat the process.

Managing Battery Life

- The battery life icon on your connected device shows the remaining charge.
- Recharge the internal battery using the included USB-C cable. Full charge takes about 2 hours.

Compatibility

- **Smartphones & Tablets:** Works with Android and iOS platforms.
- **Laptops & PCs:** Compatible if the device supports Bluetooth 4.0 and above.
- **Gaming Consoles:** Compatible with consoles offering Bluetooth audio output.

Maintenance and Care

- Clean with a soft, dry cloth. Avoid using chemical cleaners.
- Store in the provided case to prevent damage.

Troubleshooting

Connectivity Issues

- Ensure the device is within 10 meters of the headphones.
- Restart both the device and headphones, and attempt pairing again.

Resetting Headphones

- Press and hold the power button for 15 seconds until the LED indicator flashes red three times, signifying a reset.

Sound Quality Problems

- Check battery level; lower battery may affect sound quality.
- Ensure ANC is activated if encountering excessive ambient noise.

Battery Not Charging

- Confirm the USB-C cable is functioning by testing with another device.
- Inspect charging port for debris.

Customer Support Information

For further assistance or warranty claims, contact ElectroGadget Support: - **Email:** support@electrogadget.com - **Phone:** 1-800-555-HEAD (4323) - **Operating Hours:** Mon-Fri 9:00 AM to 8:00 PM ET

Warranty Information

The SyncSound Pro Wireless Headphones come with a one-year limited warranty. Please retain your purchase receipt for warranty service. Visit our website for more information.

Thank you for choosing SyncSound Pro Wireless Headphones. Enjoy an unparalleled listening experience with ElectroGadget!