

Visiomeg UltraSmart 65 - User Manual

Introduction

Welcome to your new Visiomeg UltraSmart 65! This Smart TV is designed to transform your viewing experience with stunning visuals and a wide range of smart features. Before getting started, please read this manual to understand all functionalities and to help you set up your new TV.

Product Features

- **Screen Size:** 65 inches.
- **Resolution:** 4K Ultra HD (3840 x 2160 pixels).
- **Smart OS:** Visiomeg HarmonyOS.
- **Connectivity:** Wi-Fi, Bluetooth 5.0, Ethernet port, HDMI x4, USB 3.0 x2, Optical audio out.
- **Audio:** DTS TruSurround with dual 20W speakers.
- **Integrated Apps:** Access Netflix, YouTube, Amazon Prime Video, and more from the home screen.

Box Contents

- Visiomeg UltraSmart 65
- Remote control (batteries included)
- Power cable
- Quick start guide
- Warranty card

Initial Setup

1. **Unpack the TV:** Carefully remove the TV and its components from the box. Place the TV on a clean, flat surface.
2. **Connect the Stand:** If using the stand, attach it using the screws provided. For wall mounting, consult a professional installer.

3. **Power Connection:** Plug the power cable into the TV and the wall socket.
4. **Turn On the TV:** Use the remote control to turn on the TV.
5. **Language Selection:** Choose your preferred language when prompted.
6. **Network Configuration:**
7. Go to Settings > Network.
8. Select 'Wi-Fi Setup' and choose your Wi-Fi network from the list.
9. Enter the password carefully.
10. If using a wired connection, plug the Ethernet cable into the Ethernet port.
11. **Software Update:** Check for any available software updates to ensure the latest features and enhancements.

Using the Smart Features

- **Home Screen Navigation:** Access the home screen using the 'Home' button on the remote. Navigate through available apps using arrow keys.
- **App Store:** Download additional apps from the Visiomeg App Store.
- **Streaming Services:** Log in to your favorite streaming accounts directly from the TV.
- **Voice Control:** Use the microphone button on the remote to activate voice commands.

Picture and Sound Settings

- **Picture Mode:** Various modes like Cinema, Game, and Vivid are available. Adjust them under Settings > Picture.
- **Sound Mode:** Select from Standard, Music, Movie, and Custom under Settings > Sound.

Common Troubleshooting

- **Wi-Fi Connection Issues:**
- Ensure the TV is within range of your router.
- Restart your router and TV.

- Go to Settings > Network > Reset Network Settings to reconnect.
- **App Crashes:**
 - Check for software updates.
 - Uninstall and reinstall the app.
- **Remote Not Responding:**
 - Replace the batteries.
 - Re-pair the remote via Bluetooth in Settings > Remote.

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the screen and body. Avoid harsh chemicals.
- **Ventilation:** Ensure the back vents are unobstructed for proper airflow.
- **Power Surge Protection:** Use a surge protector to safeguard against electrical surges.

Customer Support

For further support, contact our customer service: - Phone: 1-800-VISIO-ME - Email: support@visiomeg.com - Online Chat: Available on our website

Warranty

The Visiomeg UltraSmart 65 comes with a standard 2-year warranty. Please retain your purchase receipt for warranty claims.

Conclusion

We hope you enjoy your Visiomeg UltraSmart 65 as an integral part of your home entertainment. Thank you for choosing us!