

VisionMax Ultra 4K Smart TV

Documentation

Product Overview

The VisionMax Ultra 4K Smart TV delivers breathtaking image quality with its advanced Ultra HD resolution. Equipped with smart technology, users can seamlessly stream their favorite content from the most popular apps directly on their TV. Available in screen sizes ranging from 55 to 75 inches, it's designed to fit any living room setup. The sleek, bezel-less design adds a modern touch to your entertainment space.

Included in the Box

- VisionMax Ultra 4K Smart TV
- Smart Remote Control with Batteries
- Wall Mount Kit
- User Manual
- Power Cable
- HDMI Cable

Setup Instructions

Initial Setup

- 1. Unboxing and Placement:**
- Carefully remove the TV from the box and place it on a flat, stable surface.
- Use the provided wall-mount kit if preferred. Refer to the wall-mount guide included in your manual.
- 4. Connecting to Power:**
- Plug the power cable into the TV and a nearby electrical outlet.
- Press the power button on the TV or remote control to turn it on.

7. Connecting to Wi-Fi:

8. Access the 'Menu' using your remote.
9. Navigate to 'Settings' -> 'Network' -> 'Wi-Fi Settings.'
10. Select your network from the list and enter your Wi-Fi password.
11. Press 'Connect.'

Pairing the Remote

- Press and hold the 'Pair' button on the remote for 5 seconds until the pairing prompt appears on-screen.
- Follow the on-screen instructions to complete the pairing process.

Feature Guide

Smart Features

- **App Installation:**
 - Navigate to the 'App Store' from the home menu.
 - Search for popular apps such as Netflix, Amazon Prime, or YouTube.
 - Select 'Install' to download and add them to your dashboard.
- **Bluetooth Connectivity:**
 - Access 'Settings' -> 'Bluetooth Devices.'
 - Turn on Bluetooth and pair with your headphones or other compatible devices.

Troubleshooting

Wi-Fi Connection Issues

1. **Verify Wi-Fi Signal:** Make sure other devices are connected to your network.
2. **Reset Network Settings:**
 3. Go to 'Settings' -> 'Network' -> 'Reset Network Settings.'
 4. Re-enter your Wi-Fi credentials.

5. Restart Devices:

6. Turn off your router and TV.
7. Turn them back on after 2 minutes.

Remote Control Not Responding

1. **Check Batteries:** Replace with new batteries if needed.
2. **Reset the Remote:**
3. Remove batteries, press all buttons thrice, then reinsert batteries.
4. **Re-pair Remote:** Follow the pairing instructions in the initial setup.

Screen Display Issues

1. **Check Connections:** Ensure all cables (HDMI, Power) are securely connected.
2. **Power Cycle the TV:** Unplug the TV for a few minutes before plugging it back in.

Maintenance and Care

- Regularly dust the screen and exterior using a soft, dry cloth.
- Avoid using liquid cleaners directly on the screen.
- Use surge protectors to protect against voltage spikes.

Customer Support

For any further assistance, contact our support team via phone or email provided in your purchase documentation.

End of Documentation