

Precautions for Using the Robotic Arm

1. Recommended load capacity: less than 40 g.
2. Ensure there are no objects around the robotic arm that may obstruct its movement.
3. Do not forcibly twist any joints of the robotic arm while it is powered on and in operation.
4. Avoid gripping objects with the robotic claw for extended periods. It is recommended not to grip objects tightly for more than 40 seconds.
5. If the servo motor controlling the claw does not receive a command to control the claw again within 40 seconds, it will automatically shut off to protect the servo.