



ULTRA AVIATION SERVICES, INC.

General Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 18-001

Date: 5/Jan/18

SUBJECT: TOW BAR

APPLICABLE TO: ALL ULTRA RAMP Agents

Recently we had a near miss incident in which the tow bar disconnected from the nose gear as the aircraft was been push back

The result of the investigation revealed that the crew did not properly attached the tow bar to the aircraft.

remember when assigned to hook a tow bar to the nose gear and push back tractor you must.

1- Make sure that you have the correct by pass pin for the aircraft been push

2- Make sure that the tow bar is fully functional

a- check tires

b- check hydraulic pump (if applicable)

c- Make sure that the if the tow bar is equip with safety pin that you use it.

3- Once the tow bar is hooked up and the safety pin is in position move try to move the tow bar from side to side to see if it is properly connected and won't dislodge

4- Always connect to aircraft first and them to push back tractor

5- When disconnecting, disconnect from the tractor first them from aircraft.

WHEN IN DOUBT, STOP AND ASK

BE SAFE OBEY ALL THE LAWS AND COMPANY SOP

PREPARED BY:

Your friendly Safety Department